### **NAME**

hp-clean - Printer Printhead Cleaning Utility

#### **DESCRIPTION**

Printhead cleaning utility for HPLIP supported inkjet printers.

### **SYNOPSIS**

# hp-clean [DEVICE\_URI|PRINTER\_NAME] [MODE] [OPTIONS]

# PRINTER|DEVICE-URI

```
To specify a device-URI:
-d<device-uri> or --device=<device-uri>
To specify a CUPS printer:
-p<pri>-p<pri>-printer> or --printer=<pri>-p
```

### **MODE**

Run in interactive mode:

-i or --interactive

# **OPTIONS**

```
Set the logging level:
```

```
-l<level> or --logging=<level> <level>: none, info*, error, warn, debug (*default)
```

Run in debug mode:

```
-g (same as option: -ldebug)
```

This help information:

-h or --help

### **SEE ALSO**

hp-align hp-clean hp-linefeedcal hp-pqdiag

#### **AUTHOR**

HPLIP (HP Linux Imaging and Printing) is an HP developed solution for printing, scanning, and faxing with HP inkjet and laser based printers in Linux.

# REPORTING BUGS

The HPLIP Launchpad.net site **https://launchpad.net/hplip** is available to get help, report bugs, make suggestions, discuss the HPLIP project or otherwise contact the HPLIP Team.

# **COPYRIGHT**

Copyright (c) 2001-18 HP Development Company, L.P.

This software comes with ABSOLUTELY NO WARRANTY. This is free software, and you are welcome to distribute it under certain conditions. See COPYING file for more details.