NAME
ts_verify – A basic test routine for tslib's API.

SYNOPSIS
ts_print_mt [OPTION]

DESCRIPTION
ts_verify runs through tslib's API and prints test results.

−i, −−idev

Explicitly choose the original input event device for tslib to use. Default: the environment variable **TSLIB_TSDEVICE**'s value.

−h, −−help
Print usage help and exit.

SEE ALSO
ts.conf (5), ts_test (1), ts_test_mt (1), ts_calibrate (1)