NAME

sane-hp - SANE backend for HP ScanJet scanners

DESCRIPTION

The **sane-hp** library implements a SANE (Scanner Access Now Easy) backend that provides access to HP ScanJet scanners which support SCL (Scanner Control Language by HP). The following scanners are known positively to work with this backend:

Model:	Product id:	Interface:
		HP Parallel Interface Card
ScanJet IIc	C1750A 3226	SCSI
ScanJet IIcx	C2500A 3332	SCSI
ScanJet IIp	C1790A	SCSI
ScanJet 3C	C2520A 3503	SCSI
ScanJet 3P	C2570A 3406	SCSI
ScanJet 4C	C2520A	SCSI
ScanJet 4P	C1130A 3540	SCSI
ScanJet 4100C	C6290A	USB
ScanJet 5P	C5110A	SCSI
ScanJet 5100C	C5190A	parallel port
ScanJet 5200C	C7190A 3846	parallel port/USB
ScanJet 6100C	C2520A 3644	SCSI
ScanJet 6200C	C6270A 3828	SCSI/USB
ScanJet 6250C	C6270A 3828	SCSI/USB
ScanJet 6300C	C7670A	SCSI/USB
ScanJet 6350C	C7670A	SCSI/USB
ScanJet 6390C	C7670A	SCSI/USB
PhotoSmart	C5100A R029,R03	0,R032 SCSI

Support for models 5100C/5200C connected to the parallel port requires the ppSCSI driver available at http://cyberelk.net/tim/parport/ppscsi.html and http://penguin-breeder.org/kernel/download/.

Support for models 5200C/62X0C/63X0C connected to the USB require the kernel scanner driver or libusb. See **sane–usb**(5) for more details.

The **sane-hp** backend no longer supports OfficeJet multi-function peripherals. For these devices use the external "hpoj" backend in version 0.90 and later of the "HP OfficeJet Linux driver", available at http://hpoj.sourceforge.net

Because Hewlett-Packard does no longer produce scanners that support SCL (beside the OfficeJets), the above list of supported scanners is complete. Other HP scanners are not supported by the **sane-hp** backend, but might be supported by another one. See http://www.sane-project.org/. You can also watch the sane-devel mailing list at http://www.sane-project.org/mailing-lists.html.

More details about the hp backend can be found on its homepage http://www.kirchgessner.net/sane.html.

DEVICE NAMES

This backend expects device names of the form:

special

Where *special* is the UNIX path-name for the special device that corresponds to the scanner. For SCSI scanners the special device name must be a generic SCSI device or a symlink to such a device. Under Linux, such a device name could be /dev/sga or /dev/sg2, for example. If the special device name contains "usb", "uscanner" or "ugen", it is assumed that the scanner is connected by USB. For the HP ScanJet Plus the special device name must be the device that corresponds to the parallel interface card that was shipped with the scanner. That is /dev/hpscan. A special driver is required for this card. See ftp://rvs.ctrl-c.liu.se/pub/wingel/hpscan for details. If the link does not work, try

13 Jul 2008

ftp://sunsite.unc.edu/pub/Linux/kernel/patches/scanners.

CONFIGURATION

The contents of the *hp.conf* file is a list of options and device names that correspond to HP ScanJet scanners. Empty lines and lines starting with a hash mark (#) are ignored. Seesane–scsi(5) and sane–usb(5) on details of what constitutes a valid device name.

Options specified in front of the first line that contains a device name are defaults for all devices. Options specified below a line that contains a device name apply just to the most recently mentioned device.

Supported options are connect-scsi, connect-device, enable-image-buffering, and dumb-read.

Option **connect-scsi** specifies that the scanner is connected to the system by SCSI. Input/output is performed using SCSI-commands. This is the default. But if your SCSI device name contains "usb", "uscanner" or "ugen", option connect-scsi must be specified. Otherwise it is assumed that the scanner is connected by USB.

Option **connect—device** specifies that the scanner is connected to the system by a special device. Input/out-put is performed by **read**()/**write**()-operations on the device. This option must be used for HP ScanJet Plus or scanners connected to USB which are accessed through a named device (e.g. /dev/usb/scanner0). For device names that contain "usb", "uscanner" or "ugen", it is not necessary to specify option connect—device.

Option **enable-image-buffering** stores the scanned image in memory before passing it to the frontend. Could be used in case of forward/backward moving scanner lamp.

Option **dumb—read** can be used to work around problems with "Error during device I/O". These problems may occur with certain SCSI-to-USB converters or Buslogic SCSI cards. The option should not be used for SCSI devices which are working correctly. Otherwise startup of frontends and changing parameters might be slower.

A sample configuration file is shown below:

```
/dev/scanner
# this is a comment
/dev/hpscan
option connect-device
```

/dev/scanner is typically a symlink to the actual SCSI scanner device.

FILES

/etc/sane.d/hp.conf

The backend configuration file (see also description of SANE_CONFIG_DIR below).

/usr/lib/x86_64-linux-gnu/sane/libsane-hp.a

The static library implementing this backend.

/usr/lib/x86_64-linux-gnu/sane/libsane-hp.so

The shared library implementing this backend (present on systems that support dynamic loading).

\$HOME/.sane/calib-hp:<device>.dat

Calibration data for HP PhotoSmart PhotoScanner that is retrieved from the scanner after calibration. The data is uploaded to the scanner at start of the backend if it is in media mode 'print media' or if the media mode is changed to 'print media'.

ENVIRONMENT

SANE_CONFIG_DIR

This environment variable specifies the list of directories that may contain the configuration file. On *NIX systems, the directories are separated by a colon (':'), under OS/2, they are separated by a semi-colon (';'). If this variable is not set, the configuration file is searched in two default directories: first, the current working directory (.) and then in/etc/sane .d. If the value of the environment variable ends with the directory separator character, then the default directories are searched

13 Jul 2008 2

after the explicitly specified directories. For example, setting **SANE_CONFIG_DIR** to "/tmp/config:" would result in directories *tmp/config*, ., and /etc/sane.d being searched (in this order).

SANE_DEBUG_HP

If the library was compiled with debug support enabled, this environment variable controls the debug level for this backend. E.g., a value of 128 requests all debug output to be printed. Smaller levels reduce verbosity.

SANE_HOME_HP

Only used for OS/2 and along with use of HP PhotoSmart PhotoScanner. Must be set to the directory where the directory same is located. Is used to save and read the calibration file.

SANE_HP_KEEPOPEN_SCSI

SANE_HP_KEEPOPEN_USB

SANE HP KEEPOPEN DEVICE

For each type of connection (connect—scsi, connect—usb, connect—device) it can be specified if the connection to the device should be kept open ("1") or not ("0"). Usually the connections are closed after an operation is performed. Keeping connection open to SCSI-devices can result in errors during device IO when the scanner has not been used for some time. By default, USB-connections are kept open. Other connections are closed.

SANE HP RDREDO

Specifies number of retries for read operation before returning an EOF error. Only supported for non-SCSI devices. Default: 1 retry. Time between retries is 0.1 seconds.

BUGS

HP PhotoSmart PhotoScanner

In media mode 'slide' and 'negative', scan resolutions are rounded to multiple of 300 dpi. The scanner does not scale the data correctly on other resolutions. Some newer models (firmware code R030 and later) do not support adjustment of contrast/intensity level and tone map. The backend will simulate this by software, but only for gray and 24 bit color.

Automatic Document Feeder (ADF)

For use of the ADF with **xscanimage**(1), first place paper in the ADF and then change option scan source to 'ADF'. Press 'change document' to load a sheet. Then press 'scan' to start a scan. Maybe it is sufficient to press 'scan' without 'change document' for repeated scans. The use of the preview window is not recommended when working with the ADF. Setting a window to scan from ADF is not supported with **xscanimage**(1). Try **xsane**(1).

Immediate actions

Some actions in **xscanimage**(1) (i.e. unload, select media, calibrate) have an immediate effect on the scanner without starting a scan. These options can not be used with **scanimage**(1).

TODO

HP PhotoSmart PhotoScanner

PhotoScanners with firmware release R030 and up have no firmware support for contrast/brightness/gamma table. In the current backend this is simulated by software on 24 bits data. Simulation on 30 bits should give better results.

Data widths greater than 8 bits

Custom gamma table does not work.

Parallel scanner support

Beside the ScanJet Plus which came with its own parallel interface card, currently only the HP ScanJet 5100C/5200C are supported. These scanners are using an internal parallel-to-SCSI converter which is supported by the ppSCSI-driver (see above).

13 Jul 2008 3

SEE ALSO

 $sane(7), sane-scsi(5), sane-usb(5) \ scanimage(1), xscanimage(1), scanimage(1)\\$

AUTHOR

The sane-hp backend was written by Geoffrey T. Dairiki. HP PhotoSmart PhotoScanner support by Peter Kirchgessner.

13 Jul 2008 4