NAME

sane-p5 - SANE backend for the Primax PagePartner

DESCRIPTION

The **sane-p5** library implements a SANE (Scanner Access Now Easy) backend that provides access to the Primax PagePartner parallel port sheet fed scanner.

This backend handles 100, 150, 200, 300 and 600 dpi scan resolutions, in color and gray modes. The 600 dpi is actually 300x600 with lines enlarged to match the vertical resolution.

EPP/ECP MODES ONLY The current version of the backend uses only EPP or ECP mode to communicate with the scanner. It is recommended that you set your parallel port to EPP in BIOS with the current version of this backend. ECPEPP will only work if you use a 2.4 or 2.6 kernel with ppdev character device support.

DEVICE NAMES

This backend expects device names of the form:

port value

Where value is:

auto autodetect all parallel ports and probe them for scanner

/dev/parport0

uses linux ppdev device, depending on the number of available parallel port, you have to use /dev/parport1, /dev/parport2, ...

You can rename any device using the

option name my_name

option. This option apply to the last port option.

CONFIGURATION

Please make sure to edit dll.conf before you use the backend, since this backend isn't enabled by default.

FILES

/etc/sane.d/p5.conf

The backend configuration file (see also description of **SANE_CONFIG_DIR** below).

/usr/lib/x86_64-linux-gnu/sane/libsane-p5.a

The static library implementing this backend.

/usr/lib/x86_64-linux-gnu/sane/libsane-p5.so

The shared library implementing this backend (present on systems that support dynamic loading).

ENVIRONMENT

SANE_CONFIG_DIR

This environment variable specifies the list of directories that may contain the configuration file. On *NIX systems, the directories are separated by a colon (':'), under OS/2, they are separated by a semi-colon (';'). If this variable is not set, the configuration file is searched in two default directories: first, the current working directory (".") and then in /etc/sane.d. If the value of the environment variable ends with the directory separator character, then the default directories are searched after the explicitly specified directories. For example, setting SANE_CONFIG_DIR to "/tmp/config:" would result in directories tmp/config, ., and /etc/sane.d being searched (in this order).

SANE_DEBUG_P5

If the library was compiled with debug support enabled, this environment variable controls the debug level for this backend. E.g., a value of 255 requests all debug output to be printed. Smaller levels reduce verbosity.

15 Feb 2010 1

level	debug output
0	critical errors
1	errors
2	warnings & minor errors
4	information messages
8	start/stop of functions
16	tracing messages
32	I/O functions
64	I/O functions with traces
128	scanned/calibration data

SEE ALSO

sane(7), sane-net(5), saned(8), scanimage(1)

AUTHOR

Stéphane Voltz < stef.dev@free.fr>

CREDITS

Support for the Prima PagePartner has been made possible thank to an hardware donation by Sébastien Lange.

BUG REPORTS

If something doesn't work mail sane-devel@alioth-lists.debian.net or submit an issue via https://git-lab.com/sane-project/backends/issues/new with a label of backend/p5. Please give as much information as you can.

SANE version

run "scanimage -V" to determine this

the backend version and your scanner hardware

run $SANE_DEBUG_P5=255$ scanimage -L 2>log as root. If you don't get any output from the p5 backend, make sure a line "p5" is included into your /etc/sane.d/dll.conf. If your scanner isn't detected, make sure you've defined the right port address, or the correct device in your p5.conf.

the name of your scanner/vendor

also a worthy information. Please also include the optical resolution and lamp type of your scanner, both can be found in the manual of your scanner.

any further comments

if you have comments about the documentation (what could be done better), or you think I should know something, please include it.

15 Feb 2010 2