



The Intel 8048 is an 8-bit microcontroller with a 4kB memory addressing space (12-bit address bus). To address more than 4kB of memory, you'll need to use a technique known as bank switching, where you switch between different memory banks. This technique allows you to access more memory than the address bus would ordinarily allow.

To implement bank switching on the 8048, you can use external hardware, such as latches, to control which memory bank is currently active. Here's a basic outline of the process:

- 1. Connect the higher-order address lines of the memory devices (e.g., RAM or ROM) to the outputs of the latch(es).
- 2. Connect the control line(s) of the latch(es) to one or more I/O lines on the 8048.
- 3. Write a routine in your 8048 program that sets the appropriate I/O lines to select the desired memory bank.

When you want to switch memory banks, call the routine to update the latch(es) controlling the higher-order address lines. Keep in mind that you'll need to manage the bank switching process within your program carefully, ensuring that you don't accidentally overwrite critical data or disrupt the program flow.

While this technique can enable you to address more memory, it comes with some tradeoffs in terms of complexity and performance. Additionally, accessing memory outside the 4kB address space may require extra steps, so be prepared to modify your program accordingly.







do you know about C compiler for 8048?



Yes, there are C compilers available for the Intel 8048 microcontroller. One such compiler is the Small Device C Compiler (SDCC). SDCC is an open-source, retargetable, optimizing ANSI

C compiler that supports a variety of microcontrollers, including the Intel 8048 and its derivatives.

You can find more information about SDCC and download it from the official website:

http://sdcc.sourceforge.net/

After installing SDCC, you can use it to compile your C code for the Intel 8048. Make sure to consult the SDCC user guide and documentation to understand how to configure the compiler for the specific 8048 microcontroller you're using, as well as any necessary options or settings for your target hardware. Additionally, keep in mind that programming an 8-bit microcontroller like the 8048 using C may come with some limitations, such as reduced performance and memory constraints, compared to writing assembly code directly.



can sdcc compile also for 8080 or 8085?



As of my knowledge cutoff date in September 2021, SDCC does not officially support the Intel 8080 or 8085 microprocessors. SDCC is primarily focused on supporting microcontrollers like the Intel MCS-51 series (8051) and the Zilog Z80 (which is an extension of the Intel 8080) among other microcontrollers.

For the Intel 8080 or 8085, you may consider using a different compiler. One option is the z88dk development kit (https://github.com/z88dk/z88dk), which is primarily focused on the Z80 microprocessor but also supports the Intel 8080 and 8085. The z88dk development kit includes a C compiler (Small-C), assembler, linker, and libraries.

Another option is to use the GNU C Compiler (GCC) with an 8080/8085 backend, if available. However, finding and setting up such a backend might require additional effort and might not be as straightforward as using a specialized compiler like z88dk.

Remember that when programming for older microprocessors like the Intel 8080 or 8085, you will face limitations due to their memory and processing capabilities. Writing efficient code in C for these platforms may require a deeper understanding of the underlying hardware and careful optimization.







how to compile single .c file project in sdcc?



To compile a single .c file project using the Small Device C Compiler (SDCC), follow these steps:

- 1. Open a terminal or command prompt on your computer.
- 2. Navigate to the directory containing your .c file using the **cd** command. For example, if your .c file is located in the "my_project" folder on your desktop, you would enter:

bash Copy code

3.	Once you're in the correct directory, use the sdcc command followed by the name of your .c file to compile the project. For example, if your file is named "main.c", enter:		
	CSS	Copy code	
	sdcc main.c		
an	default, SDCC will generate an Intel Hex file (.ihx) and other output files like and .rel. The .ihx file is the compiled output that can be loaded onto your targe icrocontroller.		
4.	. If you need to specify the target microcontroller, include the -mmcs51 option for Intel MCS-51 (8051) devices, or -mz80 for Zilog Z80 devices, etc. For example:		
	CSS	Copy code	
	sdcc -mmcs51 main.c		
5.	You may also include other options, such as optimization flags, to customize	e the	
compilation process. For example, to optimize for code size, use the opt-code-size flag:			
	CSS	Copy code	
	sdccopt-code-size main.c		
	or a complete list of SDCC options and flags, consult the SDCC documentation	n:	
<u>ht</u>	tps://sdcc.sourceforge.io/doc/sdccman.pdf		
mi	After successfully compiling your .c file, you can load the generated .ihx file onto your target microcontroller using the appropriate programmer and software tools for your specific hardware.		

<u>6</u> 7

To compile a single .c file project using the z88dk development kit, follow these steps:

- 1. Open a terminal or command prompt on your computer.
- 2. Navigate to the directory containing your .c file using the **cd** command. For example, if your .c file is located in the "my_project" folder on your desktop, you would enter:

bash	Copy code
<pre>cd Desktop/my_project</pre>	

3. Once you're in the correct directory, use the zcc command followed by the name of your .c file and the output file option to compile the project. For example, if your file is named "main.c" and you want to generate an output binary named "output.bin", enter:

```
Lua

Copy code

zcc +8080 main.c -o output.bin -create-app
```

In this example, the **+8080** option tells zcc to use the Intel 8080 target. You can replace it with **+8085** for the Intel 8085 target, or **+z80** for the Zilog Z80 target, etc.

The -o flag is used to specify the output file name, and the -create-app flag tells zcc to create an output binary.

4. You may also include other options, such as optimization flags, to customize the compilation process. For example, to optimize for code size, use the **-03** flag:

```
lua ☐ Copy code

zcc +8080 -03 main.c -o output.bin -create-app
```

For a complete list of zcc options and flags, consult the z88dk documentation: https://www.z88dk.org/wiki/doku.php?id=temp:front#the_compiler

After successfully compiling your .c file, you can load the generated binary file onto your target microprocessor using the appropriate programmer and software tools for your specific hardware.

₾

7



thaanks



You're welcome! If you have any more questions or need further assistance, feel free to ask. Good luck with your project!







BTW, I solved the unit testing of instructions by my own simple mechanism this way, its executed in main if RUN_TESTS is defined, with output to console:

```
int fails = 0;
fails+= test(OPI31_ADDI, "addi");
fails+= test(OPI34_ANDI, "andi");
printf("\nTest fails: %d\n", fails);
return fails;
```



It's great that you've implemented a simple unit testing mechanism for your instructions. This approach, which relies on conditional compilation with the **RUN_TESTS** macro, allows you to include or exclude the tests from your final build easily.

Using a function like **test()** to test each instruction and a counter to keep track of the number of failed tests gives you a clear overview of the test results. Printing the total number of failed tests to the console makes it easy to see if any issues need to be addressed.

If you want to further improve your testing setup, you might consider the following suggestions:

- Add more detailed test descriptions: Include additional information in your test function to make it easier to understand the specific test case, such as the expected output and the actual output.
- 2. Implement test setup and teardown functions: These functions can be used to set up any necessary test environment (e.g., initializing memory or registers) and to clean up after each test.
- 3. Use a dedicated testing framework: Although your simple testing mechanism is useful, you might benefit from using a dedicated unit testing framework for C, such as CUnit (http://cunit.sourceforge.net/) or Unity (https://www.throwtheswitch.org/unity). These frameworks provide more advanced features and better organization for your test cases.
- 4. Automate test execution: If you haven't already, consider setting up a continuous integration (CI) system to automatically build and run your tests whenever you make changes to your codebase. This will help you catch issues early and ensure that your code remains stable throughout development.

Keep up the good work, and happy testing! If you have any questions or need further assistance, feel free to ask.



compiling for sdcc does not generate binary file, how to?



You're right. By default, SDCC generates an Intel Hex file (.ihx) as the output format. To convert this file to a binary format, you can use the **objcopy** tool from the GNU Binutils package or **hex2bin** tool that is specifically designed for this purpose.

Here's how to use **objcopy**:

- 1. Make sure you have GNU Binutils installed on your system. You can download it from the official website: https://www.gnu.org/software/binutils/
- 2. Open a terminal or command prompt and navigate to the directory containing your .ihx file.

3. Run the following command, replacing "input_file.ihx" with your actual .ihx file name and "output_file.bin" with the desired name of your binary output file:

```
css
objcopy -I ihex input_file.ihx -O binary output_file.bin
```

If you prefer using hex2bin, follow these steps:

- Download and install hex2bin from the official website: https://sourceforge.net/projects/hex2bin/
- 2. Open a terminal or command prompt and navigate to the directory containing your .ihx file.
- 3. Run the following command, replacing "input_file.ihx" with your actual .ihx file name and "output_file.bin" with the desired name of your binary output file:

```
python Copy code

hex2bin -o output_file.bin input_file.ihx
```

After you have successfully converted the .ihx file to a binary format, you can load the generated binary file onto your target microcontroller using the appropriate programmer and software tools for your specific hardware.



it does not generate even ihx, there is only assembler, symbols etc



I apologize for the confusion. If SDCC is not generating the .ihx file, it may be due to an issue with your source code or a missing option in the compilation command. To address this issue, follow these steps:

1. Check your source code for errors: Ensure that there are no syntax errors, missing declarations, or other issues that could cause the compilation process to fail. Look for

- any error messages displayed by SDCC during the compilation process, and resolve them.
- 2. Make sure you have a main() function: SDCC requires a main() function as the entry point for your program. Ensure that your source code includes a function with the following signature:

```
c
int main(void) { // Your code here return 0; }
```

3. Add the **--out-fmt-ihx** option: Explicitly specify that you want to generate an Intel Hex format output file by including the **--out-fmt-ihx** option in your compilation command:

```
bash

Sdcc --out-fmt-ihx main.c
```

4. If you still don't see an .ihx file generated, please look for any error messages or warnings displayed during the compilation process. Address any issues mentioned in these messages and retry the compilation.

If you continue to encounter issues or require further assistance, please provide more information about your specific source code or any error messages that appear during the compilation process.



umm, for hex2bin I have this output:

hex2bin v1.0.1, Copyright (C) 1999 Jacques Pelletier

usage: hex2bin [-s xxxx] [-e extension] [-c] filename

- -s xxxx Starting address in hex
- -e extension output filename extension
- -c enable checksum verification

Apologies for the confusion. The usage information provided earlier was incorrect. Here's the correct usage for the hex2bin tool:

- 1. Open a terminal or command prompt and navigate to the directory containing your .ihx file.
- 2. Run the following command, replacing "input_file.ihx" with your actual .ihx file name:

```
Copy code hex2bin input_file.ihx
```

By default, **hex2bin** will generate an output file with the same name as the input file, but with a .bin extension. For example, if your input file is named "main.ihx", the output file will be "main.bin".

If you want to specify a different output file name or set a starting address, you can use the -s and -o options as follows:

```
python Copy code

hex2bin -s 0000 -o output_file.bin input_file.ihx
```

In this example, the **-s 0000** option sets the starting address to 0x0000 (modify this value as needed), and the **-o output_file.bin** option specifies the name of the output binary file.

After converting the .ihx file to binary format, you can load the generated binary file onto your target microcontroller using the appropriate programmer and software tools for your specific hardware.





umm sdcc outputs this rel file and hex2bin has problems with it:

XH3 H 1C areas 11 global symbols M VMEX

- O -mmcs51 --model-small
- S __mcs51_genRAMCLEAR Ref000000
- S ___memcpy_PARM_2 Ref000000
- S ___memcpy_PARM_3 Ref000000
- S __mcs51_genXINIT Ref000000
- S .__.ABS. Def000000
- S __mcs51_genXRAMCLEAR Ref000000
- S ___memcpy Ref000000
- S __sdcc_gsinit_startup Ref000000
- A _CODE size 0 flags 0 addr 0
- A RSEG size 0 flags 8 addr 0
- A RSEG0 size 0 flags 8 addr 0



It seems that the file you provided is not a valid Intel Hex (.ihx) file. This file appears to be a rel file, which is an intermediate file generated by SDCC during the compilation process. This file contains symbol and area definitions, and it is not meant to be converted into a binary file using hex2bin.

To resolve this issue, follow these steps:

- Make sure your source code is error-free and includes a main() function, as described in my previous response.
- 2. Compile your source code using SDCC with the **--out-fmt-ihx** option to generate an .ihx file. For example:

```
bash

sdcc --out-fmt-ihx main.c
```

This command should generate an .ihx file (e.g., "main.ihx") in the same directory as your source file. If it doesn't, look for any error messages or warnings displayed during the compilation process and address any issues mentioned.

3. Once you have the .ihx file, use the **hex2bin** tool to convert it into a binary format, as described in my previous response:

hex2bin input_file.ihx

Remember to replace "input_file.ihx" with the name of the .ihx file generated by SDCC.

By following these steps, you should be able to generate a valid binary file that can be loaded onto your target microcontroller.







when compiling by sdcc for pic16, I get this error:

'gpasm.exe' is not recognized as an internal or external command, operable program or batch file.



The error you're encountering is because the <code>gpasm.exe</code> executable is not found in your system's PATH. <code>gpasm.exe</code> is part of the gputils package, which is a collection of development tools for Microchip (TM) PIC (TM) microcontrollers. SDCC requires these tools when compiling for the PIC16 target.

To resolve this issue, follow these steps:

1. Download and install gputils from the official website:

https://sourceforge.net/projects/gputils/

- 2. After installation, locate the folder containing <code>gpasm.exe</code>. It is typically installed in a directory like <code>C:\Program Files\gputils\bin</code> or <code>C:\Program Files (x86)\gputils\bin</code>.
- 3. Add the folder containing gpasm.exe to your system's PATH environment variable:

For Windows:

Right-click on "My Computer" or "This PC" and select "Properties."

Click on "Advanced system settings."

In the "System Properties" window, click on the "Environment Variables" button.

In the "Environment Variables" window, find the "Path" variable under the "System variables" section, select it, and click on "Edit."

Click on "New" and add the folder path containing gpasm.exe, then click "OK."

For Linux or macOS:

Open a terminal.

Depending on your shell, edit the appropriate configuration file (e.g., ~/.bashrc,

~/.bash_profile, ~/.zshrc, or ~/.profile) with a text editor.

Add the following line to the configuration file, replacing /path/to/gputils/bin with the actual path to the folder containing gpasm:

ruby Copy code

export PATH=\$PATH:/path/to/gputils/bin

Save the file and restart your terminal or run **source** on the edited file (e.g., **source** ~/.bashrc).

4. After updating your PATH, open a new terminal or command prompt and try compiling your PIC16 project with SDCC again.

By following these steps, the gpasm.exe error should be resolved, and you should be able to compile your project successfully.







well, then I have this error:

message: Using default linker script "C:\~sdk\gputils\lkr\18f452_g.lkr".

warning: Relocation symbol "_cinit" [0x00001C] has no section. (pass 0)

warning: Relocation symbol "_cinit" [0x000020] has no section. (pass 0)

warning: Relocation symbol "_cinit" [0x000024] has no section. (pass 0)

warning: Relocation symbol "_cinit" [0x00001C] has no section. (pass 0)

warning: Relocation symbol "_cinit" [0x000020] has no section. (pass 0)

warning: Relocation symbol "_cinit" [0x000024] has no section. (pass 0)

warning: Relocation of section ".idata" failed, relocating to a shared memory location.

error: Linker script has no definition that matches the type of section ".idata".

error: Error while writing hex file.



The error messages you're encountering are related to the linker script and the relocation of the ".idata" section. The linker script defines how the sections of the code should be placed in memory, and it seems that the linker script is missing a definition for the ".idata" section.

To resolve this issue, you can try the following steps:

1. Verify that you're using the correct linker script for your specific microcontroller. The linker script should match the microcontroller you're targeting. In your case, the linker script is for the PIC18F452. If you're using a different microcontroller, you should find the corresponding linker script in the "C:~sdk\gputils\lkr" directory and specify it during the compilation process using the -Wl,-m<path/to/linker script.lkr> option. For example:

```
bash

Copy code

sdcc main.c -mpic16 -p18f452 -Wl,-mC:/~sdk/gputils/lkr/your_linker_script.lkr
```

Replace "your_linker_script.lkr" with the appropriate linker script for your microcontroller.

2. If you're using the correct linker script and still encountering the issue, you may need to modify the linker script to include a definition for the ".idata" section. Open the linker script file (e.g., "18f452_g.lkr") in a text editor and add the following lines:

```
Copy code

SECTION NAME=.idata ROM
```

This defines a new section called ".idata" that will be placed in the ROM.

3. Save the linker script and recompile your project using SDCC with the modified linker script.

By following these steps, you should be able to resolve the linker script error and compile your project successfully.





what can you tell about MIT license? what best licensing use for VMEX to allow free personal usage and also allow to protect commercial usage at least by paid subscription support?



The MIT License is a permissive open-source software license that allows for free use, modification, and distribution of the software, even for commercial purposes. It is one of the most popular licenses due to its simplicity and permissiveness. However, it does not prevent others from using the software for commercial purposes without a subscription or support.

If you want to allow free personal usage of your VMEX software while requiring a paid subscription for commercial usage, you may consider adopting a dual licensing model. With this model, you would offer two different licenses for your software:

- 1. A free and permissive license (such as the MIT License) for personal use, education, or open-source projects. This would allow users to freely use, modify, and distribute the software for non-commercial purposes.
- 2. A separate commercial license that requires payment or a subscription for commercial use. This license would grant commercial users the right to use the software under specific terms and conditions.

By adopting a dual licensing model, you can protect your commercial interests while still allowing free usage for personal or open-source projects. It's essential to clearly specify the terms and conditions for each license and communicate the differences between the licenses to potential users.

It's worth noting that creating and managing licenses, especially for commercial use, can be a complex task. You may want to consult a legal expert to ensure that your licenses meet your requirements and are legally enforceable.

In summary, if you want to allow free personal usage and protect commercial usage with a paid subscription, you should consider using a dual licensing model that combines a permissive open-source license (e.g., MIT License) with a commercial license tailored to your specific needs.







BTW, both sdcc and z88dk used successfully by your support :-) thanks

You're welcome! I'm glad to hear that both SDCC and z88dk have been successfully used with the help of my support. If you have any more questions or need further assistance, please don't hesitate to ask. I'm here to help. Good luck with your project!







how is rv32e pseudoinstruction li composed?



In the RISC-V instruction set, the **1i** (load immediate) pseudoinstruction is used to load a small immediate value into a register. For the RV32E (RISC-V 32-bit Embedded) variant, the **1i** pseudoinstruction is also used for the same purpose. The **1i** pseudoinstruction is not a real machine instruction, but it's translated into one or more actual RISC-V instructions by the assembler.

For the RV32E variant, the **1i** pseudoinstruction can be assembled into different combinations of instructions depending on the immediate value being loaded. Here are the possible cases:

1. For small immediates that can be represented in 12 bits, the **1i** pseudoinstruction can be translated into a single **addi** (add immediate) instruction:

```
Copy code
li rd, imm -> addi rd, x0, imm
```

Here, rd is the destination register, and imm is the immediate value to be loaded.

2. For larger immediate values that cannot be represented in 12 bits, the assembler generates a sequence of instructions to load the immediate value into the register. This may include instructions such as **1ui** (load upper immediate) and **addi** (add immediate). For example:

In this case, the **1ui** instruction loads the upper 20 bits of the immediate value into the destination register, and the **addi** instruction adds the lower 12 bits of the immediate value to the destination register.

Keep in mind that the assembler may optimize the sequence of instructions based on the specific immediate value being loaded.



is good idea to publish my new virtual processor ISA based on RISC-V under MIT license?



Choosing to publish your new virtual processor ISA based on RISC-V under the MIT License can be a good idea, depending on your goals and preferences. The MIT License is a permissive open-source software license that allows for free use, modification, and distribution of the software, even for commercial purposes. This can encourage collaboration, contributions, and adoption by the broader community.

Some advantages of using the MIT License for your ISA are:

- 1. Simplicity: The MIT License is easy to understand and apply, which can make it more appealing to potential users and contributors.
- 2. Permissiveness: The MIT License allows users to freely use, modify, and distribute the software, which can encourage adoption and collaboration.
- 3. Compatibility: The MIT License is compatible with many other open-source licenses, making it easy for your ISA to be used with other open-source projects.

However, it's essential to understand that using the MIT License means that you're giving up some control over your project. Others can use, modify, and distribute your ISA, even for commercial purposes, without any obligation to pay you or share their changes with you. If you're comfortable with this level of openness and want to encourage collaboration, the MIT License can be a good choice.

Before making a decision, consider your goals and preferences for your project. If you prefer to have more control over the usage of your ISA, particularly for commercial purposes, you might want to explore other licensing options or even consider a dual licensing model, as discussed in a previous response.

Ultimately, the decision to use the MIT License or another license depends on your project goals, your preferences for control and openness, and your willingness to allow others to use, modify, and distribute your work.



well, I am now considering for VMEX to support full 16bit immediates in instructions as it fits to natural binary encoding; the RV32 supports only 12bit direct immediates without LUI/AUIPC and has even shifted by SRR 1 the branch immediate. By using 16bit immediates, I will support better the 8bit and 16bit MCUs having omited also the compressed instructions, as for example LI and branches will allow single 32bit instruction oveer entire 16bit data and address space, but code compiled to RV32 will needs to be transformed at relocatable level to generate less instructions with updated smybols table, how difficult this would be?



Creating a custom ISA based on RISC-V that supports full 16-bit immediates in instructions can potentially lead to more efficient code for 8-bit and 16-bit microcontrollers, as you mentioned. This could simplify the encoding of certain instructions and improve the overall performance on such platforms.

However, transforming code compiled for RV32 to your custom ISA with 16-bit immediates will require a few steps:

- 1. **Disassembly**: Disassemble the compiled RV32 binary to obtain the assembly code. This will allow you to analyze the instructions and modify them as needed.
- 2. Analysis and transformation: Analyze the RV32 assembly code and replace the instructions that use 12-bit immediates with your custom ISA instructions that use 16-bit immediates. This process will likely involve mapping the original RV32 instructions to their equivalents in your custom ISA, updating the immediate values, and possibly modifying the register usage, depending on the specifics of your ISA.
- 3. **Symbol table update**: When you modify the assembly code, you'll need to update the symbol table accordingly to reflect the changes in the instructions and addresses.

- 4. **Assembly**: Assemble the transformed assembly code into binary code compatible with your custom ISA.
- 5. **Testing and validation**: Thoroughly test the transformed binary code to ensure that it behaves as expected and produces the correct results.

The difficulty of this process will depend on the specifics of your custom ISA, how different it is from RV32, and the complexity of the code being transformed. It might be a challenging task, especially if you need to perform these transformations for a wide range of programs.

An alternative approach could be to develop a compiler or a compiler backend that directly targets your custom ISA. This way, you can generate code optimized for your ISA from the source code instead of transforming RV32 binaries. This can be a more efficient approach and can help you avoid the complexities associated with transforming binaries and updating symbol tables.

Regardless of the approach you choose, ensure that you have a solid understanding of the RISC-V architecture and your custom ISA, as well as a good grasp of compiler and assembler internals. This knowledge will be essential in implementing the required transformations and generating efficient code for your custom ISA.







well how complex can be to update code generation in C/C++ compiler (Ilvm?) to support 16bit instead 12bit immediates for risc-v? simply, how complex would be to modify code generation for VMEX having 16bit immediates and different binary ISA encoding? VMEX and RV32 will be compatible at assembler level using pseudoinstructions



Modifying the code generation in a C/C++ compiler, such as LLVM, to support a custom ISA like VMEX with 16-bit immediates instead of the standard 12-bit immediates in RISC-V is a non-trivial task but achievable with a solid understanding of compiler internals and the target architecture.

Here are the general steps you would need to take to modify LLVM to support your custom ISA:

- 1. **Understand LLVM internals**: Familiarize yourself with the LLVM architecture, including the front-end, middle-end (optimization passes), and back-end (code generation). This will help you understand where and how to make the necessary changes.
- 2. Create a new target or modify an existing one: If VMEX and RV32 are similar enough, you may consider modifying the existing RISC-V target in LLVM to support your custom ISA. Alternatively, you can create a new target for VMEX. In either case, you'll need to define the architecture specifics, such as register files, instruction set, and calling conventions.
- 3. **Update instruction encoding**: Modify the instruction encoding to accommodate the 16-bit immediates in your custom ISA. This may involve updating the existing instruction encodings or creating new ones for VMEX-specific instructions.
- 4. **Modify code generation**: Update the code generation logic in LLVM to generate instructions that use 16-bit immediates when appropriate. This might include changes to the instruction selection process, instruction scheduling, and register allocation.
- 5. **Implement and test**: Implement the changes, and thoroughly test the modified LLVM to ensure that it generates correct and efficient code for your custom ISA.
- 6. **Support for C/C++ standard libraries**: You might also need to provide support for C/C++ standard libraries, depending on how different VMEX is from RV32.

Keep in mind that modifying a compiler like LLVM to support a custom ISA is a complex and time-consuming task, and it requires a deep understanding of both the compiler internals and the target architecture. The process might also involve multiple iterations to achieve the desired level of performance and compatibility.

If you decide to go down this route, be prepared to invest a significant amount of time and effort into understanding, implementing, and testing the required changes. Additionally, consider engaging with the LLVM and RISC-V communities for guidance and support, as they can be invaluable resources during this process.







its really challenging decision ... as I dont support compressed instructions, having limited immediate values to unsigned 4096 and signed +- 2048 means that anything larger needs to compose another 32bit instruction for upper immediate ... one thing is that I can make VMEX runtime allowing to use 16bit but fully compatible with 12bit only... what I need to be carefull for?

If you decide to make VMEX runtime capable of handling 16-bit immediates while remaining fully compatible with the 12-bit immediates in RISC-V, there are several things you need to be careful about:

- 1. **Instruction encoding**: Make sure the instruction encoding for your 16-bit immediate version doesn't conflict with the standard RISC-V encoding, including the compressed instruction set. This will help maintain compatibility at the binary level.
- 2. **Assembler support**: Ensure that the assembler can correctly handle both 12-bit and 16-bit immediates, generating the appropriate instructions for each. This might involve modifying the assembler to recognize and handle the new instructions and encoding.
- 3. **Backward compatibility**: Keep backward compatibility with existing RISC-V code, so that code compiled for the standard RISC-V ISA still runs correctly on VMEX runtime.
- 4. **Compiler support**: If you plan to use an existing compiler like LLVM or GCC, you'll need to ensure that it can generate code that takes advantage of the 16-bit immediates when appropriate, while still maintaining compatibility with the standard RISC-V ISA.
- 5. **Performance**: Analyze the performance implications of using 16-bit immediates compared to the standard 12-bit immediates. Consider if the added complexity and potentially larger instruction size are worth the performance benefits.
- 6. **Documentation**: Clearly document the differences between VMEX and the standard RISC-V ISA, including any additional instructions, encoding changes, and the handling of 16-bit immediates. This will help users and developers understand the capabilities and limitations of your custom ISA.
- 7. **Testing**: Thoroughly test the compatibility between VMEX and the standard RISC-V ISA, including the handling of 12-bit and 16-bit immediates, instruction encoding, and performance. Ensure that both VMEX-specific and standard RISC-V code runs correctly on the VMEX runtime.
- 8. **Community engagement**: Engage with the RISC-V community to gather feedback on your custom ISA and its compatibility with the standard RISC-V ISA. This can help identify potential issues and improvements, as well as facilitate adoption of your custom ISA by the community.

By paying attention to these aspects and carefully implementing the required changes, you can create a custom ISA that takes advantage of the 16-bit immediates while maintaining

compatibility with the standard RISC-V ISA. This will help you leverage the benefits of the larger immediates while minimizing the impact on compatibility and performance.



well, may be I can implement switchable support for 16bit or 12bit in runtime ...



Implementing switchable support for 16-bit and 12-bit immediates at runtime can be an interesting approach, as it allows you to maintain compatibility with the standard RISC-V ISA while providing the option to take advantage of the larger immediates when desired.

Here are some considerations for implementing such a feature:

- Switching mechanism: Design a mechanism for switching between 12-bit and 16-bit immediate support at runtime. This could involve a special instruction, a control register, or some other method to enable or disable the 16-bit immediate support.
- Instruction encoding: Ensure that the instruction encoding for both 12-bit and 16-bit immediates is compatible and doesn't conflict. You may need to reserve certain bits or encoding space for the 16-bit immediate instructions.
- 3. **Assembler and compiler support**: Modify the assembler and compiler to support the generation of code that uses either 12-bit or 16-bit immediates, depending on the selected mode.
- 4. **Runtime handling**: Update the runtime to correctly handle and execute instructions based on the currently selected mode (12-bit or 16-bit immediates).
- 5. **Testing**: Thoroughly test the switchable support for 12-bit and 16-bit immediates to ensure that both modes work correctly and can be switched between seamlessly at runtime.
- 6. **Documentation**: Clearly document the switchable support for 12-bit and 16-bit immediates, including how to enable or disable it, any limitations, and the impact on performance and compatibility.

Keep in mind that implementing switchable support for different immediate sizes may add complexity to your runtime, assembler, and compiler. You'll need to carefully consider the trade-offs between flexibility and complexity to ensure that the benefits outweigh the additional implementation effort and potential performance impact.

Additionally, testing and validation will be crucial to ensure that the switchable support works as expected and doesn't introduce any issues or incompatibilities. Make sure to thoroughly test all aspects of your custom ISA, including the handling of 12-bit and 16-bit immediates, instruction encoding, and the switching mechanism.







well, so I deeply support the 16bit immediates now, it will be better to learning RISC-V assembly and using it on smaller MCUs directly using (pseudo)assembly of VMEX/ASLIX ... then, if it will be interesting, somebody can modify code generation from RV32 to VMEX too



That sounds like a good plan. By deeply supporting the 16-bit immediates in your VMEX/ASLIX custom ISA, you can provide a more convenient and efficient solution for smaller microcontrollers that can benefit from larger immediates. Focusing on the (pseudo)assembly level will allow developers to write and optimize code for your custom ISA, leveraging its unique features.

As you work on your custom ISA, consider the following steps:

- Design and document the ISA: Clearly define the instruction set, register file, instruction encoding, and any other architecture-specific details. Provide thorough documentation to help developers understand and utilize your custom ISA effectively.
- 2. **Develop an assembler**: Create an assembler that can convert (pseudo)assembly code written for your custom ISA into binary code compatible with your target microcontrollers.
- 3. **Create a simulator or emulator**: Develop a simulator or emulator that allows developers to test and debug code written for your custom ISA without the need for physical hardware. This can be a valuable tool for developers working with your ISA.
- 4. **Develop example code and tutorials**: Write example code and tutorials to help developers learn how to use your custom ISA effectively. This can include code snippets, explanations of key concepts, and step-by-step guides for common tasks.
- 5. **Engage with the community**: Share your custom ISA with the RISC-V and embedded systems communities to gather feedback, answer questions, and facilitate adoption. This can help you refine your ISA and identify potential improvements.

6. **Consider future compiler support**: While it's not an immediate priority, keep in mind that modifying a compiler like LLVM or GCC to generate code for your custom ISA could be a valuable addition in the future. This will allow developers to write code in higher-level languages like C and C++ and take advantage of the features of your custom ISA.

By focusing on these steps, you can create a custom ISA that provides a more efficient and convenient solution for smaller microcontrollers while maintaining compatibility with RISC-V assembly. This approach can help you build a solid foundation for your custom ISA and encourage adoption by developers and the broader RISC-V community.



yes, okay, thanks, main purpose of VMEX is to familiarize and encourage people of RV32 pseudo assembly usage for small MCUs and learning the RISC-V ... so it will be okay



That's a great goal! Familiarizing and encouraging people to learn and use RISC-V pseudo assembly for small microcontrollers can help promote the adoption of the RISC-V ecosystem and improve understanding of RISC-V concepts. By designing your custom VMEX ISA with this goal in mind, you can create a valuable resource for learners and developers interested in RISC-V and embedded systems.

To maximize the impact of your project and help achieve your goal, consider the following suggestions:

- Create educational resources: Develop tutorials, guides, and other educational resources
 that teach RISC-V concepts and pseudo assembly using your VMEX ISA. These materials
 can help newcomers and experienced developers alike to better understand and work
 with RISC-V.
- 2. **Build a community**: Encourage collaboration and engagement among users and developers working with your VMEX ISA. Establish forums, mailing lists, or chat rooms where people can discuss ideas, ask questions, and share their experiences.
- 3. **Participate in events**: Attend and present at RISC-V and embedded systems events, such as workshops, conferences, and meetups. This can help you connect with others interested in your project and increase awareness of your custom ISA and its benefits.
- 4. **Collaborate with educational institutions**: Partner with universities, schools, or other educational institutions to incorporate your VMEX ISA and related resources into their

curricula. This can help expose more students to RISC-V concepts and encourage learning and adoption.

5. Open-source your project: Make your VMEX ISA, assembler, emulator, and other tools open-source to facilitate collaboration, contributions, and improvements from the community.

By focusing on these activities, you can help promote the use of RISC-V pseudo assembly for small microcontrollers and support learning and adoption of RISC-V concepts. Your VMEX ISA can serve as a valuable resource for the RISC-V and embedded systems communities, and contribute to the growth and success of the RISC-V ecosystem. Good luck with your project!







how exactly behaves lui instruction on riscv? it loads upper immediate value, but leaves lower 12bits in target register intact?



The LUI (Load Upper Immediate) instruction in RISC-V is used to load a 20-bit immediate value into the upper 20 bits of a 32-bit register while setting the lowest 12 bits to zero. The instruction does not leave the lower 12 bits of the target register intact; it clears them.

The format of the LUI instruction is lui rd, imm. It takes a 20-bit immediate value, which is sign-extended to 32 bits and then left-shifted by 12 bits. The resulting 32-bit value is then loaded into the destination register rd.

For example, if you execute the following LUI instruction:

Copy code

lui x1, 0xABCD

The register x1 will contain the value **0xABCD0000**, with the lowest 12 bits set to zero.







The HP-16C is a classic programmable calculator designed by Hewlett-Packard, specifically for computer programmers and engineers. It is known for its ability to work with various number systems, including binary, octal, decimal, and hexadecimal, and perform bitwise operations. It also offers features like register manipulation, which can be useful when working with assembly language and debugging low-level code.

Using the HP-16C or a similar calculator when debugging your VMEX custom ISA can be quite helpful. It allows you to quickly convert between different number systems, perform calculations, and manipulate bits, which can be invaluable when working with assembly code and understanding the behavior of your ISA. Additionally, it can be a convenient tool for verifying the correctness of your instructions and other aspects of your design.

So, while debugging VMEX, having the HP-16C or a modern calculator with similar capabilities can be a useful addition to your toolkit.







Now, loudly thinking, considering for ASLIX (the VMEX universal orthogonal assembler on based slightly modified/extended RISC-V syntax) the possibility to use more than 16 registers in some scenarios - immediate instructions will be possible only on those first 16 registers and as a whole, but register instructions may be in VMEX encoded also with specifier for individual parts of 32bit registers (so each byte, by 3,2,1,0, full word 3210 or B,A half words). Its proposed to allow some syntax for this as rN, rN:0, rN:1, rN:A, rN:B in ASLIX assembler to be used in context of small 8bit/16bit MCUs - it will not necessarily be implemented inside VMEX runtime, but space in instructions encodig is here. Flexibility of ASLIX is more important - to allow this, MCUs will mimic concept of partial ZEROPAGE from 6502 for entire register set (16*x4=64bytes mandatory everywhere), while native (index) registers of each MCU will be rather preserved for internal fastest VMEX runtime operation (in case VMEX will implement this mixworx extension), and there will be also possibility to address those native registers from ASLIX assembly by "E" specifier used in syntax. This way will be probably possible to make superset of most important features of all tiny MCUs in ASLIX.

Your idea of extending ASLIX to support more than 16 registers and allow specifying individual parts of 32-bit registers is interesting and could provide more flexibility when working with small 8-bit and 16-bit microcontrollers. By introducing a syntax like **rN**, **rN:0**, **rN:1**, **rN:A**, and **rN:B**, you can give developers more fine-grained control over register manipulation and better adapt your assembler to the specific needs of the target MCU.

Allowing access to native registers with an "E" specifier is also a valuable idea, as it enables developers to take advantage of the unique features and performance benefits of the underlying hardware.

However, when implementing these features, consider the following points:

- 1. **Complexity**: Extending the register set and allowing partial register access can increase the complexity of both the ASLIX assembler and VMEX runtime. Ensure that you manage this complexity and maintain a clean, modular design.
- 2. **Compatibility**: Introducing new syntax and features may affect compatibility with existing RISC-V syntax and tools. Strive to maintain compatibility where possible and provide clear documentation for any deviations.
- 3. **Performance**: Be mindful of the performance implications of these extensions, especially when designing the VMEX runtime. Using native registers for internal operation may provide performance benefits but could also introduce complexity and potential bottlenecks.
- 4. **Documentation**: Thoroughly document the new syntax, features, and any limitations or special considerations developers should be aware of when using ASLIX and VMEX with extended registers and partial register access.

By carefully considering these points and designing your extensions with flexibility and compatibility in mind, you can create a powerful, adaptable assembler and runtime that caters to the needs of developers working with small 8-bit and 16-bit microcontrollers. This can help make ASLIX and VMEX more appealing and useful in a broader range of applications and contribute to the success of your project.







The Intel 8080 microprocessor uses little-endian byte ordering. In a little-endian system, the least significant byte (LSB) of a multi-byte value is stored at the lowest memory address, and the most significant byte (MSB) is stored at the highest memory address.

For example, consider a 16-bit value **0xABCD**. In a little-endian system like the 8080, it would be stored in memory as follows:

```
Address Value ----- N ØxCD (LSB) N+1 ØxAB (MSB)
```

Keep in mind that endianness is a property of the memory system and not the processor itself. However, the 8080 microprocessor was designed to work with little-endian memory systems, and as such, it is commonly referred to as a little-endian processor.





what is more common in 8bit MCUs? little or big endian?



In the world of 8-bit microcontrollers, little-endian byte ordering is more common. Most popular 8-bit microcontrollers, such as the MOS Technology 6502, Intel 8051, and Atmel AVR series, use little-endian byte ordering. However, it's essential to note that endianness is more relevant for processors and systems that work with multi-byte data.

Since 8-bit microcontrollers mostly deal with single-byte data, the concept of endianness is less critical for these systems. However, when working with multi-byte values or interfacing with peripherals or other systems, endianness may become relevant.

In summary, little-endian byte ordering is more common among 8-bit microcontrollers, but the relevance of endianness is generally less significant for these systems compared to processors that work with larger data widths.







what 8bit MCUs are big endian?



While most 8-bit microcontrollers use little-endian byte ordering, there are some notable exceptions that employ big-endian byte ordering. The most prominent example is the Motorola 6800 series, which includes the Motorola 6800 and 6809 microprocessors. These microcontrollers store the most significant byte (MSB) at the lowest memory address and the least significant byte (LSB) at the highest memory address.

For example, consider a 16-bit value **0xABCD**. In a big-endian system like the Motorola 6800 series, it would be stored in memory as follows:

```
Address Value ----- N ØxAB (MSB) N+1 ØxCD (LSB)
```

Although the Motorola 6800 series is an example of big-endian 8-bit microcontrollers, it's worth noting that big-endian systems are less common in the 8-bit microcontroller world. Little-endian systems are more prevalent in this domain.





has motorla 6800 instruction to swap bytes in 16bit registers or memory?



The Motorola 6800 microprocessor does not have a dedicated instruction to swap bytes in its 16-bit registers or memory. However, you can achieve byte swapping using a combination of other instructions available in the instruction set.

For instance, if you want to swap the bytes of a 16-bit value stored in memory at addresses ADDR and ADDR+1, you can use the following assembly code:

```
Copy code

LDAA ADDR; Load the byte at ADDR into accumulator A LDAB ADDR+1; Load the byte at ADDR+1 into accumulator B STAA ADDR+1; Store the contents of accumulator A at ADDR+1 STAB ADDR; Store the contents of accumulator B at ADDR
```

This sequence of instructions loads the bytes at ADDR and ADDR+1 into the accumulators A and B, then swaps their positions in memory. Note that the Motorola 6800 uses two 8-bit accumulators (A and B) instead of a single 16-bit register for most of its operations.

If you want to swap bytes within the 16-bit index register (X), you can use the following assembly code:

Copy code arduino

LDAA X_HI; Load the high byte of the index register into accumulator A LDAB X_LO; Load the low byte of the index register into accumulator B STAA X_LO; Store the contents of accumulator A into the low byte of the index register STAB X HI; Store the contents of accumulator B into the high byte of the index register

Here, **X_HI** and **X_LO** represent memory locations where the high byte and low byte of the index register are stored, respectively. This code sequence swaps the bytes within the 16-bit index register using the 8-bit accumulators A and B.







what i smore common in 16bit MCUs little or big endian?



In the 16-bit microcontroller world, both little-endian and big-endian byte ordering can be found, with no clear dominance of one over the other. Some popular 16-bit microcontrollers and their endianness are listed below:

- 1. Little-endian: Intel 8086 and its successors in the x86 family, Texas Instruments MSP430, and Microchip PIC24 series use little-endian byte ordering.
- 2. **Big-endian**: Motorola 68000 series, which is a 16/32-bit hybrid, and some of the early SPARC processors (which are mainly 32-bit but have 16-bit versions as well) use bigendian byte ordering.

The choice between little-endian and big-endian byte ordering often depends on the specific application and the desired compatibility with other systems or components. Both endianess types have their own advantages and disadvantages, so there isn't a clear winner in the 16-bit microcontroller domain.

As a developer, it's essential to be aware of the endianness of the microcontroller you're working with, especially when dealing with multi-byte data or interfacing with other systems.



what is more common in 32bit MCUs?



In the 32-bit microcontroller world, little-endian byte ordering is more common. Some popular 32-bit microcontrollers and processors and their endianness are listed below:

- 1. **Little-endian**: ARM Cortex-M series (Cortex-M0, Cortex-M3, Cortex-M4, and Cortex-M7) which are widely used in various microcontroller families like STM32, NXP LPC, and Silicon Labs EFM32. ARM processors, in general, can operate in both little-endian and big-endian modes, but little-endian is the most common configuration. Additionally, the x86 family (which includes 32-bit processors) and MIPS architecture (found in PIC32 microcontrollers from Microchip) also use little-endian byte ordering.
- 2. **Big-endian**: Some PowerPC-based microcontrollers, like the NXP QorlQ series, and certain configurations of the ARM architecture are big-endian. However, these are less common compared to little-endian configurations.

In summary, little-endian byte ordering is more prevalent in the 32-bit microcontroller world, but it's important to be aware of the endianness of the specific microcontroller you're working with, especially when dealing with multi-byte data or interfacing with other systems.







only noting here, for individual bytes indexes, I will use 1,2,3,4 not 0,1.2.3:



Using indices 1, 2, 3, and 4 for individual bytes instead of 0, 1, 2, and 3 is a design choice you can make for your VMEX/ASLIX project. It's essential to ensure that the documentation and any related tools or libraries are consistent with this choice to avoid confusion for users.

Here's the updated list of opcode constants with the new indices:

```
Copy code
С
//OP RD-TYPE #define OPRDD_MV OcDD //pseudo #define OPRD1_MV1 OcD1 //pseudo
//aslix #define OPRD2_MV2 OcD2 //pseudo //aslix #define OPRD3_MV3 OcD3 //pseudo
//aslix #define OPRD4_MV4 0cD4 //pseudo //aslix
```

This choice will impact how the instructions are decoded and executed in the VMEX runtime, and how the ASLIX assembler generates opcodes based on the assembly input. Make sure to update the corresponding parts of your project to handle the new byte indices consistently.







I originall yordered in source code all instructions by James Zho cheatsheet; in fact, as I am now semantically reordering the instructions, will provide new VMEX cheatsheet based on James.



Reordering the instructions in your VMEX project and providing a new cheatsheet based on James Zho's original work is a good idea. It will help users understand and navigate your instruction set more easily. Make sure to give proper credit to James Zho for the original work and inspiration.

When creating the new cheatsheet, keep the following points in mind:

1. Organize the instructions in a logical and coherent manner, grouping similar instructions together.

- 2. Clearly explain the purpose and function of each instruction, including any relevant pseudoinstructions.
- 3. Provide examples and use cases for each instruction, if possible.
- 4. Include any specific details about your instruction set, such as register naming conventions, addressing modes, or operand sizes.
- 5. Ensure that the instruction encoding is clearly documented, including any relevant details about the opcode and operand formats.

Once you have your new VMEX cheatsheet, make sure to include it in your project documentation and any related resources, such as tutorials, blog posts, or articles. This will help users get started with your VMEX project and provide a valuable reference for experienced users.







is in C possible to differentiate logical and aritmetical shift by operators << >>?



In C, the shift operators << and >> represent left shift and right shift, respectively. However, the behavior of the right shift operator >> depends on the type of the operand being shifted:

- 1. If the operand is an unsigned integer, the right shift >> is a logical shift. In a logical shift, zeros are shifted into the leftmost bits, and the sign bit is not preserved.
- 2. If the operand is a signed integer, the right shift >> is an arithmetic shift. In an arithmetic shift, the sign bit (the leftmost bit) is replicated and shifted into the leftmost bits, preserving the sign of the value.

It is important to note that the behavior of right shifts on negative signed integers is implementation-defined in C. However, most modern compilers treat right shifts on signed integers as arithmetic shifts.

To ensure that you get the desired shift behavior, you can cast the operand to the appropriate type before applying the shift operator. For example:

```
int32_t a = -10; uint32_t b = (uint32_t)a; // Arithmetic right shift int32_t
arith_shift = a >> 1; // Logical right shift uint32_t logical_shift = b >> 1;
```

In this example, arith_shift will store the result of an arithmetic right shift, while logical_shift will store the result of a logical right shift.







can be here something optimized for code size?

```
//instruction execution
switch (opcode)
{
  //R-TYPE
  case OPR31_ADD:
     core.regs[rd] = (REGS_TYPE) core.regs[rs1] + (REGS_TYPE) core.regs[rs2];
     break:
  case OPR32_SUB:
     core.regs[rd] = (REGS_TYPE) core.regs[rs1] - (REGS_TYPE) core.regs[rs2];
     break;
  case OPR33_XOR:
     core.regs[rd] = core.regs[rs1] ^ core.regs[rs2];
     break;
  case OPR34_AND:
     core.regs[rd] = core.regs[rs1] & core.regs[rs2];
     break;
  case OPR35_OR:
     core.regs[rd] = core.regs[rs1] | core.regs[rs2];
     break;
  case OPR36_SLL:
     core.regs[rd] = core.regs[rs1] << (core.regs[rs2] & 0x1F);
     break;
  case OPR37_SRL:
```

```
core.regs[rd] = (REGU_TYPE) core.regs[rs1] >> (core.regs[rs2] & 0x1F);
  break;
case OPR38_SRA:
  core.regs[rd] = (REGS_TYPE) core.regs[rs1] >> (core.regs[rs2] & 0x1F);
  break;
case OPR3A_CLT: //SLT
  core.regs[rd] = (REGS_TYPE) core.regs[rs1] < (REGS_TYPE) core.regs[rs2];
  break;
case OPR3B_CLTU: //SLTU
  core.regs[rd] = (REGU_TYPE) core.regs[rs1] < (REGU_TYPE) core.regs[rs2];
  break;
//I-TYPE
case OPI11_ADDI:
  core.regs[rd] = (REGS_TYPE) core.regs[rs1] + (IMMS_TYPE) imm;
  break;
case OPI12_SUBI: //pseudo
  core.regs[rd] = (REGS_TYPE) core.regs[rs1] - (IMMS_TYPE) imm;
  break;
case OPI13_XORI:
  core.regs[rd] = core.regs[rs1] ^ ((IMMS_TYPE) imm & 0xFFFF);
  break;
case OPI14_ANDI:
  core.regs[rd] = core.regs[rs1] & ((IMMS_TYPE) imm & 0xFFFF);
  break;
case OPI15_ORI:
  core.regs[rd] = core.regs[rs1] | ((IMMS_TYPE) imm & 0xFFFF);
  break;
case OPI16_SLLI:
  core.regs[rd] = core.regs[rs1] << ((IMMS_TYPE) imm & 0x1F);
  break;
```

```
case OPI17_SRLI:
  core.regs[rd] = core.regs[rs1] >> ((IMMS_TYPE) imm & 0x1F);
  break;
case OPI18_SRAI:
  core.regs[rd] = (REGS_TYPE) core.regs[rs1] >> ((IMMS_TYPE) imm & 0x1F);
  break;
case OPI1A_CLTI: //SLTI
  core.regs[rd] = (REGS_TYPE) core.regs[rs1] < (IMMS_TYPE) imm;
  break;
case OPI1B_CLTIU: //SLTIU
  core.regs[rd] = (REGU_TYPE) core.regs[rs1] < (REGU_TYPE) imm;
  break;
case OPIA1_LB:
  core.regs[rd] = (TS8) core.data[core.regs[rs1] + imm];
  break;
//TEST
case OPIA2_LH:
  core.regs[rd] = (TS16) ((core.data[core.regs[rs1] + imm] << 0) |
                 (core.data[core.regs[rs1] + imm + 1] << 8));
  break;
//TEST
case OPIA4_LW:
  core.regs[rd] = (TS32) ((core.data[core.regs[rs1] + imm] << 0) |
                 (core.data[core.regs[rs1] + imm + 1] << 8) |
                 (core.data[core.regs[rs1] + imm + 2] << 16)
                 (core.data[core.regs[rs1] + imm + 3] << 24));
  break;
case OPIAB_LBU:
  core.regs[rd] = (TU8) core.data[core.regs[rs1] + imm] & 0xFF;
  break;
```

```
//TEST
case OPIAD_LHU:
  core.regs[rd] = (TU16) ((core.data[core.regs[rs1] + imm] << 0) |
                  (core.data[core.regs[rs1] + imm + 1] << 8)) & 0xFFFF;
  break;
//TEST
case OPI4F_JALR:
  core.regs[rd] = core.pc + 4;
  core.pc = (core.regs[rs1] + imm) & ~0x1;
  break;
//TEST
case OPI42_ECALL:
case OPI48_EBREAK:
  if (imm == 0) {
     // Execute the system call
     println("System call!");
     } else if (imm == 1) {
     // Execute the break instruction
     println("Breakpoint!");
     } else {
     println("Unknown instruction");
  }
  break;
case OPSF1_WB: //SB
  core.data[core.regs[rs2] + imm] = core.regs[rs1] & 0xFF;
  break;
//TEST
case OPSF2_WH: //SH
  core.data[core.regs[rs2] + imm] = core.regs[rs1] & 0xFF;
  core.data[core.regs[rs2] + imm + 1] = (core.regs[rs2] >> 8) & 0xFF;
```

```
break;
//TEST
case OPSF4_WW: //SW
  core.data[core.regs[rs2] + imm] = core.regs[rs1] & 0xFF;
  core.data[core.regs[rs2] + imm + 1] = (core.regs[rs1] >> 8) & 0xFF;
  core.data[core.regs[rs2] + imm + 2] = (core.regs[rs1] >> 16) & 0xFF;
  core.data[core.regs[rs2] + imm + 3] = (core.regs[rs1] >> 24) & 0xFF;
  break;
case OPSB1_BLT:
  if ((REGS_TYPE)
                      core.regs[rs1] < (REGS_TYPE) core.regs[rs2]) {
    core.pc += imm;
  }
  break;
case OPSB2_BLE:
   break;
case OPSB3_BNE:
  if (core.regs[rs1] != core.regs[rs2]) {
    core.pc += imm;
  }
  break;
case OPSB4_BEQ:
  if (core.regs[rs1] == core.regs[rs2]) {
    core.pc += imm;
  }
  break;
case OPSB5_BGE:
  if ((REGS_TYPE) core.regs[rs1] >= (REGS_TYPE) core.regs[rs2]) {
     core.pc += imm;
  }
  break;
case OPSB6_BGT:
```

```
break;
case OPSBA_BLTU:
  if ((REGU_TYPE) core.regs[rs1] < (REGU_TYPE) core.regs[rs2]) {
    core.pc += imm;
  }
  break;
case OPSBB_BLEU:
  break;
case OPSBC_BGEU:
  if ((REGU_TYPE) core.regs[rs1] >= (REGU_TYPE) core.regs[rs2]) {
    core.pc += imm;
  break;
case OPSBD_BGTU:
  break;
case OPU71_LUI:
  core.regs[rd] = (REGU_TYPE) (imm << IMM_BITS);
  break;
case OPU7A_AUIPC:
  core.regs[rd] = ((REGU_TYPE) (imm << IMM_BITS)) + core.pc;</pre>
  break;
case OPU7F_JAL:
  core.regs[rd] = core.pc + 4;
  core.pc += imm;
  break;
default:
  print("Unknown opcode: "); println(itoh(opcode));
  break;
```

```
r10i = core.regs[10];
r10u = core.regs[10];
r11i = core.regs[11];
r11u = core.regs[11];
core.pc+=4; // Increment the PC
```



print("PC: "); println(itoh(core.pc)); //TODO DEBUG
Your code is already quite compact, and there isn't much room for significant optimization
in terms of code size. However, you can make some minor adjustments to slightly reduce
the size of your code and improve readability:

- 1. Instead of using the & operation to mask the immediate values in some cases, you can directly use the IMMS_TYPE and REGU_TYPE types for casting. This change will not reduce the size of the code, but it will improve consistency and readability.
- 2. You can use a lookup table for the load and store instructions, which will reduce the number of lines of code.

Here's an updated version of your code with these changes:

```
Copy code

// ... (the rest of your code) // Lookup tables for load and store instructions

const int load_shifts[] = {0, 8, 16, 24}; const int store_shifts[] = {0, 8, 16,

24}; //instruction execution switch (opcode) { // ... (the rest of your code)

case OPIA2_LH: case OPIAD_LHU: { uint16_t value = 0; for (int i = 0; i < 2; i++)

{ value |= core.data[core.regs[rs1] + imm + i] << load_shifts[i]; }

core.regs[rd] = opcode == OPIA2_LH ? (TS16) value : (TU16) value; } break; case

OPIA4_LW: { uint32_t value = 0; for (int i = 0; i < 4; i++) { value |=

core.data[core.regs[rs1] + imm + i] << load_shifts[i]; } core.regs[rd] = (TS32)

value; } break; // ... (the rest of your code) case OPSF2_WH: //SH case

OPSF4_WW: //SW { int num_bytes = opcode == OPSF2_WH ? 2 : 4; for (int i = 0; i <

num_bytes; i++) { core.data[core.regs[rs2] + imm + i] = (core.regs[rs1] >>

store_shifts[i]) & 0xFF; } break; // ... (the rest of your code) } // ... (the

rest of your code)
```

These modifications slightly reduce the size of your code and improve its readability. However, the overall impact on the code size is relatively small.

can be in this code something optmized for speed?

Optimizing for speed is often a trade-off with code size and readability. Here are some suggestions that may help improve the execution speed of your code:

- 1. Use a function pointer table (also called a jump table) for instruction dispatch. This can potentially speed up the dispatch process by eliminating the need for a large switch statement.
- 2. Unroll the loops used for loading and storing values. This may lead to faster execution due to the elimination of loop overhead.

Here is an example of these optimizations applied to your code:

```
Copy code
С
// Define a function type for instruction handlers typedef void
(*instruction_handler)(void); // Forward declare instruction handlers void
handle_opr31_add(void); // ... (forward declarations for other handlers) //
Create a function pointer table for instruction dispatch instruction handler
instruction_handlers[] = { [OPR31_ADD] = handle_opr31_add, // ... (other opcode
and handler pairs) }; // Define the instruction handlers void
handle_opr31_add(void) { core.regs[rd] = (REGS_TYPE)core.regs[rs1] +
(REGS_TYPE)core.regs[rs2]; } // ... (other instruction handler definitions)
//instruction execution instruction_handler handler =
instruction handlers[opcode]; if (handler != NULL) { handler(); } else {
print("Unknown opcode: "); println(itoh(opcode)); } // Unroll the load and store
loops case OPIA2_LH: case OPIAD_LHU: { uint16_t value =
(core.data[core.regs[rs1] + imm] << 0) | (core.data[core.regs[rs1] + imm + 1] <</pre>
8); core.regs[rd] = opcode == OPIA2_LH ? (TS16)value : (TU16)value; } break;
case OPIA4_LW: { uint32_t value = (core.data[core.regs[rs1] + imm] << 0) |</pre>
(core.data[core.regs[rs1] + imm + 1] << 8) | (core.data[core.regs[rs1] + imm + 1] << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.regs[rs1] + imm + 1] | << 8) | (core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.data[core.dat
2] << 16) | (core.data[core.regs[rs1] + imm + 3] << 24); core.regs[rd] =
(TS32)value; } break; // ... (the rest of your code) case OPSF2_WH: //SH {
core.data[core.regs[rs2] + imm] = core.regs[rs1] & 0xFF;
core.data[core.regs[rs2] + imm + 1] = (core.regs[rs1] >> 8) & 0xFF; } break;
case OPSF4_WW: //SW { core.data[core.regs[rs2] + imm] = core.regs[rs1] & 0xFF;
core.data[core.regs[rs2] + imm + 1] = (core.regs[rs1] >> 8) & 0xFF;
core.data[core.regs[rs2] + imm + 2] = (core.regs[rs1] \Rightarrow 16) & 0xFF;
```

```
core.data[core.regs[rs2] + imm + 3] = (core.regs[rs1] >> 24) & 0xFF; } break; //
... (the rest of your code)
```

Keep in mind that these optimizations can increase code size and may reduce readability. It's also





please continue



important to note that the actual performance improvement depends on various factors, such as the target platform, compiler optimizations, and the specific code being executed. Be sure to profile and test the performance of your code after making these changes to ensure that they have the desired effect.

Additional suggestions for optimizing speed include:

- 3. Use inline functions for small and frequently called functions. This can help reduce the overhead of function calls.
- 4. Optimize memory access patterns. Ensure that data structures are cache-friendly and that memory is accessed in a linear manner whenever possible.
- 5. Profile your code to identify performance bottlenecks and focus optimization efforts on the most time-consuming parts of the code.
- 6. Consider using compiler optimization flags and profile-guided optimization to further improve the performance of the generated binary.
- 7. If possible, take advantage of hardware-specific features or instruction sets to optimize the performance of your code for a particular platform.

Remember that optimization is often a trade-off between code size, readability, and performance. It's essential to strike a balance between these factors and to optimize only when necessary. Be sure to test and profile your code thoroughly to ensure that your optimizations have the desired effect and do not introduce any bugs or unintended side effects.







well, how much of code space can be saved by coding this thing in pure assembly for 8bit, 16bit, 32bit MCUs?



It is difficult to give a precise estimate of the code space savings when converting the code from C to pure assembly for 8-bit, 16-bit, and 32-bit microcontrollers without knowing the specific microcontrollers, compilers, and optimizations being used. However, generally speaking, coding in assembly can lead to significant code size reductions due to the low-level control and optimization opportunities it offers.

The code space savings also depend on the programmer's experience and familiarity with the target MCU's instruction set and hardware. A skilled assembly programmer can hand-tune the code to take advantage of the specific features and characteristics of the MCU, leading to more compact and efficient code.

For 8-bit and 16-bit MCUs, the code space savings can be more pronounced due to their limited resources and simpler instruction sets. It is not uncommon to see code size reductions of 30-50% or more when compared to the equivalent C code compiled with standard optimization flags.

For 32-bit MCUs, the potential code size savings may be less significant due to the more complex instruction sets and the fact that modern C compilers are quite effective at optimizing code for these platforms. However, you can still expect some reduction in code size, potentially around 10-30%, depending on the specific use case and optimization techniques used.

Keep in mind that coding in assembly can be more time-consuming and harder to maintain, so you should carefully weigh the potential code space savings against the increased development and maintenance effort.







how to optimize this using pointers?

Using pointers, you can optimize the code by reducing the number of array indexing operations and directly accessing memory locations. Here's the optimized code using pointers:

```
Copy code

//TEST case OPIA2_LH: { uint8_t *mem_ptr = &core.data[core.regs[rs1] + imm];

core.regs[rd] = (TS16) (mem_ptr[0] | (mem_ptr[1] << 8)); break; } //TEST case

OPIA4_LW: { uint8_t *mem_ptr = &core.data[core.regs[rs1] + imm]; core.regs[rd] =

(TS32) (mem_ptr[0] | (mem_ptr[1] << 8) | (mem_ptr[2] << 16) | (mem_ptr[3] <<
24)); break; }
```

In this optimized version, a pointer mem_ptr is created to point to the base address of the data to be loaded. Then, using the pointer, the code directly accesses the memory locations instead of performing multiple array indexing operations. This should result in more efficient code, as it reduces the number of calculations needed to access the memory locations.





how to omit also | and << operators to access memory halfword and word directly here?



To access memory halfword and word directly without using | and << operators, you can use type casting with pointers. Here's the optimized code:

```
c
//TEST case OPIA2_LH: { uint8_t *mem_ptr = &core.data[core.regs[rs1] + imm];
core.regs[rd] = *(TS16 *)mem_ptr; break; } //TEST case OPIA4_LW: { uint8_t
*mem_ptr = &core.data[core.regs[rs1] + imm]; core.regs[rd] = *(TS32 *)mem_ptr;
break; }
```

In this version, a pointer mem_ptr is created to point to the base address of the data to be loaded. Then, using type casting, the code directly accesses the memory halfword and word

without the need for bitwise operations.

However, please note that this approach assumes that the memory is correctly aligned for halfword and word access. If the memory is not aligned, it may result in undefined behavior or incorrect results, depending on the target hardware. To ensure correct operation, you may need to add checks for memory alignment or handle unaligned accesses manually.



how to optimize similary way also this? ill be advantage using pointer even for accessing single byte?



For the **OPIAB_LBU** case, using a pointer could make the code more concise, but it might not necessarily result in a performance improvement, as accessing a single byte is already a simple operation. However, using a pointer can make the code more consistent with the other cases.

For the **OPIAD_LHU** case, using a pointer with type casting can help simplify the code and potentially improve performance. Here's the optimized code for both cases:

```
c case OPIAB_LBU: { uint8_t *mem_ptr = &core.data[core.regs[rs1] + imm];
core.regs[rd] = *(TU8 *)mem_ptr; break; } //TEST case OPIAD_LHU: { uint8_t
*mem_ptr = &core.data[core.regs[rs1] + imm]; core.regs[rd] = *(TU16 *)mem_ptr;
break; }
```

Again, it's important to note that this approach assumes that the memory is correctly aligned for halfword access. If the memory is not aligned, it may result in undefined behavior or incorrect results, depending on the target hardware. To ensure correct operation, you may need to add checks for memory alignment or handle unaligned accesses manually.







how to optimize using poiners also this?

```
case OPSF1_WB: //SB
  core.data[core.regs[rs2] + imm] = core.regs[rs1] & 0xFF;
  break;
//TEST
case OPSF2_WH: //SH
  core.data[core.regs[rs2] + imm] = core.regs[rs1] & 0xFF;
  core.data[core.regs[rs2] + imm + 1] = (core.regs[rs2] >> 8) & 0xFF;
  break;
//TEST
case OPSF4_WW: //SW
  core.data[core.regs[rs2] + imm] = core.regs[rs1] & 0xFF;
  core.data[core.regs[rs2] + imm + 1] = (core.regs[rs1] >> 8) & 0xFF;
  core.data[core.regs[rs2] + imm + 2] = (core.regs[rs1] >> 16) & 0xFF;
  core.data[core.regs[rs2] + imm + 3] = (core.regs[rs1] >> 24) & 0xFF;
  break;
```

You can use pointers to optimize the code for these cases as well. Here's the optimized code using pointers:

```
Copy code
C
case OPSF1_WB: //SB { uint8_t *mem_ptr = &core.data[core.regs[rs2] + imm]; *
(uint8_t *)mem_ptr = (uint8_t)(core.regs[rs1] & 0xFF); break; } //TEST case
OPSF2_WH: //SH { uint8_t *mem_ptr = &core.data[core.regs[rs2] + imm]; *(uint16_t
*)mem_ptr = (uint16_t)(core.regs[rs1] & 0xFFFF); break; } //TEST case OPSF4_WW:
```

```
//SW { uint8_t *mem_ptr = &core.data[core.regs[rs2] + imm]; *(uint32_t *)mem_ptr
= core.regs[rs1]; break; }
```

Keep in mind that this approach assumes the memory is correctly aligned for halfword and word access. If the memory is not aligned, it may result in undefined behavior or incorrect results, depending on the target hardware. To ensure correct operation, you may need to add checks for memory alignment or handle unaligned accesses manually.



how to optimize this using pointers?

```
case IE_TYPE:
    rd = core.prog[core.pc + 1] >> 4;
    rs1 = core.prog[core.pc + 1] & 0xF;
    imm = core.prog[core.pc + 2] | (core.prog[core.pc + 3] << 8); //TODO consider
12bit (RISC-V) or 16bit immediates !!!
    break;</pre>
```



To optimize this code using pointers, you can use a pointer to access the **core.prog** array elements more efficiently. Here's the optimized code using pointers:

This optimization replaces the multiple indexed array accesses with a single pointer, which may improve performance. Note that the performance improvement might not be significant, as modern compilers often optimize array access automatically.





how to omit | and << using pointer?



To omit the | and << operators, you can use a pointer cast to access the 16-bit immediate value directly. Here's the optimized code using pointers:

This optimization uses a pointer cast to **uint16_t** * to access the 16-bit immediate value in a single operation. Note that this assumes the data is stored in little-endian format. If the data is stored in big-endian format, you may need to use a function like **ntohs()** to convert the byte order correctly. Also, keep in mind that this code may not be portable across different systems due to differences in endianness and alignment requirements.







optimize please also this code:

```
case S8_TYPE:
    rs1 = core.prog[core.pc + 1] >> 4;
    rs2 = core.prog[core.pc + 1] & 0xF;
    imm = core.prog[core.pc + 2] | (core.prog[core.pc + 3] << 8); //TODO RISC-V
compatible shift !!!
    break;</pre>
```



To optimize this code snippet using pointers, you can follow a similar approach as in the previous example:

This optimization uses a pointer cast to <code>uint16_t *</code> to access the 16-bit immediate value in a single operation. Remember that this assumes the data is stored in little-endian format. If the data is stored in big-endian format, you may need to use a function like <code>ntohs()</code> to convert the byte order correctly. Also, keep in mind that this code may not be portable across different systems due to differences in endianness and alignment requirements.





optimize also this code:

```
case U6_TYPE:
    rd = core.prog[core.pc + 1] >> 4;
    imm = core.prog[core.pc + 2] | (core.prog[core.pc + 3] << 8); //TODO consider
12bit (RISC-V) or 16bit immediates !!!
    break;</pre>
```



To optimize this code snippet using pointers, you can follow a similar approach as in the previous examples:

This optimization uses a pointer cast to **uint16_t** * to access the 16-bit immediate value in a single operation. Remember that this assumes the data is stored in little-endian format. If the data is stored in big-endian format, you may need to use a function like **ntohs()** to convert the byte order correctly. Also, keep in mind that this code may not be portable across different systems due to differences in endianness and alignment requirements.





may be optimized also this?

```
rd = core.prog[core.pc + 1] >> 4;
rs1 = core.prog[core.pc + 2] >> 4;
rs2 = core.prog[core.pc + 3] >> 4;
break;
```



Yes, you can optimize this code snippet using pointers like this:

This optimization uses a pointer to **uint8_t** to access the values in **core.prog** array directly. While it does not save much in terms of complexity, it makes the code more consistent with the other optimized examples provided.







how to activate microchip subscription license for XC8 compiler in microchip studio?



To activate a subscription license for the XC8 compiler in Microchip Studio, follow these steps:

- First, make sure you have a subscription license for the XC8 compiler. If you haven't purchased one yet, you can do so from the Microchip website
 (https://www.microchip.com/).
- 2. Once you have the license, open Microchip Studio.
- 3. Go to the "Tools" menu in the toolbar and select "Licenses".
- 4. In the "License Manager" window, click on "Activate License".
- 5. You will be prompted to enter your Microchip Direct account credentials (email and password). Enter the required information and click "Next".
- 6. The License Manager will show a list of available licenses associated with your account. Find the XC8 compiler license in the list and click on the "Activate" button next to it.

- 7. The activation process may take a few moments. Once it's completed, the license will be activated, and you should see the license status change to "Active" in the License Manager.
- 8. Close the License Manager, and you can now use the XC8 compiler with your subscription license.

Remember that you need an active internet connection to activate the license. If you face any issues during the activation process, you may want to contact Microchip's support team for further assistance.



can you try to rewrite this code snippet in AVRx assembly?

```
TU8 *ptr = &core.prog[core.pc];
//parameters parsing
switch (opcode & 0xF0)
{
  case R3_TYPE:
  case R2_TYPE:
  case RC_TYPE:
  case RD_TYPE:
  {
     rd = ptr[1] >> 4;
     rs1 = ptr[2] >> 4;
     rs2 = ptr[3] >> 4;
     break;
  }
  case I1_TYPE:
  case IA_TYPE:
  case I4_TYPE:
  case IE_TYPE:
  {
     rd = ptr[1] >> 4;
     rs1 = ptr[1] \& 0xF;
     imm = *((TU16 *) (ptr + 2)); // Read 16-bit immediate value directly
     break;
  }
```

```
case SF_TYPE:
  case SB_TYPE:
  case S8_TYPE:
  {
     rs1 = ptr[1] >> 4;
     rs2 = ptr[1] & 0xF;
     imm = *((TU16 *) (ptr + 2)); // Read 16-bit immediate value directly
     break;
  }
  case U7_TYPE:
  case U6_TYPE:
     rd = ptr[1] >> 4;
     imm = *((TU16 *) (ptr + 2)); // Read 16-bit immediate value directly
     break;
  }
  case UNKNOWN_TYPE:
     default:
     println("Unknown opcode type");
     break;
}
```

I have converted the given code snippet to AVR Assembly language for an 8-bit AVR microcontroller. Please note that I'm assuming you have some knowledge of AVR Assembly language and are familiar with the registers and instructions used in the code.

```
; Assumptions: ; - R16 to R19 are used as general-purpose registers ; - Z register (R30 and R31) is used for indirect addressing ; - core.pc is stored in R20 and R21 (16-bit value) ; - core.prog is stored in R22 and R23 (16-bit base address) ; Load core.prog + core.pc into the Z register add r30, r20 adc r31, r21 ; Load opcode from Z into R16 ld r16, Z ; Right shift R16 by 4 bits swap r16 andi r16, 0x0F ; Branch based on the value in R16 ; Note: You will need to adjust the branch offsets (k) accordingly brbs 0, R3_TYPE brbs 1, R2_TYPE ;
```

```
(continue for the other cases); R3_TYPE, R2_TYPE, RC_TYPE, RD_TYPE R3_TYPE:
R2_TYPE: RC_TYPE: RD_TYPE: ; Code for these cases rjmp EndOfSwitch ; I1_TYPE,
IA_TYPE, I4_TYPE, IE_TYPE I1_TYPE: IA_TYPE: I4_TYPE: IE_TYPE: ; Code for these
cases rjmp EndOfSwitch; (continue for the other cases) EndOfSwitch:; Continue
with the rest of your program
```

Please note that this is a rough conversion and might require adjustments based on the specific AVR microcontroller you are using and the context of the rest of your program. You will also need to write the assembly code for each case separately.







can you rewrite this to assembly?

```
case RD_TYPE:
  rd = ptr[1] >> 4;
  rs1 = ptr[2] >> 4;
  rs2 = ptr[3] >> 4;
  break;
}
```



Sure, here's the AVR assembly code for the given code snippet:

assembly Copy code

; Assumptions: ; - Z register (R30 and R31) is used for indirect addressing, pointing to ptr; - R16, R17, and R18 are used as general-purpose registers for rd, rs1, and rs2 respectively RD_TYPE: ; Load ptr[1] into R16 and right shift by 4 bits ld r16, Z+1 swap r16 andi r16, 0x0F; Load ptr[2] into R17 and right shift by 4 bits ld r17, Z+2 swap r17 andi r17, 0x0F; Load ptr[3] into R18 and right shift by 4 bits 1d r18, Z+3 swap r18 andi r18, 0x0F; Continue with the rest of your program (e.g., jump to the end of switch) rjmp EndOfSwitch

This code assumes that the Z register is already pointing to the base address (ptr) and uses R16, R17, and R18 as general-purpose registers for rd, rs1, and rs2 respectively. After the code snippet is executed, the values of rd, rs1, and rs2 will be stored in R16, R17, and R18.



can you try to rewrite in assembly also this?

```
case IE_TYPE:
{
    rd = ptr[1] >> 4;
    rs1 = ptr[1] & 0xF;
    imm = *((TU16 *) (ptr + 2)); // Read 16-bit immediate value directly break;
}
```



Sure, here's the AVR assembly code for the given code snippet:

```
assembly Copy code
```

; Assumptions: ; - Z register (R30 and R31) is used for indirect addressing, pointing to ptr; - R16, R17, and R18 are used as general-purpose registers for rd, rs1, and imm respectively IE_TYPE: ; Load ptr[1] into R16 and right shift by 4 bits ld r16, Z+1 swap r16 andi r16, 0x0F; Load ptr[1] into R17 and mask lower 4 bits ld r17, Z+1 andi r17, 0x0F; Load ptr[2] and ptr[3] as a 16-bit immediate value into R18:R19 ld r18, Z+2 ld r19, Z+3; Continue with the rest of your program (e.g., jump to the end of switch) rjmp EndOfSwitch

This code assumes that the Z register is already pointing to the base address (ptr) and uses R16, R17, and R18 as general-purpose registers for rd, rs1, and imm respectively. After the code snippet is executed, the values of rd, rs1, and imm will be stored in R16, R17, and R18:R19.





can you try to rewrite this in assembly?

```
case OPR31_ADD:
    core.regs[rd] = (REGS_TYPE) core.regs[rs1] + (REGS_TYPE) core.regs[rs2];
    break;
```

```
case OPR32_SUB:
    core.regs[rd] = (REGS_TYPE) core.regs[rs1] - (REGS_TYPE) core.regs[rs2];
    break;

case OPR33_XOR:
    core.regs[rd] = core.regs[rs1] ^ core.regs[rs2];
    break;

case OPR34_AND:
    core.regs[rd] = core.regs[rs1] & core.regs[rs2];
    break;

case OPR35_OR:
    core.regs[rd] = core.regs[rs1] | core.regs[rs2];
    break;
```

I can provide you with the AVR assembly code for each case individually, but please note that the actual implementation might differ depending on your register allocation,

Copy code

addressing mode, and other factors. Here's the assembly code for each case:

assembly

; Assumptions: ; - X register (R26 and R27) is used for indirect addressing, pointing to core.regs; - rd, rs1, and rs2 are already in R16, R17, and R18 respectively OPR31 ADD: ; Calculate the addresses of core.regs[rs1] and core.regs[rs2] add X, R17 ld R19, X sub X, R17 add X, R18 ld R20, X sub X, R18; Perform addition add R19, R20; Store the result in core.regs[rd] add X, R16 st X, R19 sub X, R16 rjmp EndOfSwitch OPR32_SUB: ; Calculate the addresses of core.regs[rs1] and core.regs[rs2] add X, R17 ld R19, X sub X, R17 add X, R18 ld R20, X sub X, R18; Perform subtraction sub R19, R20; Store the result in core.regs[rd] add X, R16 st X, R19 sub X, R16 rjmp EndOfSwitch OPR33_XOR: ; Calculate the addresses of core.regs[rs1] and core.regs[rs2] add X, R17 ld R19, X sub X, R17 add X, R18 ld R20, X sub X, R18 ; Perform XOR eor R19, R20 ; Store the result in core.regs[rd] add X, R16 st X, R19 sub X, R16 rjmp EndOfSwitch OPR34_AND: ; Calculate the addresses of core.regs[rs1] and core.regs[rs2] add X, R17 ld R19, X sub X, R17 add X, R18 ld R20, X sub X, R18; Perform AND and R19, R20; Store the result in core.regs[rd] add X, R16 st X, R19 sub X, R16 rjmp EndOfSwitch OPR35 OR: ; Calculate the addresses of core.regs[rs1] and core.regs[rs2] add X, R17 ld R19, X sub X, R17 add X, R18 ld R20, X sub X, R18; Perform OR or R19, R20; Store the result in core.regs[rd] add X, R16 st X, R19

sub X, R16 rjmp EndOfSwitch EndOfSwitch: ; Continue with the rest of your program

This assembly code assumes that X register (R26 and R27) is used for indirect addressing, pointing to the base address (core.regs), and rd, rs1, and rs2 are already in



well, okay, but the REGS_TYPE and default registers type is signed 32bit integer for calculations and bit manipulations



My apologies for the confusion. Here's the updated AVR assembly code for each case, considering signed 32-bit integers (assuming that the AVR is an 8-bit MCU). Note that the actual implementation might differ depending on your register allocation, addressing mode, and other factors.

assembly Copy code

; Assumptions: ; - X register (R26 and R27) is used for indirect addressing, pointing to core.regs; - rd, rs1, and rs2 are already in R16, R17, and R18 respectively; - R19-R22 are used as temporary registers OPR31 ADD:; Calculate the addresses of core.regs[rs1] and core.regs[rs2] add X, R17 ldd R19, X+ ldd R20, X+ 1dd R21, X+ 1dd R22, X sub X, R17 add X, R18 1dd R23, X+ 1dd R24, X+ 1dd R25, X+ ldd R26, X sub X, R18; Perform 32-bit addition add R19, R23 adc R20, R24 adc R21, R25 adc R22, R26; Store the result in core.regs[rd] add X, R16 std X+, R19 std X+, R20 std X+, R21 std X, R22 sub X, R16 rjmp EndOfSwitch OPR32_SUB: ; Calculate the addresses of core.regs[rs1] and core.regs[rs2] add X, R17 ldd R19, X+ ldd R20, X+ ldd R21, X+ ldd R22, X sub X, R17 add X, R18 ldd R23, X+ 1dd R24, X+ 1dd R25, X+ 1dd R26, X sub X, R18; Perform 32-bit subtraction sub R19, R23 sbc R20, R24 sbc R21, R25 sbc R22, R26; Store the result in core.regs[rd] add X, R16 std X+, R19 std X+, R20 std X+, R21 std X, R22 sub X, R16 rjmp EndOfSwitch OPR33_XOR: ; Calculate the addresses of core.regs[rs1] and core.regs[rs2] add X, R17 ldd R19, X+ ldd R20, X+ ldd R21, X+ ldd R22, X sub X, R17 add X, R18 ldd R23, X+ ldd R24, X+ ldd R25, X+ ldd R26, X sub X, R18; Perform 32-bit XOR eor R19, R23 eor R20, R24 eor R21, R25 eor R22, R26; Store the result in core.regs[rd] add X, R16 std X+, R19 std X+, R20 std X+, R









My apologies for the truncation. Here's the continuation of the assembly code:

assembly Copy code

std X+, R21 std X, R22 sub X, R16 rjmp EndOfSwitch OPR34_AND: ; Calculate the addresses of core.regs[rs1] and core.regs[rs2] add X, R17 ldd R19, X+ ldd R20, X+ ldd R21, X+ ldd R22, X sub X, R17 add X, R18 ldd R23, X+ ldd R24, X+ ldd R25, X+ ldd R26, X sub X, R18; Perform 32-bit AND and R19, R23 and R20, R24 and R21, R25 and R22, R26; Store the result in core.regs[rd] add X, R16 std X+, R19 std X+, R20 std X+, R21 std X, R22 sub X, R16 rjmp EndOfSwitch OPR35_OR: ; Calculate the addresses of core.regs[rs1

network error