

Export mesh in Attila format in Ansys ICEM

1. **Output Mesh**

2.     4.

3. **Solver Setup**

Output Solver: **Attila**

☐ Set As Default

Apply OK Dismiss

5. **Attila**

Please edit the following Attila options.

Set mesh file name

Domain file:	/home/kroll/FELICS/3D_case/full_cc/meshes/fine_TF.uns
Mesh output file:	/home/kroll/FELICS/3D_case/full_cc/meshes/.mesh.inp
Attila input deck:	/home/kroll/FELICS/3D_case/full_cc/meshes/.inp
Write attila input deck:	☒ Yes ☐ No
Title of Mesh:	ICEM_MESH
Version:	1.0.0
Cycle Number:	1
Problem Time:	0.0
Problem Time Units:	s
Coordinate Units:	cm
Scaling Factor:	1.0

Done Cancel