

PRIMAL RAGE (1994)

Atari Games — Complete Restoration Guide for Public Placements

Cabinet • Controls • Power • Monitor • Reliability

Prepared for **Coin Op 4 Charity** / Arcade Angels

Making Atari's dinosaur fighting classic reliable and inviting for youth and community spaces

1. Overview & Goals

Primal Rage (Atari Games, 1994) is a two-player fighting game featuring stop-motion digitized dinosaurs and apes. It was popular in the mid-1990s and remains a strong draw for all ages when running well. For public and youth-center placements the priorities are reliable controls, a stable picture, clean presentation, and simple ongoing care.

2. Safety

- Unplug the cabinet before any internal work.
- CRT monitors store high voltage — discharge the anode before working on the chassis or neckboard.
- Original power supplies involve AC voltages; treat every connection with care.
- If CRT work is outside your comfort zone, an LCD conversion is a practical option for high-use public sites.

3. Cabinet Exterior & Cosmetics

- Clean the entire cabinet thoroughly. Remove sticky residue, dust, and years of hand prints.
- Inspect side art, front decals, bezel, and control-panel overlay. Replace or carefully restore heavily damaged graphics so the machine looks cared for.
- Marquee: clean the plastic and replace the fluorescent tube or lighting if dim. A bright marquee makes the game far more inviting.
- Coin door: clean, lubricate, confirm locks or convert/document free-play status for the placement site.
- Level the cabinet so it sits solidly with no rocking.

4. Control Panel — Joysticks & Buttons

Primal Rage is a two-player fighter. Responsive, accurate controls are essential.

- Clean or replace sticky buttons on both player sides.
- Inspect microswitches under the joysticks and buttons; clean contacts and adjust for positive, reliable actuation.
- Rebuild or replace worn joysticks (bushings, actuators, restrictor plates) so movement is smooth and accurate in all directions for both players.
- If the control-panel overlay is heavily scratched, torn, or peeling, a replacement improves both appearance and hygiene for public use. Secure any lifting edges.

5. Power Supply & Edge Connector

Clean the power supply area thoroughly. Check and replace oxidized or burned fuse holders. Verify stable voltages at the board under load. The edge connector is a frequent source of intermittent boots, resets, or missing power — clean the PCB fingers and the cabinet-side connector carefully. A modern switching supply conversion is a common reliability upgrade if the original supply is marginal.

6. Game Boards

Reseat boards firmly. Clean edge connectors. Look for obvious corrosion, broken traces, or heat-damaged components. If the machine has a history of random resets with power present, the edge connector and power path are the first places to check. Document any non-original boards or ROM sets for future volunteers.

7. Monitor

CRT path

Common issues include weak colors, focus problems, brightness drift, and chassis failures. Start with cleaning, checking monitor fuses, confirming isolation power, and reseating the neckboard. Only attempt deeper CRT work if experienced and following proper discharge procedures.

LCD conversion

An LCD conversion reduces heat, eliminates high-voltage hazards, and provides consistent picture quality with lower ongoing maintenance. Some cabinet modification or mounting work is usually required. Preserve the original CRT and chassis when possible.

8. Sound, Coin Door & Interior

- Confirm the speaker(s) produce clean sound at reasonable volume. Replace if distorted or weak.
- Clear dust from the interior, especially around the power supply and boards. Heat shortens component life.
- Confirm the rear interlock switch (if present) functions for safety.
- For free-play youth placements, set and document free-play or appropriate credit settings.

9. Final Testing Checklist Before Placement

- Full cold boot to attract mode with correct picture and sound
- Player 1 and Player 2 joysticks move cleanly in all directions with no dead zones
- All buttons on both sides register reliably and repeatedly
- Complete several full matches (both players) with no freezes or resets
- Monitor picture is focused and bright enough from normal player distance
- Cabinet exterior is clean, level, and free of sharp edges or loose parts
- Marquee is lit and readable
- Free-play or pricing configured correctly for the host site
- Keys, spare fuses, and basic notes bagged and labeled for the host organization

10. Notes for Host Sites

Provide a short one-page sheet: power on/off, free-play status, and who to contact. Recommend a weekly wipe-down of the control panel and glass. Ask the host to report any new stickiness, picture changes, or resets early. Document any non-original parts (LCD, switching supply, rebuilt joysticks, etc.) for future volunteers.

This guide is intended for educational and nonprofit restoration use by Coin Op 4 Charity and partner organizations. The goal is a Primal Rage that stays reliable, safe, and fun for the people who play it.

Document version 1.0 • Coin Op 4 Charity / Arcade Angels • coinop4charity.org