METHOD STATEMENT

Acrycourt CU — Rubberised Acrylic Cushion Layer for Sport Courts

Project Name		**Document No.**	OMX-MS-ACRYCOURTCU
Main Contractor		**Revision**	01
Consultant		**Date of Issue**	Nov 2026
Product	Acrycourt CU	**Status**	For Approval

1. Purpose

This method statement defines the procedure, sequence, resources, quality checks and safety measures for the supply and application of Acrycourt CU on site. It ensures that the work is carried out safely, in line with the approved drawings and project specification, and achieves the performance stated in the O MIX Technical Data Sheet.

2. Scope of Work

This method statement covers the application of Acrycourt CU rubberised acrylic cushion layers on prepared sport courts.

- Inspection and acceptance of the substrate and the work area.
- Surface preparation and repair of defects.
- Mixing and application of the material as described in this document.
- Curing, protection and handover of the completed area.
- Quality control, inspection and documentation of each stage.

3. Definitions

Term	Meaning
Coat	One application pass of material over the full area.
Squeegee	Rubber blade used to spread acrylic court materials.
Recoat time	Minimum drying time before the next coat.
Acrylic court system	Primer, resurfacer, cushion layers and colour coats applied in sequence.

4. Roles & Responsibilities

Role	Responsibility
Project Manager	Overall responsibility for planning, resources, approvals and coordination with the consultant and main contractor.
Site Engineer	Supervises the work daily; confirms substrate readiness, climate conditions, mixing, consumption and sequence; keeps daily records.

Role	Responsibility
QA/QC Inspector	Carries out inspections and tests at each stage, records results, raises inspection requests at hold points and signs the checklist.
HSE Officer	Conducts toolbox talks, checks PPE, ventilation, access and safe storage; stops work if unsafe conditions arise.
Foreman / Applicators	Carry out the work as per this method statement and report any deviation immediately.
Storekeeper	Receives, stores and issues materials in original packaging under the stated storage conditions; controls batch numbers.

5. Materials

Material	Description
Acrycourt CU	20 kg pails and 200 kg drums.
Primer	Bondmix WB on concrete where specified
Silica sand	Clean, dry, graded, where specified

5.1 Key product data

Property	Typical Value
Base	Acrylic with rubber granules
Density	1.20 – 1.35 kg/L
Solids content	50 – 65 %
Viscosity	20,000 – 35,000 mPa·s
Drying time	2 – 4 hours
Recoat time	6 – 12 hours
Full cure	24 – 48 hours

6. Tools & Equipment

- Rubber squeegees
- Soft brooms
- Rollers
- Mixing drums
- Slow-speed mixer
- Line tape
- Blowers
- Straight edge
- Thermo-hygrometer and surface thermometer (dew point check)
- Moisture meter
- Measuring buckets and scale
- Masking tape and protective sheeting

- Lighting and extension cables

6.1 Personal protective equipment

- Gloves
- Goggles
- Safety shoes

7. Storage & Handling

- 12 months in original, unopened packaging. Store at +5 °C to +35 °C; protect from frost and direct sunlight.
- Store on pallets, off the ground, in a dry, covered and ventilated area.
- Keep containers closed until use; use materials on a first-in, first-out basis.
- Keep containers tightly closed and protect from frost and direct sunlight.
- Handle with care to avoid damage to packaging; do not stack beyond the safe height.

8. Pre-Start Requirements

- Material submittal, this method statement and the inspection plan approved by the consultant.
- Work area handed over clean, free of other trades and with safe access.
- Adequate lighting, power supply and ventilation available.
- Climate conditions checked and recorded before work starts.
- A trial area prepared and approved where required by the project.
- Toolbox talk held with the work team covering this method statement and the safety measures.

9. Surface Preparation

1. Confirm the resurfaced base (Acrycourt RAC) is cured, clean and dry.
2. Remove dust and loose particles by blowing.
3. Correct ridges and depressions.
4. Check that ponding does not exceed the project tolerance (flood test) and correct low areas before coating.
5. Obtain QA/QC approval of the prepared surface before application.

10. Mixing

1. Check the batch numbers and colours and record them; use one batch per court where possible.
2. Stir Acrycourt CU thoroughly until uniform.
3. Apply as supplied.

11. Application

1. Spread with a rubber squeegee in straight passes.
2. Apply coarse coats first, then fine coats, as specified.
3. Apply each coat at 1.5 – 3.0 kg/m².
4. Work in straight passes in one direction; apply the next coat at 90° to the previous one.
5. Check consumption per coat and record it.

12. Curing & Protection

- Drying time 2 – 4 hours; recoat after 6 – 12 hours; full cure 24 – 48 hours.
- Protect from rain, dew and traffic until dry.
- Do not open the court to play before the full cure time.

13. Quality Control & Inspection

Check	Stage	Acceptance Criteria	By
Base	Before application	Cured, clean, dry	QA/QC
Climate	During work	+10 °C to +35 °C, no rain	Site Engineer
Consumption	Each coat	1.5 – 3.0 kg/m²	QA/QC
Finish	After drying	Uniform texture, no ridges	QA/QC

13.1 Inspection and test plan

Activity	Inspection / Test	Frequency	Record
Material receipt	Product, colour, batch, expiry	Each delivery	Material inspection report
Substrate	Cure, planarity, cleanliness	Each court	Inspection request (hold point)
Climate	Temperature, rain forecast	Start of each shift	Daily log
Each coat	Consumption, uniformity	Each coat	Daily report
Final	Colour, texture, line marking	Each court	Handover checklist

14. Defects & Remedies

Defect	Likely Cause	Remedy
Blisters	Thick coats; hot surface	Apply thinner coats in cooler hours
Ridges	Uneven squeegee passes	Scrape and recoat
Soft areas	Insufficient drying	Allow full drying before next coat

15. Health, Safety & Environment

Hazard	Control Measures
Eye and skin contact	Gloves, goggles
Slips on wet coatings	Barricades and signs
Manual handling of pails and drums	Correct lifting technique
Heat stress (outdoor work)	Shade, water, work schedule

- Wear gloves and safety goggles.
- Avoid contact with eyes and prolonged skin contact.
- Ensure ventilation in enclosed areas.
- Eyes: rinse with clean water for 15 minutes and seek medical advice.
- Skin: wash with soap and water.

15.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Do not discharge material or washings into drains or soil.
- Allow small quantities of leftover mixed material to cure before disposal; dispose of according to local regulations.

16. Cleaning

- Clean tools with water immediately after use.

17. Limitations

- Do not apply below +10 °C, above +35 °C surface temperature, or when rain is expected.
- Do not apply on asphalt younger than 14 days or concrete younger than 28 days.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

Appendix A — Inspection Checklist

Inspection Item	Result	Remarks
Base cured and clean	☐ Yes ☐ No	
Material stirred	☐ Yes ☐ No	
Coarse coats applied	☐ Yes ☐ No	
Fine coats applied	☐ Yes ☐ No	
Drying respected between coats	☐ Yes ☐ No	
Consumption recorded	☐ Yes ☐ No	
Surface uniform	☐ Yes ☐ No	

Inspected by	Signature	Date