Construction Chemicals

SUBMITTAL DOCUMENT

Mixflex SBR

Recycled SBR Rubber Granules
Infill & Shock Pad



Shock Absorbing
Safer play

Elastic
180 % elongation

Versatile
Infill or bound

Grades
0.5 – 20 mm

Project	
Main Contractor	
Consultant	
Submittal No. / Rev.	00
Date	Nov 2026

Construction Chemicals

Contents

1. Method Statement 3

2. Technical Data Sheet 8

3. Test Reports 11

4. Approvals & Certificates 12

METHOD STATEMENT

Mixflex SBR — Recycled SBR Rubber Granules Infill & Shock Pad

Project Name		**Document No.**	OMX-MS-MIXFLEXSBR
Main Contractor		**Revision**	01
Consultant		**Date of Issue**	Nov 2026
Product	Mixflex SBR	**Status**	For Approval

1. Purpose

This method statement defines the procedure, sequence, resources, quality checks and safety measures for the supply and application of Mixflex SBR on site. It ensures that the work is carried out safely, in line with the approved drawings and project specification, and achieves the performance stated in the O MIX Technical Data Sheet.

2. Scope of Work

This method statement covers the spreading of Mixflex SBR rubber infill into artificial turf and the installation of bound SBR shock layers.

- Inspection of the turf or base.
- Spreading and brushing infill.
- Mixing and laying bound layers.
- Levelling and inspection.
- Handover.

3. Definitions

Term	Meaning
Infill	Granules brushed between turf fibres.
Shock pad	Resilient layer under a sports surface.
Bound layer	Granules mixed with PU binder and compacted.

4. Roles & Responsibilities

Role	Responsibility
Project Manager	Overall responsibility for planning, resources, approvals and coordination with the consultant and main contractor.
Site Engineer	Supervises the work daily; confirms substrate readiness, climate conditions, mixing, consumption and sequence; keeps daily records.

Role	Responsibility
QA/QC Inspector	Carries out inspections and tests at each stage, records results, raises inspection requests at hold points and signs the checklist.
HSE Officer	Conducts toolbox talks, checks PPE, ventilation, access and safe storage; stops work if unsafe conditions arise.
Foreman / Applicators	Carry out the work as per this method statement and report any deviation immediately.
Storekeeper	Receives, stores and issues materials in original packaging under the stated storage conditions; controls batch numbers.

5. Materials

Material	Description
Mixflex SBR	Rubber granules, 25 kg bags, grade as specified
PU binder	For bound layers, as specified

5.1 Key product data

Property	Typical Value
Material	Recycled SBR rubber
Hardness	Shore A 70
Tensile strength	3 MPa
Elongation	180 %
Bulk density	0.78 g/cm³

6. Tools & Equipment

- Mechanical broom / top dresser
- Spreaders
- Forced-action mixer
- Screed rails
- Trowels
- Roller
- Thermo-hygrometer and surface thermometer (dew point check)
- Moisture meter
- Measuring buckets and scale
- Masking tape and protective sheeting
- Lighting and extension cables

6.1 Personal protective equipment

- Gloves
- Dust mask

- Safety shoes

7. Storage & Handling

- Store dry and covered, away from heat sources.
- Store on pallets, off the ground, in a dry, covered and ventilated area.
- Keep containers closed until use; use materials on a first-in, first-out basis.
- Store rolls and cartons flat, off the ground, protected from direct sunlight, heat, oil and mechanical damage.
- Handle with care to avoid damage to packaging; do not stack beyond the safe height.

8. Pre-Start Requirements

- Material submittal, this method statement and the inspection plan approved by the consultant.
- Work area handed over clean, free of other trades and with safe access.
- Adequate lighting, power supply and ventilation available.
- Climate conditions checked and recorded before work starts.
- A trial area prepared and approved where required by the project.
- Toolbox talk held with the work team covering this method statement and the safety measures.

9. Surface Preparation

1. Confirm the turf is installed and seams are complete.
2. Confirm the base for bound layers is level and clean.
3. Check grain size against the specification.
4. Obtain QA/QC approval before spreading.

10. Preparation of Material

1. Check bag labels for grade.
2. Infill: use as supplied.
3. Bound layers: mix granules with PU binder in a forced-action mixer as specified.

11. Spreading / Laying

1. Spread infill in several thin passes.
2. Brush into the turf with a mechanical broom after each pass.
3. Check depth at several points.
4. Bound layers: lay between screed rails, level and compact.
5. Record quantities per area.

12. Finishing & Protection

- Allow bound layers to cure as per the binder datasheet.
- Protect from traffic until cured.
- Final brushing and inspection of infill.

13. Quality Control & Inspection

Check	Stage	Acceptance Criteria	By
Material	On receipt	Correct grade	Storekeeper
Infill depth	After spreading	As per design	QA/QC
Bound layer	After curing	Firm, level	QA/QC

13.1 Inspection and test plan

Activity	Inspection / Test	Frequency	Record
Material receipt	Grade, condition	Each delivery	Material inspection report
Infill	Depth, uniformity	Each area	Daily report
Bound layer	Thickness, level	Each area	Inspection request
Final	Uniform surface	Each area	Handover checklist

14. Defects & Remedies

Defect	Likely Cause	Remedy
Uneven infill	Single heavy pass	Spread in thin passes and brush
Loose bound layer	Low binder content	Remove and relay
Puddling	Uneven base	Correct base levels

15. Health, Safety & Environment

Hazard	Control Measures
Dust	Dust masks
Machinery	Trained operators
Manual handling of bags	Correct lifting technique
Heat stress	Shade, water

- Wear gloves and a dust mask during spreading.
- Keep away from heat and ignition sources.
- Avoid inhalation of fine dust.

- Eyes: rinse with clean water.
- Inhalation: move to fresh air.

15.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Do not discharge material or washings into drains or soil.
- Allow small quantities of leftover mixed material to cure before disposal; dispose of according to local regulations.

16. Cleaning

- Collect spills with a broom or vacuum.

17. Limitations

- Spread infill only when dry.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

Appendix A — Inspection Checklist

Inspection Item	Result	Remarks
Grade verified	☐ Yes ☐ No	
Turf / base approved	☐ Yes ☐ No	
Infill spread in passes	☐ Yes ☐ No	
Brushed in	☐ Yes ☐ No	
Depth checked	☐ Yes ☐ No	
Bound layers cured	☐ Yes ☐ No	
Final inspection	☐ Yes ☐ No	

Inspected by	Signature	Date

Construction Chemicals

Technical Data Sheet

Mixflex SBR — Submittal Document

Construction Chemicals

Product Datasheet
Edition: 01 | Date: Nov 2026
Sport Court Systems



Mixflex SBR

Recycled SBR Rubber Granules
Infill & Shock Pad

Product Description

Mixflex SBR is recycled SBR rubber granulate used as infill for artificial turf and, bound with a PU binder, as shock-absorbing layers for sports surfaces, playgrounds and walkways.

Uses

- Infill for artificial turf.
- Shock pads for multi-purpose courts.
- Playgrounds and walkways.
- Base layers for tennis and running surfaces.

Advantages

- Shock absorbing.
- Range of grain sizes.
- Elastic: elongation 180 %.
- Infill or bound layers.
- Suitable for outdoor use.

Application

1. **Preparation**
   Check the turf or base is clean and installed as per design.
2. **Spreading**
   Spread infill evenly in layers with a mechanical broom, or mix with PU binder for bound layers.
3. **Finishing**
   Brush infill into the turf to the design depth; compact and level bound layers.

Consumption

approx. 8.2 kg/m²
typical infill
Depends on turf pile height and design.

Packaging

25 kg bags.

Storage & Shelf Life

Store dry and covered, away from heat sources.

Technical Data

Typical values at 25 °C

Property	Typical Value	Test Method
Material	Recycled SBR rubber	—
Hardness	Shore A 70	—
Tensile strength	3 MPa	—
Elongation	180 %	—
Bulk density	0.78 g/cm³	—

Consumption

Grain size	Typical use
0.5 – 1.5 mm	Turf infill (fine)
0.5 – 2.5 mm	Turf infill
0.5 – 4 mm	Shock pads / bound layers
2 – 8 mm	Bound base layers
8 – 20 mm	Coarse base layers

Consumption is theoretical and varies with substrate porosity, profile and application method.

Application Conditions

- Spread infill when the turf and granules are dry.
- Bound layers: follow the PU binder datasheet conditions.
- Spread in several passes for even distribution.

Application Notes

- Spread infill in layers and brush into the turf with a mechanical broom.
- Check infill depth at several points.
- For bound layers mix with PU binder and compact with a trowel or roller.
- Top up infill during maintenance.

Health & Safety

- Wear gloves and a dust mask during spreading.
- Keep away from heat and ignition sources.
- Avoid inhalation of fine dust.

First Aid & Cleaning

- Eyes: rinse with clean water.
- Inhalation: move to fresh air.
- Skin: wash with soap and water.
- Collect spills with a broom or vacuum.

The information in this datasheet is based on laboratory tests and practical experience and is given in good faith. Users should verify product suitability for their specific application. O MIX reserves the right to update this information without prior notice.

Construction Chemicals

Test Reports

Mixflex SBR — Submittal Document

To be attached: laboratory test reports supporting the values in the Technical Data Sheet.

Construction Chemicals

Approvals & Certificates

Mixflex SBR — Submittal Document

To be attached: approvals and certificates, where available.