METHOD STATEMENT

# O MIX MicroArt HD-Walls — Micro-Cement System for Walls & Columns

| | | | |
|---|---|---|---|
| **Project Name** | | **Document No.** | OMX-SMS-16 |
| **Main Contractor** | | **Revision** | 01 |
| **Consultant** | | **Date of Issue** | Nov 2026 |
| **System** | O MIX MicroArt HD-Walls | **Status** | For Approval |

## 1. Purpose

This method statement defines the sequence, resources, inspection and test plan and safety measures for the installation of the O MIX MicroArt HD-Walls system on site. It describes how each layer of the system is prepared, mixed, applied, inspected and protected so that the completed system achieves the performance stated in the O MIX Technical Data Sheets of its components.

## 2. Scope of Work

O MIX MicroArt HD-Walls is a thin decorative micro-cement system for interior walls and columns: a water-based bonding primer, fine micro-cement finishing layers, an intermediate water-based epoxy sealer and a clear matt PU top coat.

- Substrate inspection, testing and acceptance.
- Surface preparation and repair of defects.
- Stage 1: Primer / bonding coat — Bondmix WB.
- Stage 2: Finish layers — Micromix Deco 2.
- Stage 3: Intermediate sealer — Bondmix WB.
- Stage 4: Clear matt top coat — Decora PU.
- Curing, protection, final testing and handover.

### 2.1 System build-up

| Stage | Product | Function | Consumption |
|---|---|---|---|
| 1 | Bondmix WB | Primer / bonding coat | 0.2 kg/m² |
| 2 | Micromix Deco 2 | Finish layers | approx. 1 kg/m² |
| 3 | Bondmix WB | Intermediate sealer | 0.2 kg/m² |
| 4 | Decora PU | Clear matt top coat | 0.25 kg/m² |

### 2.2 Typical areas of use

- Interior walls.
- Columns.
- Feature walls in commercial and residential interiors.

## 3. Definitions

| Term | Meaning |
|---|---|
| **System** | All layers of the build-up applied in the stated sequence. |
| **Hold point** | Stage at which work stops until QA/QC (and the consultant, where required) approve. |
| **Recoat window** | Minimum and maximum time between two layers for proper inter-layer bonding. |
| **Dew point** | Temperature at which moisture condenses; the substrate must be at least 3 °C above it. |
| **Mock-up / trial area** | Area applied before the main works to approve materials, method and appearance. |
| **Pot life** | Time a mixed multi-component material remains workable. |

## 4. Roles & Responsibilities

| Role | Responsibility |
|---|---|
| **Project Manager** | Planning, resources, approvals and coordination with the consultant and main contractor. |
| **Site Engineer** | Daily supervision; confirms substrate readiness, climate, mixing, consumption and recoat windows; keeps daily records. |
| **QA/QC Inspector** | Carries out tests at each hold point, records results and signs the inspection checklist. |
| **HSE Officer** | Toolbox talks, PPE, ventilation, safe access and storage; stops unsafe work. |
| **Applicator Foreman** | Leads the application team and follows this method statement; reports deviations. |
| **O MIX Technical Representative** | Technical support, site visits and advice on product use when requested. |

## 5. Materials

| Product | Description | Packaging |
|---|---|---|
| **Bondmix WB** | Water-Based Two-Component Epoxy Primer & Bonding Coat | 10 kg sets (Part A 2 kg + Part B 8 kg) and 20 kg sets (Part A 4 kg + Part B 16 kg). |
| **Micromix Deco 2** | Micro-Cement Fine Finish Decorative Top Layer | 25 kg bags. |
| **Decora PU** | Clear Matt Polyurethane Top Coat for Decorative Concrete | 5 L and 20 L sets (Part A + Part B) in metal containers. |

### 5.1 Key product data

| Product | Mixing ratio | Pot life / working time | Recoat / drying |
|---|---|---|---|
| **Bondmix WB** | 1 : 4 by weight — pre-weighed sets, mix as recommended | 1 – 2 hours | 4 – 6 hours |
| **Micromix Deco 2** | Water / powder 0.30 – 0.33 | 15 – 20 minutes | approx. 2 hours |
| **Decora PU** | 5 : 1 by weight | 2 hours | 4 hours to 10 days |

## 6. Tools & Equipment

- Diamond grinder and/or shot blaster with dust extraction; industrial vacuum
- Slow-speed drill mixer (300 – 500 rpm) with spiral paddle
- Rollers, brushes, squeegees, notched trowels and steel trowels as required by each stage
- Scales and measuring containers for part mixing (where permitted)
- Thermo-hygrometer, surface thermometer and dew-point calculator
- Moisture meter and plastic sheets for moisture testing
- Masking tape, protective sheeting, barriers and warning signs
- Lighting and extension cables with residual current protection
- Stainless-steel and flexible trowels
- Orbital sander with 120 – 220 grit discs

### 6.1 Personal protective equipment

- Safety shoes, helmet and high-visibility vest
- Chemical-resistant gloves (nitrile) and safety goggles
- Coveralls with long sleeves
- Dust masks (P2) during grinding and powder mixing
- Respirators with organic vapour cartridges for solvent-containing products and confined spaces
- Knee pads for floor work

## 7. Storage & Handling

- Store all products in original, unopened packaging in a dry, shaded and ventilated store at the temperatures stated in each TDS.
- Keep Part A, Part B (and Part C) of each kit together; do not mix components from different batches.
- Protect liquids from frost and direct sun, and powders from moisture.
- Store solvent-containing products away from heat, sparks and ignition sources.
- Use materials on a first-in, first-out basis and record batch numbers for each area.
- Condition materials to +15 °C to +25 °C for 24 hours before use in hot or cold weather.

## 8. Pre-Start Requirements

- Approved material submittal, this method statement and the inspection and test plan.
- Approved drawings showing areas, joints, upstands, drains and details.
- Work area handed over clean, free of other trades, with safe access, lighting and power.
- Mock-up / trial area executed and approved for system, colour and finish.
- Toolbox talk held with the team on this method statement and HSE measures.
- Climate monitoring equipment calibrated and available.

## 9. Substrate Inspection & Acceptance (Hold Point)

| Check | Acceptance criteria | Method |
|---|---|---|
| **Concrete age** | ≥ 28 days (cement-based substrates) | Site records |
| **Compressive strength** | ≥ 25 N/mm² | Rebound hammer (ASTM C805) or cores |
| **Surface tensile (pull-off) strength** | ≥ 1.5 N/mm² | Pull-off test ASTM D7234 |
| **Moisture content** | < 4 % (no moisture under plastic sheet after 16 h) | Moisture meter; plastic sheet test ASTM D4263 |
| **Surface profile** | CSP 2 – 3 (primers / thin coats), CSP 3 – 5 (self-levelling / thick layers) | ICRI 310.2R comparator chips |
| **Flatness** | As per project specification | 3 m straight edge |
| **Climate** | Substrate ≥ 3 °C above dew point; RH ≤ 85 % | ISO 8502-4 / thermo-hygrometer |

## 10. Surface Preparation

1. Remove laitance, curing compounds, oil, paint and loose material by shot blasting or diamond grinding to the required profile.
2. Open cracks to a V-groove and remove dust; repair holes, voids and spalls.
3. Grind high spots and remove sharp edges; form 45° coves at wall / floor junctions where required.
4. Vacuum all dust with an industrial vacuum immediately before priming.
5. Mask and protect adjacent surfaces, drains and fixtures.
6. Record substrate test results and obtain QA/QC approval before priming (hold point).

## 11. Application Sequence

Apply the system stage by stage in the order below. Each stage must be inspected and approved before the next stage starts, and the next stage must be applied within the recoat window stated.

### 11.1 Stage 1 — Primer / bonding coat: Bondmix WB

Consumption: 0.2 kg/m². Time before next stage: 4 – 6 h.

1. Check batch numbers and condition the kit to +15 °C to +25 °C.
2. Pour the complete Part A into Part B (1 : 4 by weight).
3. Mix 2 – 3 minutes with a slow-speed mixer until uniform.
4. Mix complete sets only.
5. Apply by roller or brush at 0.15 – 0.30 kg/m² without puddles.
6. Apply a second coat on very porous substrates.
7. Apply the next system layer after 4 – 6 hours and within 24 hours.

### 11.2 Stage 2 — Finish layers: Micromix Deco 2

Consumption: approx. 1 kg/m². Time before next stage: 24 h between layers, sanding.

1. Pour the measured clean water into the bucket.
2. Add the powder gradually while mixing at low speed.
3. Mix 3 minutes to a smooth, lump-free paste; rest 2 minutes and remix briefly.
4. Apply the first finishing layer at 0.5 – 1 mm with a stainless-steel trowel.
5. After drying, sand lightly and remove dust.
6. Apply the second finishing layer after 24 hours and burnish as required.
7. Sand lightly and apply Decora PU top coat.

### 11.3 Stage 3 — Intermediate sealer: Bondmix WB

Consumption: 0.2 kg/m². Time before next stage: 4 – 6 h.

1. Check batch numbers and condition the kit to +15 °C to +25 °C.
2. Pour the complete Part A into Part B (1 : 4 by weight).
3. Mix 2 – 3 minutes with a slow-speed mixer until uniform.
4. Mix complete sets only.
5. Apply by roller or brush at 0.15 – 0.30 kg/m² without puddles.
6. Apply a second coat on very porous substrates.
7. Apply the next system layer after 4 – 6 hours and within 24 hours.

### 11.4 Stage 4 — Clear matt top coat: Decora PU

Consumption: 0.25 kg/m². Time before next stage: 12 – 24 h between coats.

1. Check batch numbers and condition the kit to +15 °C to +25 °C.
2. Stir Part A.
3. Add Part B to Part A at 5 : 1 by weight.
4. Mix 2 – 3 minutes with a slow-speed mixer.
5. Thin up to 20 % only where required.
6. Apply the first coat by roller or spray in a thin, even layer.
7. Avoid puddles and lap marks; keep a wet edge.
8. Apply the second coat after 12 – 24 hours (minimum 4 hours, maximum 10 days).
9. Apply further coats as specified.

## 12. Hold Points & Recoat Windows

| Stage | Before starting | Waiting time before next stage | Approved by |
|---|---|---|---|
| **1. Bondmix WB** | Substrate accepted (Section 9) | 4 – 6 h | QA/QC |
| **2. Micromix Deco 2** | Previous stage inspected and approved | 24 h between layers, sanding | QA/QC |

| Stage | Before starting | Waiting time before next stage | Approved by |
|---|---|---|---|
| **3. Bondmix WB** | Previous stage inspected and approved | 4 – 6 h | QA/QC |
| **4. Decora PU** | Previous stage inspected and approved | 12 – 24 h between coats | QA/QC |

## 13. Curing, Protection & Return to Service

- Protect each layer from rain, dew, dust, water and traffic until it has cured.
- Barricade the area and display warning signs during application and curing.
- Keep ventilation running in enclosed areas until full cure.
- Avoid water and heavy traffic for 7 days after the top coat; maintain with neutral cleaners only.

## 14. Quality Control & Inspection Test Plan

| Activity | Inspection / Test | Frequency | Record |
|---|---|---|---|
| **Material receipt** | Product, batch, expiry, packaging condition | Each delivery | Material inspection report |
| **Climate** | Air / substrate temperature, RH, dew point (ISO 8502-4) | Start of shift and every 4 h | Daily climate log |
| **Substrate** | Strength, pull-off (ASTM D7234), moisture (ASTM D4263) | Each area (hold point) | Inspection request |
| **Mixing** | Complete kits, ratio, mixing time | Each mix | Daily record |
| **Consumption** | Material used vs area | Each stage | Daily record |
| **Final inspection** | Appearance, continuity, finish, details | Each area | Handover checklist |

## 15. Defects & Remedies

| Defect | Likely cause | Remedy |
|---|---|---|
| **Poor adhesion / delamination** | Weak, dusty or damp substrate; recoat window exceeded | Remove, re-prepare and reapply; abrade and re-prime if window exceeded |
| **Pinholes / bubbles** | Outgassing; air trapped in mixing; thick application | Seal porous areas; mix slowly; spiked roller; sand and recoat |
| **Blushing / tacky surface** | High humidity or low temperature during cure | Wash, abrade and recoat in suitable conditions |
| **Soft spots** | Incorrect ratio or incomplete mixing | Remove and reapply with complete kits |
| **Cracking of cementitious layers** | Rapid drying; layer too thick | Protect from sun and wind; apply thinner layers |
| **Colour / shade variation** | Different batches; uneven application | Use one batch per area; apply additional coat |

## 16. Health, Safety & Environment

| Hazard | Control measures |
|---|---|
| **Skin / eye contact with resins and cement** | Gloves, goggles, coveralls; eye-wash station |
| **Inhalation of dust and vapours** | Dust extraction; ventilation; masks / respirators |
| **Fire (solvent vapours)** | No smoking or hot work; fire extinguisher at the work area |
| **Slips and trips** | Housekeeping; barricades and warning signs |
| **Manual handling** | Correct lifting; mechanical aids for drums and pails |
| **Electrical equipment** | Inspected tools; protected cables with RCD |

- Read the Safety Data Sheet of each product before use.
- Keep first-aid kit and eye-wash on site; follow the first-aid measures in each TDS.

### 16.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Allow small quantities of mixed resin to cure before disposal; dispose of according to local regulations.
- Do not discharge materials or washings into drains or soil.

## 17. Cleaning

- Clean tools of water-based and cementitious products with water immediately after use.
- Clean tools of epoxy and PU products with the recommended thinner before the material cures.
- Cured material can only be removed mechanically.

## 18. Limitations

- Do not apply outside the temperature and humidity limits stated in the TDS of each product.
- Do not apply on wet surfaces or when rain or dew is expected before the layer has cured.
- Do not mix or substitute products from other systems without written approval from O MIX.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

## 19. Maintenance

- Clean with neutral pH cleaners; avoid abrasive pads and acids.
- Re-apply Decora PU in high-traffic areas as needed.
- Use felt pads under furniture legs.

## Appendix A — Inspection Checklist

| Inspection Item | Result | Remarks |
|---|---|---|
| Approved submittal and method statement on site | ☐ Yes ☐ No | |
| Mock-up approved | ☐ Yes ☐ No | |
| Substrate tests passed (strength, pull-off, moisture) | ☐ Yes ☐ No | |
| Surface preparation approved | ☐ Yes ☐ No | |
| Stage 1 — Bondmix WB applied and approved | ☐ Yes ☐ No | |
| Stage 2 — Micromix Deco 2 applied and approved | ☐ Yes ☐ No | |
| Stage 3 — Bondmix WB applied and approved | ☐ Yes ☐ No | |
| Stage 4 — Decora PU applied and approved | ☐ Yes ☐ No | |
| Recoat windows respected | ☐ Yes ☐ No | |
| Final tests passed | ☐ Yes ☐ No | |
| Area protected and handed over | ☐ Yes ☐ No | |

| Inspected by | Signature | Date |
|---|---|---|
| | | |

## Appendix B — Daily Application Record

| Date | Area / zone | Stage | Batch No. | Qty used | Air / substrate °C | RH % | Sign |
|---|---|---|---|---|---|---|---|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |