METHOD STATEMENT

O MIX Soft Acrylic — Cushioned Acrylic Sport Court System

Project Name		**Document No.**	OMX-SMS-14
Main Contractor		**Revision**	01
Consultant		**Date of Issue**	Nov 2026
System	O MIX Soft Acrylic	**Status**	For Approval

1. Purpose

This method statement defines the sequence, resources, inspection and test plan and safety measures for the installation of the O MIX Soft Acrylic system on site. It describes how each layer of the system is prepared, mixed, applied, inspected and protected so that the completed system achieves the performance stated in the O MIX Technical Data Sheets of its components.

2. Scope of Work

O MIX Soft Acrylic is a cushioned acrylic court system. Over the primer and resurfacer, coarse and fine rubberised acrylic cushion layers add resilience and comfort, and coloured acrylic top coats complete the playing surface.

- Substrate inspection, testing and acceptance.
- Surface preparation and repair of defects.
- Stage 1: Primer (concrete only) — Bondmix WB.
- Stage 2: Resurfacer — Acrycourt RAC.
- Stage 3: Cushion layers — coarse — Acrycourt CU.
- Stage 4: Cushion layers — fine — Acrycourt CU.
- Stage 5: Colour top coat (2 coats) — Acrycourt PAC.
- Curing, protection, final testing and handover.

2.1 System build-up

Stage	Product	Function	Consumption
1	Bondmix WB	Primer (concrete only)	0.2 kg/m²
2	Acrycourt RAC	Resurfacer	1.5 kg/m²
3	Acrycourt CU	Cushion layers — coarse	3 kg/m² (in several coats)
4	Acrycourt CU	Cushion layers — fine	3 kg/m² (in several coats)
5	Acrycourt PAC	Colour top coat (2 coats)	0.5 kg/m²

2.2 Typical areas of use

- Tennis courts.

- Basketball courts.
- Multi-purpose and school courts.

3. Definitions

Term	Meaning
System	All layers of the build-up applied in the stated sequence.
Hold point	Stage at which work stops until QA/QC (and the consultant, where required) approve.
Recoat window	Minimum and maximum time between two layers for proper inter-layer bonding.
Dew point	Temperature at which moisture condenses; the substrate must be at least 3 °C above it.
Mock-up / trial area	Area applied before the main works to approve materials, method and appearance.
Pot life	Time a mixed multi-component material remains workable.

4. Roles & Responsibilities

Role	Responsibility
Project Manager	Planning, resources, approvals and coordination with the consultant and main contractor.
Site Engineer	Daily supervision; confirms substrate readiness, climate, mixing, consumption and recoat windows; keeps daily records.
QA/QC Inspector	Carries out tests at each hold point, records results and signs the inspection checklist.
HSE Officer	Toolbox talks, PPE, ventilation, safe access and storage; stops unsafe work.
Applicator Foreman	Leads the application team and follows this method statement; reports deviations.
O MIX Technical Representative	Technical support, site visits and advice on product use when requested.

5. Materials

Product	Description	Packaging
Bondmix WB	Water-Based Two-Component Epoxy Primer & Bonding Coat	10 kg sets (Part A 2 kg + Part B 8 kg) and 20 kg sets (Part A 4 kg + Part B 16 kg).
Acrycourt RAC	Acrylic Resurfacer for Sport Courts	20 kg pails and 200 kg drums.
Acrycourt CU	Rubberised Acrylic Cushion Layer for Sport Courts	20 kg pails and 200 kg drums.
Acrycourt PAC	Coloured Acrylic Top Coat for Sport Courts	20 kg pails and 200 kg drums.

5.1 Key product data

Product	Mixing ratio	Pot life / working time	Recoat / drying
Bondmix WB	1 : 4 by weight — pre-weighed sets, mix as recommended	1 – 2 hours	4 – 6 hours

Product	Mixing ratio	Pot life / working time	Recoat / drying
Acrycourt RAC	Ready to use	—	6 – 12 hours
Acrycourt CU	Ready to use	—	6 – 12 hours
Acrycourt PAC	Ready to use	—	4 – 6 hours

6. Tools & Equipment

- Diamond grinder and/or shot blaster with dust extraction; industrial vacuum
- Slow-speed drill mixer (300 – 500 rpm) with spiral paddle
- Rollers, brushes, squeegees, notched trowels and steel trowels as required by each stage
- Scales and measuring containers for part mixing (where permitted)
- Thermo-hygrometer, surface thermometer and dew-point calculator
- Moisture meter and plastic sheets for moisture testing
- Masking tape, protective sheeting, barriers and warning signs
- Lighting and extension cables with residual current protection
- Rubber squeegees and soft brooms
- Line-marking tape and equipment
- 3 m straight edge

6.1 Personal protective equipment

- Safety shoes, helmet and high-visibility vest
- Chemical-resistant gloves (nitrile) and safety goggles
- Coveralls with long sleeves
- Dust masks (P2) during grinding and powder mixing
- Respirators with organic vapour cartridges for solvent-containing products and confined spaces
- Knee pads for floor work

7. Storage & Handling

- Store all products in original, unopened packaging in a dry, shaded and ventilated store at the temperatures stated in each TDS.
- Keep Part A, Part B (and Part C) of each kit together; do not mix components from different batches.
- Protect liquids from frost and direct sun, and powders from moisture.
- Store solvent-containing products away from heat, sparks and ignition sources.
- Use materials on a first-in, first-out basis and record batch numbers for each area.
- Condition materials to +15 °C to +25 °C for 24 hours before use in hot or cold weather.

8. Pre-Start Requirements

- Approved material submittal, this method statement and the inspection and test plan.
- Approved drawings showing areas, joints, upstands, drains and details.

- Work area handed over clean, free of other trades, with safe access, lighting and power.
- Mock-up / trial area executed and approved for system, colour and finish.
- Toolbox talk held with the team on this method statement and HSE measures.
- Climate monitoring equipment calibrated and available.

9. Substrate Inspection & Acceptance (Hold Point)

Check	Acceptance criteria	Method
Asphalt / concrete age	Asphalt ≥ 14 days; concrete ≥ 28 days	Site records
Planarity and falls	Falls typically 0.8 – 1 % in one plane; no ponding after drainage	Flood test and 3 m straight edge
Climate	Substrate ≥ 3 °C above dew point; RH ≤ 85 %	ISO 8502-4 / thermo-hygrometer

10. Surface Preparation

1. Clean the asphalt or concrete by pressure washing and blowing; remove oil, dirt and vegetation.
2. Repair cracks and depressions; correct ponding areas with Acrycourt RAC patch mix.
3. Prime concrete surfaces with Bondmix WB; asphalt is not primed.
4. Mask and protect adjacent surfaces, drains and fixtures.
5. Record substrate test results and obtain QA/QC approval before priming (hold point).

11. Application Sequence

Apply the system stage by stage in the order below. Each stage must be inspected and approved before the next stage starts, and the next stage must be applied within the recoat window stated.

11.1 Stage 1 — Primer (concrete only): Bondmix WB

Consumption: 0.2 kg/m². Time before next stage: 4 – 6 h.

1. Check batch numbers and condition the kit to +15 °C to +25 °C.
2. Pour the complete Part A into Part B (1 : 4 by weight).
3. Mix 2 – 3 minutes with a slow-speed mixer until uniform.
4. Mix complete sets only.
5. Apply by roller or brush at 0.15 – 0.30 kg/m² without puddles.
6. Apply a second coat on very porous substrates.
7. Apply the next system layer after 4 – 6 hours and within 24 hours.

11.2 Stage 2 — Resurfacer: Acrycourt RAC

Consumption: 1.5 kg/m². Time before next stage: 6 – 12 h.

1. Stir Acrycourt RAC in its container.
2. Add silica sand at 1 : 1 to 1 : 2 (product : sand) and water as recommended.

3. Mix to a uniform squeegee consistency.
4. Pour the mix in lines and spread with a rubber squeegee in one direction.
5. Apply 1 – 2 coats to a total of 1.0 – 2.0 kg/m².
6. Scrape ridges lightly between coats.

11.3 Stage 3 — Cushion layers — coarse: Acrycourt CU

Consumption: 3 kg/m² (in several coats). Time before next stage: 6 – 12 h between coats.

1. Stir Acrycourt CU thoroughly until uniform.
2. Apply as supplied.
3. Spread with a rubber squeegee in straight passes.
4. Apply coarse coats first, then fine coats, as specified.
5. Apply each coat at 1.5 – 3.0 kg/m².

11.4 Stage 4 — Cushion layers — fine: Acrycourt CU

Consumption: 3 kg/m² (in several coats). Time before next stage: 6 – 12 h; full cure 24 – 48 h.

1. Stir Acrycourt CU thoroughly until uniform.
2. Apply as supplied.
3. Spread with a rubber squeegee in straight passes.
4. Apply coarse coats first, then fine coats, as specified.
5. Apply each coat at 1.5 – 3.0 kg/m².

11.5 Stage 5 — Colour top coat (2 coats): Acrycourt PAC

Consumption: 0.5 kg/m². Time before next stage: 4 – 6 h between coats; line marking after drying.

1. Stir Acrycourt PAC thoroughly.
2. Add silica sand where a textured finish is specified, as recommended.
3. Mix until uniform.
4. Apply the first coat by squeegee or roller in one direction.
5. Apply the second coat at 90° after 4 – 6 hours.
6. Apply each coat at 0.3 – 0.5 kg/m².
7. Mark lines after the final coat has dried.

12. Hold Points & Recoat Windows

Stage	Before starting	Waiting time before next stage	Approved by
1. Bondmix WB	Substrate accepted (Section 9)	4 – 6 h	QA/QC
2. Acrycourt RAC	Previous stage inspected and approved	6 – 12 h	QA/QC
3. Acrycourt CU	Previous stage inspected and approved	6 – 12 h between coats	QA/QC

Stage	Before starting	Waiting time before next stage	Approved by
4. Acrycourt CU	Previous stage inspected and approved	6 – 12 h; full cure 24 – 48 h	QA/QC
5. Acrycourt PAC	Previous stage inspected and approved	4 – 6 h between coats; line marking after drying	QA/QC

13. Curing, Protection & Return to Service

- Protect each layer from rain, dew, dust, water and traffic until it has cured.
- Barricade the area and display warning signs during application and curing.
- Keep ventilation running in enclosed areas until full cure.
- Allow the final colour coat to dry before line marking; open the court to play after full cure.

14. Quality Control & Inspection Test Plan

Activity	Inspection / Test	Frequency	Record
Material receipt	Product, batch, expiry, packaging condition	Each delivery	Material inspection report
Climate	Air / substrate temperature, RH, dew point (ISO 8502-4)	Start of shift and every 4 h	Daily climate log
Substrate	Strength, pull-off (ASTM D7234), moisture (ASTM D4263)	Each area (hold point)	Inspection request
Mixing	Complete kits, ratio, mixing time	Each mix	Daily record
Consumption	Material used vs area	Each stage	Daily record
Planarity	Flood test / straight edge	Each court	Inspection report
Line marking	Dimensions and straightness	Each court	Inspection report
Final inspection	Appearance, continuity, finish, details	Each area	Handover checklist

15. Defects & Remedies

Defect	Likely cause	Remedy
Poor adhesion / delamination	Weak, dusty or damp substrate; recoat window exceeded	Remove, re-prepare and reapply; abrade and re-prime if window exceeded
Pinholes / bubbles	Outgassing; air trapped in mixing; thick application	Seal porous areas; mix slowly; spiked roller; sand and recoat
Blushing / tacky surface	High humidity or low temperature during cure	Wash, abrade and recoat in suitable conditions
Soft spots	Incorrect ratio or incomplete mixing	Remove and reapply with complete kits
Colour / shade variation	Different batches; uneven application	Use one batch per area; apply additional coat

16. Health, Safety & Environment

Hazard	Control measures
Skin / eye contact with resins and cement	Gloves, goggles, coveralls; eye-wash station
Inhalation of dust and vapours	Dust extraction; ventilation; masks / respirators
Fire (solvent vapours)	No smoking or hot work; fire extinguisher at the work area
Slips and trips	Housekeeping; barricades and warning signs
Manual handling	Correct lifting; mechanical aids for drums and pails
Electrical equipment	Inspected tools; protected cables with RCD

- Read the Safety Data Sheet of each product before use.
- Keep first-aid kit and eye-wash on site; follow the first-aid measures in each TDS.

16.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Allow small quantities of mixed resin to cure before disposal; dispose of according to local regulations.
- Do not discharge materials or washings into drains or soil.

17. Cleaning

- Clean tools of water-based and cementitious products with water immediately after use.
- Clean tools of epoxy and PU products with the recommended thinner before the material cures.
- Cured material can only be removed mechanically.

18. Limitations

- Do not apply outside the temperature and humidity limits stated in the TDS of each product.
- Do not apply on wet surfaces or when rain or dew is expected before the layer has cured.
- Do not mix or substitute products from other systems without written approval from O MIX.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

19. Maintenance

- Clean the court regularly with soft brooms and water.
- Remove leaves and debris to prevent staining.
- Re-coat colour layers every few years depending on use.

Appendix A — Inspection Checklist

Inspection Item	Result	Remarks
Approved submittal and method statement on site	☐ Yes ☐ No	
Mock-up approved	☐ Yes ☐ No	
Substrate tests passed (strength, pull-off, moisture)	☐ Yes ☐ No	
Surface preparation approved	☐ Yes ☐ No	
Stage 1 — Bondmix WB applied and approved	☐ Yes ☐ No	
Stage 2 — Acrycourt RAC applied and approved	☐ Yes ☐ No	
Stage 3 — Acrycourt CU applied and approved	☐ Yes ☐ No	
Stage 4 — Acrycourt CU applied and approved	☐ Yes ☐ No	
Stage 5 — Acrycourt PAC applied and approved	☐ Yes ☐ No	
Recoat windows respected	☐ Yes ☐ No	
Final tests passed	☐ Yes ☐ No	
Area protected and handed over	☐ Yes ☐ No	

Inspected by	Signature	Date

Appendix B — Daily Application Record

Date	Area / zone	Stage	Batch No.	Qty used	Air / substrate °C	RH %	Sign