Construction Chemicals

SUBMITTAL DOCUMENT

Safe Coat AC

Water-Based Anti-Microbial
Coating for Hygienic Areas



Anti-Microbial
Bacteria & fungi

Resistant
Disinfectants

Hygienic
Easy to clean

Low VOC
Water-based

Project	
Main Contractor	
Consultant	
Submittal No. / Rev.	00
Date	Nov 2026

Construction Chemicals

Contents

1. Method Statement 3

2. Technical Data Sheet 9

3. Test Reports 12

4. Approvals & Certificates 13

METHOD STATEMENT

Safe Coat AC — Water-Based Anti-Microbial Coating for Hygienic Areas

Project Name		**Document No.**	OMX-MS-SAFECOATAC
Main Contractor		**Revision**	01
Consultant		**Date of Issue**	Nov 2026
Product	Safe Coat AC	**Status**	For Approval

1. Purpose

This method statement defines the procedure, sequence, resources, quality checks and safety measures for the supply and application of Safe Coat AC on site. It ensures that the work is carried out safely, in line with the approved drawings and project specification, and achieves the performance stated in the O MIX Technical Data Sheet.

2. Scope of Work

This method statement covers preparation, mixing, application, curing and inspection of Safe Coat AC (water-based anti-microbial coating for hygienic areas).

- Inspection and acceptance of the substrate and the work area.
- Surface preparation and repair of defects.
- Mixing and application of the material as described in this document.
- Curing, protection and handover of the completed area.
- Quality control, inspection and documentation of each stage.

3. Definitions

Term	Meaning
Pot life	Time the mixed material remains workable after adding water.
SSD	Saturated surface dry — substrate damp but without standing water.
Layer thickness	Thickness of one application pass.
Curing	Keeping the applied material protected from rapid drying until it gains strength.

4. Roles & Responsibilities

Role	Responsibility
Project Manager	Overall responsibility for planning, resources, approvals and coordination with the consultant and main contractor.
Site Engineer	Supervises the work daily; confirms substrate readiness, climate conditions, mixing, consumption and sequence; keeps daily records.

Role	Responsibility
QA/QC Inspector	Carries out inspections and tests at each stage, records results, raises inspection requests at hold points and signs the checklist.
HSE Officer	Conducts toolbox talks, checks PPE, ventilation, access and safe storage; stops work if unsafe conditions arise.
Foreman / Applicators	Carry out the work as per this method statement and report any deviation immediately.
Storekeeper	Receives, stores and issues materials in original packaging under the stated storage conditions; controls batch numbers.

5. Materials

Material	Description
Safe Coat AC	5 kg and 20 kg pails.

5.1 Key product data

Property	Typical Value
Base	Water-based acrylic, anti-microbial
Finish / colour	Satin to semi-gloss, white
Density	1.2 – 1.4 kg/L
Solids content	45 – 55 %
Touch dry	1 – 2 hours
Recoat	4 – 6 hours
Coverage	8 – 10 m²/L
Shelf life	12 months

6. Tools & Equipment

- Pressure washer
- Wire brushes
- Slow-speed mixer
- Brushes
- Rollers
- Airless spray
- Wet-film comb
- Thermo-hygrometer and surface thermometer (dew point check)
- Moisture meter
- Measuring buckets and scale
- Masking tape and protective sheeting
- Lighting and extension cables

6.1 Personal protective equipment

- Gloves
- Goggles
- Overalls
- Mask for spray

7. Storage & Handling

- 12 months in original, unopened packaging. Store dry at +5 °C to +35 °C, away from direct sunlight.
- Store on pallets, off the ground, in a dry, covered and ventilated area.
- Keep containers closed until use; use materials on a first-in, first-out basis.
- Keep containers tightly closed and protect from frost and direct sunlight.
- Handle with care to avoid damage to packaging; do not stack beyond the safe height.

8. Pre-Start Requirements

- Material submittal, this method statement and the inspection plan approved by the consultant.
- Work area handed over clean, free of other trades and with safe access.
- Adequate lighting, power supply and ventilation available.
- Climate conditions checked and recorded before work starts.
- A trial area prepared and approved where required by the project.
- Toolbox talk held with the work team covering this method statement and the safety measures.

9. Surface Preparation

1. Remove dust, dirt, oil, efflorescence and loose material.
2. Repair cracks and defects.
3. Ensure the surface is sound and dry (or as specified).
4. Pre-wet absorbent surfaces to a saturated surface-dry condition; remove standing water.
5. Protect adjacent surfaces with masking tape and sheeting.
6. Obtain QA/QC approval of the prepared surface before starting the next step.

10. Mixing

1. Check the batch number and expiry date and record them.
2. Stir thoroughly; use as supplied.

11. Application

1. Apply the first coat by brush, roller or airless spray.
2. Apply the second coat after 4 – 6 hours.

3. Work in manageable areas and finish each area in one operation where possible.
4. Check layer thickness and consumption regularly and record the results.

12. Curing & Protection

- Touch dry 1 – 2 hours; allow full drying before use.
- Protect from sun, wind and rain; keep moist where required during the first 24 hours.
- Barricade the area and display warning signs.

13. Quality Control & Inspection

Check	Stage	Acceptance Criteria	By
Substrate	Before application	Prepared, sound and clean as specified	QA/QC
Climate	During work	Ambient and substrate temperature: +10 °C to +35 °C	Site Engineer
Consumption	During application	0.12 – 0.15 kg/m² per coat (8 – 10 m²/L)	QA/QC
Finish	After curing	Uniform, no defects	QA/QC

13.1 Inspection and test plan

Activity	Inspection / Test	Frequency	Record
Material receipt	Product, batch, expiry, packaging condition	Each delivery	Material inspection report
Climate	Air / substrate temperature, RH, dew point	Start of shift and every 4 hours	Daily climate log
Surface preparation	Visual, moisture, soundness	Each area	Inspection request (hold point)
Application	Consumption, thickness, appearance	Each coat / area	Daily progress report
Final inspection	Visual, continuity, finish	Each completed area	Handover checklist

14. Defects & Remedies

Defect	Likely Cause	Remedy
Shrinkage cracks	Rapid drying; layer too thick; excess water	Remove, reapply in thinner layers and protect from drying
Poor adhesion / hollow areas	Dusty or dry substrate	Remove, clean and pre-wet; reapply
Dusting surface	Excess water or late finishing	Light sanding and apply a fresh thin layer
Uneven finish	Insufficient trowelling	Sand and apply a finishing layer

15. Health, Safety & Environment

Hazard	Control Measures
Skin and eye contact	Gloves, goggles, overalls; eye-wash available
Inhalation of vapours / dust	Ventilation; masks as required
Slips and trips	Housekeeping; barricades and signs
Manual handling	Correct lifting technique; mechanical aids
Electrical tools	Inspected tools; protected cables

- Wear gloves and safety goggles.
- Avoid contact with eyes and prolonged skin contact.
- Ensure ventilation in enclosed areas; use a mask for spray application.
- Eyes: rinse with clean water for 15 minutes and seek medical advice.
- Skin: wash with soap and water.

15.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Do not discharge material or washings into drains or soil.
- Allow small quantities of leftover mixed material to cure before disposal; dispose of according to local regulations.

16. Cleaning

- Clean tools with water immediately after use.

17. Limitations

- Ambient and substrate temperature: +10 °C to +35 °C.
- Substrate at least 3 °C above dew point.
- Do not apply in rain or when rain is expected before the material has set.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

Appendix A — Inspection Checklist

Inspection Item	Result	Remarks
Substrate prepared and approved	☐ Yes ☐ No	
Batch numbers recorded	☐ Yes ☐ No	
Material mixed as specified	☐ Yes ☐ No	
Applied at specified consumption	☐ Yes ☐ No	
Curing and protection carried out	☐ Yes ☐ No	
Final inspection passed	☐ Yes ☐ No	

Inspected by	Signature	Date

Construction Chemicals

Technical Data Sheet

Safe Coat AC — Submittal Document

Construction Chemicals

Product Datasheet
Edition: 01 | Date: Nov 2026
Protective Coating

Safe Coat AC

Water-Based Anti-Microbial Coating for Hygienic Areas



Product Description

Safe Coat AC is a water-based anti-microbial coating for walls and ceilings in hygienic environments. It resists bacteria, fungi, mild acids and alkalis and common disinfectants, and gives a satin, easy-to-clean finish. Low VOC.

Uses

- Clean rooms.
- Hospitals and laboratories.
- Pharmaceutical plants.
- Food processing areas.

Advantages

- Resists bacteria and fungi.
- Resists disinfectants and mild chemicals.
- Easy to clean, satin finish.
- Water-based, low VOC.
- Top coat of the O MIX Safecoat system.

Application

1. **Surface Preparation**
   Fill with O-Filler and seal with Carboseal.
2. **Mixing**
   Stir thoroughly; use as supplied.
3. **Application**
   Apply 2 coats by brush, roller or airless spray, 4 – 6 hours apart.

Consumption

0.12 – 0.15 kg/m²
per coat (8 – 10 m²/L)
Two coats recommended.

Packaging

5 kg and 20 kg pails.

Storage & Shelf Life

12 months in original, unopened packaging. Store dry at +5 °C to +35 °C, away from direct sunlight.

Technical Data

Typical values at 25 °C

Property	Typical Value	Test Method
Base	Water-based acrylic, anti-microbial	—
Finish / colour	Satin to semi-gloss, white	—
Density	1.2 – 1.4 kg/L	—
Solids content	45 – 55 %	—
Touch dry	1 – 2 hours	—
Recoat	4 – 6 hours	—
Coverage	8 – 10 m²/L	—
Shelf life	12 months	—

Consumption

Layer	Product	Consumption
Filler	O-Filler	0.25 kg/m²
Sealer	Carboseal	0.1 – 0.15 kg/m²
Top coat (2 coats)	Safe Coat AC	0.12 – 0.15 kg/m² per coat

Consumption is theoretical and varies with substrate porosity, profile and application method.

Application Conditions

- Ambient and substrate temperature: +10 °C to +35 °C.
- Substrate at least 3 °C above dew point.
- Relative humidity: max. 85 %.

Application Notes

- Apply over a sealed substrate.
- Apply 2 coats.
- Allow full drying before cleaning with disinfectants.
- Do not thin more than recommended.

Health & Safety

- Wear gloves and safety goggles.
- Avoid contact with eyes and prolonged skin contact.
- Ensure ventilation in enclosed areas; use a mask for spray application.

First Aid & Cleaning

- Eyes: rinse with clean water for 15 minutes and seek medical advice.
- Skin: wash with soap and water.
- Inhalation: move to fresh air.
- Ingestion: rinse mouth and seek medical advice.
- Clean tools with water immediately after use.

The information in this datasheet is based on laboratory tests and practical experience and is given in good faith. Users should verify product suitability for their specific application. O MIX reserves the right to update this information without prior notice.

Construction Chemicals

Test Reports

Safe Coat AC — Submittal Document

To be attached: laboratory test reports supporting the values in the Technical Data Sheet.

Construction Chemicals

Approvals & Certificates

Safe Coat AC — Submittal Document

To be attached: approvals and certificates, where available.