

For Pre-Flashed Sensor

1. Connect the station to a USB cable to power up the sensor.
2. The station will then create a WiFi network with the name airRohr-ID. The ID will be a set of numbers unique to each station. Take note of this, as this is how you will check its data.
3. Connect to the WiFi network created by the station. The default password for this network is 'airrohrcfg'.
4. Open your browser and type in <http://192.168.4.1/>
 - 4.1. Please note It may take a few tries for the NodeMCU to connect to the home WiFi network. Please be patient and try the steps several times until it works.
5. On the page that opens up, type in the name and password of your home WiFi network. Click the 'Save configuration and restart' button. The station will restart and will no longer be accessible in this way when it connects to your home WiFi network.
6. Wait 10 minutes

Verify it's Working

1. If you made no other changes in the previous step other than WiFi network configuration, the sensor will now start recording and uploading the data.
2. Navigate to the following page, and search using the ID you noted down.



Registering Your Device (Optional)

1. Go to devices.sensor.community to create an account and become a part of the open data network.
2. Fill out the form to register your device. Navigate to Home -> (Login) - Sensors -> Register new sensor
 - 2.1. Sensor ID is ID that you noted down before
 - 2.2. Your email address (will not be published)
 - 2.3. Your address: Street with house number, postcode and city. Click on "Lookup entered address" to get the location coordinates (will be rounded off). Check the position of the pin, change it if needed.
 - 2.4. Set a personal sensor name to make it easier to separate them if you have multiple sensors.
 - 2.5. The surroundings of the station - e.g. height above ground, side of the road, high traffic volume, free field or similar