Sophia Systems 2006-12-1

SGVP Driver Checklist

Operating environment:
OS:FedoraCore5
zImage (kernel): CD:¥binary¥kernel¥zImage
redboot (boot loader): CD:¥binary¥redboot¥redboot.bin
FileSystem: CD:¥binary¥rootfs¥kompressor.jffs2

Driver check

Driver	Check Method	Result
FrameBuffer	QVGA, color space: Only supports RGB16 (565) Check if a screen is displayed after executing "8.3.1 Test Application df_input Startup" of the Handbook.	○
USB Client	Perform the check using the procedure in "8.8 USB" of the Handbook.	○
CF	Use the SanDisk SDCFB 512MB. Perform a CF boot and CF mount and check if read and write is possible for the file. The transmission speed is outside the scope of the evaluation.	○
IrDA	Perform the check using the procedure in "8.7 IrDA" of the Handbook.	○
Sound(OSS)	Check if the system calls provided in "8.6 Sound" of the Handbook can be executed correctly. The audio is outside the scope of the evaluation.	○
Pointer	Check by operating the pointer after executing "8.3.1 Test Application df_input Startup" of the Handbook.	○
Power supply IC	Check if the voltage has changed after executing "8.5 DPM" of the Handbook.	○
LED	Check if the lit up status of the lights changes to match the charge status.	○
Keypad	Check by operating the pointer after executing "8.3.1 Test Application df_input Startup" of the Handbook.	○
Key Lighting	Perform the check using the procedure in "8.1 Key Lighting" of the Handbook.	○
Vibrator	Perform the check using the procedure in "8.2 Vibrator" of the Handbook.	○
Battery detection	Perform the check using the procedure in "8.4 Battery Cover Detection" of the Handbook.	○
WLAN (binary)	Use the SGVP's onboard module to connect to the access point and check if a ping is successfully received. The connection time is outside the scope of the evaluation.	○