




The screenshot shows the Cadence Virtuoso IDE interface. The top window has tabs for 'Project Summary', 'Device', 'dff.v', and 'dff.tb.v'. The main workspace displays a schematic diagram with a central component labeled 'X1 Y0' and a signal path. The bottom status bar indicates the current view is 'Td Console'.

Tcl Console x Messages Log

Q Z H ||

Starting simulation data flow analysis
Completed simulation data flow analysis
Time Resolution for simulation is 1ps
Compiling module xil_defaultlib.dff
Compiling module xil_defaultlib.glbl
Built simulation snapshot dff_behav

***** Webtalk v2021.1 (64-bit)
**** SW Build 3247384 on Thu Jun 10 19:36:33 MDT 2021
**** IP Build 3246043 on Fri Jun 11 00:30:35 MDT 2021
** Copyright 1986-2021 Xilinx, Inc. All Rights Reserved.

source C:/Users/Asus/sequential -notrace
couldn't read file "C:/Users/Asus/sequential": permission denied
INFO: [Common 17-206] Exiting Webtalk at Thu Jun 25 16:37:55 2026...
run_program: Time (s): cpu = 00:00:02 ; elapsed = 00:00:20 . Memory (MB): peak = 2172.789 ; gain = 20.449
INFO: [USF-XSim-69] 'elaborate' step finished in '20' seconds
INFO: [USF-XSim-4] XSim::Simulate design
INFO: [USF-XSim-61] Executing 'SIMULATE' step in 'C:/Users/Asus/sequential circuit/sequential circuit.sim/sim_1/behav/xsim'
INFO: [USF-XSim-98] *** Running xsim
with args "dff_behav -key {Behavioral:sim_1:Functional:dff} -tclbatch {dff.tcl} -log {simulate.log}"
INFO: [USF-XSim-8] Loading simulator feature
Time resolution is 1 ps
source dff.tcl
set curr_wave {current_wave_config}
if { (string length \$curr_wave) == 0 } {
if { ([length [get_objects]] > 0) {
add_wave /
set_property needs_save false [current_wave_config]
} else {
send_msg_id Add_Wave-1 WARNING "No top level signals found. Simulator will start without a wave window. If you want to open a wave window go to 'File->New Waveform'
}
}
run 1000ns
xsim: Time (s): cpu = 00:00:10 ; elapsed = 00:00:06 . Memory (MB): peak = 2194.406 ; gain = 21.617
INFO: [USF-XSim-96] XSim completed. Design snapshot 'dff_behav' loaded.
INFO: [USF-XSim-97] XSim simulation ran for 1000ns
launch_simulation: Time (s): cpu = 00:00:14 ; elapsed = 00:00:39 . Memory (MB): peak = 2194.406 ; gain = 42.781
|
< >

