
KY-028 Temperature Sensor module (Thermistor)

tents	Conte	tents		
			 	1
			 	1

Picture



Technical data / Short description

Temperature measurement range: -55° C / $+125^{\circ}$ C This module includes a NTC Thermistor - its resistance falls with higher temperature.


Digital Out: While measuring a temperature which is higher than the limit value, it will be shown here - you can set the limit value via potentiometer

Analog Out: Direct measurement of the sensor unit

LED1: Shows that the sensor is receiving power

LED2: Shows that a magnetic field was detected

Pinout




Functionality of the sensor

The sensor has 3 main components on its circuit board. First, the sensor unit at the front of the module which measures the area physically and sends an analog signal to the second unit, the amplifier. The amplifier amplifies the signal, according to the resistant value of the potentiometer, and sends the signal to the analog output of the module.

The third component is a comparator which switches the digital out and the LED if the signal falls under a specific value.

You can control the sensitivity by adjusting the potentiometer.

Please notice: The signal will be inverted; that means that if you measure a high value, it is shown as a low voltage value at the analog output.



This sensor doesn't show absolute values (like exact temperature in °C or magneticfield strenght in mT). It is a relative measurement: you define an extreme value to a given normal environment situation and a signal will be send if the measurement exceeds the extreme value.

It is perfect for temperature control (KY-028), proximity switch (KY-024, KY-025, KY-036), detecting alarms (KY-037, KY-038) or rotary encoder (KY-026).

Code example Arduino

The program reads the current voltage value which will be measured at the output pin and shows it via serial interface.

Additionally, the status of the digital pin will be shown at the terminal which means if the extreme value was exceeded or not.

```
// Declaration and initialization of the input pins
int Analog_Eingang = A0; // X-axis-signal
int Digital_Eingang = 3; // Button

void setup ()
{
```





KY-028 Temperature Sensor module (Thermistor)

```
pinMode (Analog_Eingang, INPUT);
  pinMode (Digital_Eingang, INPUT);
  Serial.begin (9600); // serial output with 9600 bps
}
// The program reads the current values at the input pins
// and outputs them at the serial output
void loop ()
  float Analog;
  int Digital;
  // Current values will be read and converted to voltage
  Analog = analogRead (Analog_Eingang) * (5.0 / 1023.0);
 Digital = digitalRead (Digital_Eingang);
  //... and outputted here
 Serial.print ("Analog voltage value:"); Serial.print (Analog, 4); Serial.print ("V, "); Serial.print ("Extreme value:");
  if(Digital==1)
  {
     Serial.println (" reached");
  else
  {
     Serial.println (" not yet reached");
  Śerial.println ("-----");
  delay (200);
```

Connections Arduino:

Export: 16.06.2017

```
\begin{array}{ll} \text{digital signal} &= [\text{Pin 3}] \\ +\text{V} &= [\text{Pin 5V}] \\ \text{GND} &= [\text{Pin GND}] \end{array}
```

!! Attention !! Analog Sensor !! Attention !!

The program uses the specific ADS1x15 and I2C python-libraries from the company Adafruit to control the ADS1115 ADC. You can find these here: [https://github.com/adafruit/Adafruit-Raspberry-Pi-Python-Code] published under the BSD-License [Link]. You can find the needed libraries in the lower download package.

The program reads the current values of the input pins and outputs it at the terminal in [mV].

Additionally, the status of the digital pin will be shown at the terminal to show if the extreme value was exceeded or not.

```
## Copyright by Joy-IT
### Published under Creative Commons Attribution-NonCommercial-ShareAlike 3.0 Unported License
### Commercial use only after permission is requested and granted
### KY-053 Analog Digital Converter - Raspberry Pi Python Code Example
# This code is using the ADS1115 and the I2C Python Library for Raspberry Pi
# This was published on the following link under the BSD license
# [https://github.com/adafruit/Adafruit-Raspberry-Pi-Python-Code]
from Adafruit_ADS1x15 import ADS1x15
from time import sleep
# import needed modules
import math, signal, sys, os
import RPi.GPIO as GPIO
GPIO.setmode(GPIO.BCM)
GPIO.setwarnings(False)
# initialise variables
delayTime = 0.5 # in Sekunden
# assigning the ADS1x15 ADC
ADS1015 = 0 \times 00 # 12-bit ADC
ADS1115 = 0 \times 01 \# 16 - bit
# choosing the amplifing gain
gain = 4096 \# +/- 4.096V
# gain = 2048 # +/- 2.048V
# gain = 1024 # +/- 1.024V
# qain = 512 # +/- 0.512V
              # +/- 0.256V
# gain = 256
# choosing the sampling rate
            # 8 Samples per second
\# sps = 8
             # 16 Samples per second
\# \text{ sps} = 16
\# sps = 32
            # 32 Samples per second
sps = 64 # 64 Samples per second
# sps = 128 # 128 Samples per second
\# sps = 250 \# 250 Samples per second
# sps = 475  # 475 Samples per second
# sps = 860  # 860 Samples per second
# assigning the ADC-Channel (1-4)
adc_channel_0 = 0
                    # Channel 0
adc_channel_1 = 1
adc_channel_2 = 2
adc_channel_3 = 3
                    # Channel 1
                     # Channel 2
                     # Channel 3
```

```
# initialise ADC (ADS1115)
adc = ADS1x15(ic=ADS1115)
# Input pin for the digital signal will be picked here
Digital_PIN = 24
GPIO.seTup(Digital_PIN, GPIO.IN, pull_up_down = GPIO.PUD_OFF)
# #######
# main program loop
# #######
# The program reads the current value of the input pin
# and shows it at the terminal
try:
       while True:
              #Current values will be recorded
              analog = adc.readADCSingleEnded(adc_channel_0, gain, sps)
              # Output at the terminal
              if GPIO.input(Digital PIN) == False:
                  print "Analog voltage value:", analog, "mV, ", "extreme value: not reached"
                   print "Analog voltage value:", analog, "mV, ", "extreme value: reached"
              print "-----
              sleep(delayTime)
except KeyboardInterrupt:
       GPIO.cleanup()
```

Connections Raspberry Pi:

Sensor

```
digital signal
                    = GPIO 24
                                 [Pin 18 (RPi)]
    +V
                    = 3,3V
                                 [Pin 1 (RPi)]
    GND
                    = GND
                                 [Pin 06 (RPi)]
                                 [Pin A0 (ADS1115 - KY-053)]
    analog signal
                    = Analog 0
ADS1115 - KY-053:
    VDD = 3.3V
                                 [Pin 01]
    GND
           = GND
                                 [Pin 09]
    SCL
           = GPIO03 / SCL
                                 [Pin 05]
    SDA
           = GPIO02 / SDA
                                 [Pin 03]
```

[Sensor: analog signal]

Example program download

Α0

KY-028_Temperature-sensor-module_RPi

= look above

To start, enter the command:

sudo python KY-028_Temperature-sensor-module_RPi.py