Lab 4: Simple Subroutine Call and Input Instructions

I. Simple Function Call

In the first year programming language courses such as CSc 110, CSc 111, we wrote many functions. In assembly language, the terms such as procedure, function, or subroutine can be used interchangeably. A function call implies a transfer (branch, jump) to an address representing the entry point of the function, causing execution of the body of the function. When the function is finished, another transfer occurs to resume execution at the statement following the call. The first transfer is the function call (for invocation), the second transfer is the return (to get back to the calling program). Together, this constitutes the processor's call-return mechanism.

In today's lab, we are going to write a simple function – no parameter passing, no return value. Create a new project named lab4. Type the following code then turn to the next page:

Step 0: Properly download the files (For help, watch Video Clip "How to download" from the course website Content -> Lab Material -> Lab03 -> videos -> "How to download":

```
LCD Shield Buttons.pdf
exercise1.docx
exercise2_blink.asm
exercise3_button.asm
```

Step 1: create a project named lab4 and type the following code:

```
; A simple subroutine
.cseg
.org 0


ldi r16, 1 ;load 1 to r16, opcode -> 01 e0
   call addOne ;call subroutine, opcode -> 0e 94 06 00
   mov r1, r16 ;copy the value in r16 to r1, opcode -> 10 2e

done: jmp done ; opcode -> 0c 94 04 00

addOne:
   inc r16 ; opcode -> 03 95
   ret ; opcode -> 08 95
```

Step 3: Build and go to the menu, click on *Debug -> Start Debugging and Break*. Press *F11* to step into the program. Download *exercise1.docx* file and do exercise 1. When you are done, show the result to your lab instructor.

The Program Counter (PC) contains the memory address of the next instruction to be fetched and executed. Observe how the value in PC is changed. How the execution of the program is transferred to the function "addOne" and is returned to the statement (mov r1, r16) after the call. The value in r16 is incremented by 1 in the subroutine call.




Step 4: Move the downloaded *exercise2_blink.asm* to the same directory as your main.asm and added it to your project, set it as "EntryFile", then change the code to a subroutine call (the section which is repeated). Make a copy of *upload.bat* file from lab 3 and save it to lab4\lab4\Debug\, the same directory as your lab4.hex file. Modify the *comX* port and *.hex* file name and upload the lab4.hex file to the board. The top and bottom lights are blinking. The LED lights are the same after changing to code to a method call.


Step 5: Move the downloaded *exercise3_button.asm* to the same directory as your main.asm and added it to your project, set it as "EntryFile", Open the file and read the text below:

Analog Inputs from Push Buttons

The five push buttons (exclude the *RST*- reset button) on the LCD shield are connected to pins of Port F and Port K on the board. Analog means continuous time signal and we need to use the built-in **A**nalog to **D**igital Convertor (ADC) to convert continuous electronic analog signal to digital value first. When a signal is sampled, the ADC converts the analog value to a 10-bit digital value as shown below:



The following is the I/O View of the ADC (If you don't see the I/O View window, make sure you clicked menu -> "Debug" -> "Start Debugging and Break", then click on menu -> "Debug" -> "Windows" -> "I/O"):



The memory addresses in SRAM are shown in the diagram below:


Name	Address	Value	Bits	
ADC ADC	0x78 ←	0x001	- 00000 000 000001	_
⊞ 🔐 ADCS	0x7A ←	0x00	-00 00000	
± Mac ADCSRB	0x7B ←	0x00	-0 -000	
⊞\‱ ADMUX	0x7C	0x00	0000000	
⊕ 🗎 DIDR2	0x7D	0x00	0000000	
⊕ 🖺 DIDR0	0x7E	0x00	000000	

Several registers must be set up properly before the ADC starts to digitize an analog signal. They are: ADCSR A/B (Control and Status Register A/B), ADMUX (Multiplexer Selection Register: selects a channel, as ADC can handle up to 8 channels) and ADC (10-bit ADC Data register). ADC is split into two 8-bit registers ADCL (8-bits) and ADCH (only 2-bits are used)

Expand the "+" sign for details. Give them a symbolic name using the following code:


- ; Definitions for using the Analog to Digital Conversion
- .equ ADCSRA BTN=0x7A
- .equ ADCSRB BTN=0x7B
- .equ ADMUX_BTN=0x7C
- .equ ADCL BTN=0x78
- .equ ADCH BTN=0x79

Set the proper values for those I/O registers:




A brief description of the registers:

ADCSRA - ADC Control and Status Register A



ADMUX - ADC Multiplexer Selection Register



In line 65 of exercise3_button.asm, the value in ADMUX is set to 0b01000000.

ldi r16, 0x40; 0x40 = 0b01000000

sts ADMUX_BTN, r16

It means:

bits 7:6(REFS1:0) = 01: AVCC with external capacitor at AREF pin. For proper conversion. bit 5 = 0: right adjustment the result. The result is stored in register pair (16 bits). The result is stored in the right most 10 bits (from 2^0 to 2^9).

bits 4:0 (MUX4:0) = 00000: combine with MUX5 (2^3) in ADCSRB_BTN ->ADC0 channel is used. There are 6 bits used to select which combination in of analog inputs are connected to the ADC. Among the 6 bits, bit 5 is the (2^3) in ADCSRB_BTN, and bits 4:0 are in $2^42^32^22^12^0$ of ADMUX BTN

ADCL and ADCH - The ADC Data Register

ADLAR = 0

Bit	15	14	13	12	11	10	9	8	_
(0x79)	-	_	_	-	-	-	ADC9	ADC8	ADCH
(0x78)	ADC7	ADC6	ADC5	ADC4	ADC3	ADC2	ADC1	ADC0	ADCL
	7	6	5	4	3	2	1	0	

ADLAR = 1

Bit	15	14	13	12	11	10	9	8	_
(0x79)	ADC9	ADC8	ADC7	ADC6	ADC5	ADC4	ADC3	ADC2	ADCH
(0x78)	ADC1	ADC0	-	-	-	-	-	-	ADCL
	7	6	5	1	2	2	4	٥	•

To initialize the ADC, several I/O registers should be set up properly. These are: **ADEN** bit in **ADCSRA**, reference signal bits **REFS1:S0** in **ADMUX**, the channel to be selected. The ADLAR bit affects the presentation of the ADC conversion result in the ADC Data Register. When this bit is 1, the result is left adjusted. Otherwise, it is right adjusted.

```
; enable the ADC & slow down the clock from 16mHz to ~125kHz, 16mHz/128
ldi r16, 0x87 ;0x87 = 0b10000111
sts ADCSRA_BTN, r16

ldi r16, 0x00
sts ADCSRB_BTN, r16 ; combine with MUX4:0 in ADMUX_BTN to select ADC0 p282

; bits 7:6(REFS1:0) = 01: AVCC with external capacitor at AREF pin p.281
; bit 5 ADCL_BTNAR(ADC Left Adjust Result) = 0: right adjustment the result
; bits 4:0 (MUX4:0) = 00000: combine with MUX5 in ADCSRB_BTN ->ADC0 channel is used.
ldi r16, 0x40 ;0x40 = 0b01000000
sts ADMUX_BTN, r16
```

ADCSRA: $0x87 = 0b \ 1000 \ 0111$ (means enable the ADC and slow down the ADC clock from 16mHz to $\sim 125kHz$, 16mHz/128).

ADMUX: $0x40 = 0b\ 0100\ 0000$ (means use the AVCC with external capacitor at AREF pin and use the right adjustment since ADCLAR is 0, ADC0 channel is used.) The reason for the right

adjustment is that the analog signal is digitized to a 10 bits value. ADCH:ADCL is 2 bytes (16bits). The digitized value is either left-adjusted or right-adjusted.

```
check button:
    ; start a2d
    lds r16, ADCSRA BTN
    ; bit 6 =1 ADSC (ADC Start Conversion bit), remain 1 if conversion not done
    ; ADSC changed to 0 if conversion is d
                                              In Single Conversion mode, turn on the
    ori r16, 0x40 ; 0x40 = 0b01000000
                                              ADC start conversion bit to start.
    sts ADCSRA_BTN, r16
    ; wait for it to complete, check for bit 6, the ADSC bit
wait:
        lds r16, ADCSRA BTN
                                    In Single Conversion mode, this bit is 0 if
        andi r16, 0x40 ___
                                  the conversion is in progress, 1 if the
        brne wait
                                    conversion is completed.
        ; read the value, use XH:XL to store the 10-bit result
        lds DATAL, ADCL BTN
        lds DATAH, ADCH BTN
        clr r23
        ; if DATAH:DATAL < BOUNDARY H:BOUNDARY L
              r23=1 "right" button is pressed
        ; else
              r23=0
        cp DATAL, BOUNDARY_L
        cpc DATAH, BOUNDARY_H
        brsh skip
        ldi r23,1
skip:
        ret
```

IV. Exercise 3: download **exercise3_button.asm** and write the delay function you did in the exercise 2 (need to change registers from r17, r18, r19 to the ones specified in the code).

This lab is derived from the chapter 5 of the book pdf file (go to course website -> Lecture slides, recent recordings ->) and chapter 26 (page 268) of the datasheet of ATMEGA 2560 https://ww1.microchip.com/downloads/en/devicedoc/atmel-2549-8-bit-avr-microcontroller-atmega640-1280-1281-2560-2561_datasheet.pdf)

The schematic on the LCD shield is posted below: http://www.dfrobot.com/image/data/DFR0009/LCDKeypad%20Shield%20V1.0%20SCH.pdf