IIIM ThinkPad 365 (non-CD-ROM models) - withdrawn

IBM® ThinkPad®:						ThinkPad 365 strengths:		
	10.4" dual scan		10.4" TFT			⇒ Entry-priced notebook		
Processor Processor upgrade Memory cache Diskette drive CD-ROM	Cyrix Cx486DX4™ 75/25 MHz / integrated math coprocessor None 8 KB in DX4 (write back) / no L2 cache Internal 3.5" 1.44 MB (not removeable) None (cannot upgrade)					 Extensive software preload Infrared port Optional Port Replicator with battery charger and palm rest 		
Price Type - model all 2625 Part number Preload (see side) Disk - capacity Disk - ms / interface Avail / withdrawn date Display - diagonal size Display - type Display - colors Display - contrast Graphics - controller Graphics - memory Graphics - external Graph - arch/data path	SelSys Win 95 340 MB 340 MB 540 M 13 ms / EIDE 13 ms Nov 1995 / Jun 96 Nov 19 10.4" Dual scan VGA color / 640 x 480 256 simultaneous colors 30 to 1 Chips and Technologies™ 512 KB DRAM External SVGA to 1024 x	65545 768 w/ 256 c	Selection 13 m Nov 10.4' VGA 262, 100 t Chip 1 ME colors u	5714 ctaSystem MB is / EIDE 95 / Jun 96 ' Black Matrix color / 640 x 144 simultane o 1 s and Technol 3 DRAM up to 70 Hz	ogies 65545	SELECTASYSTEM PRELOAD - IBM DOS 7.0 - Windows 3.11 - OS/2® Warp 3.0 (dual boot) with selected Bonus Pak applications - IBM PC Card Director™ 1.4 - IBM ThinkPad Demo - Online Users Guide - ThinkPad features; Diskette Factory 1. Lotus® cc:Mail™, e-mail for IBM Global® Network 2. Lotus Organizer™ 3. Lotus ScreenCam™		
Memory - std / max Memory - upgrade	VL-Bus 2.0 local bus / 32 bit / Simultaneous LCD and CRT / 180 degree tilt 8 MB / 24 MB 70 ns / non-parity / 3.3 volt / fast page 1 socket for one JEDEC 72 pin SO DIMM of 4 or 16 MB					4. Triton CoSession™ Host 5. PRODIGY® 6. SofNet FaxWorks™ 7. Video For Windows™ Runtime 8. Puma TranXit™ 9. Compuserv for Windows 10. NetFinity for Windows and OS/2 WINDOWS 95 PRELOAD - Microsoft Windows 95 - IBM ThinkPad Demo - Online Users Guide - ThinkPad features; Diskette Factory 1. Lotus® cc:Mail™, e-mail for IBM Global® network 2. Lotus Organizer™ 3. Lotus ScreenCam™ 4. Triton CoSession™ Host 5. PRODIGY® 6. SofNet FaxWorks™ 7. Puma TranXit™ 8. Compuserve for Windows		
Keyboard / # of keys Keyboard slope Pointing Ext keyboard support	Full size alp/num / 85 (8 Fn key functions) Yes (legs pop out) TrackPoint IIITM Yes (with option cable or Port Replicator) Liftable (pop-up) keyboard to access and remove battery (and upgrade memory and disk); diskette drive is not							
Dimensions (cubic in) Weight (with battery) Battery - type Battery - life Charge time - on / off	11.7 x 8.3 x 2.0" (194 cubic inches) 5.9 pounds NiMH/non-intelligent 3 to 9 hours 6 hrs / 2 hrs							
Architecture Docking Station Port replicator PCMCIATM 2.1 slots Serial / parallel ports Other features	ISA (audio, PCMCIA, diskette, serial, parallel, 100 pin external expansion) VL-Bus 2.0 / 32 bit / 25 MHz (graphics, disk) None Port Replicator and Charger (with built-in battery charger and palm rest) 2 Type I or 2 Type II or 1 Type III One 9 pin; 16550A / one (IEEE P1284, EPP, ECP, bidirectional) APM-aware BIOS / Universal AC adapter (35 watts) / Phoenix™ BIOS							
MPEG decoder Data/fax modem Audio support Audio in/out jacks Infrared ports	None None None None Infrared port in back / IrDA 1.0 compatible / up to 115 Kbps							
Security	Power-on password / Supervisor password / Locking device keyhole (Kensington™ MicroSaver™ cable lock) / keyboard lock (requires Kensington)							
Preinstalled software Warranty	Choice of two preloaded configurations (listed to right) 1 year - ThinkPad EasyServ (optional Overnight Repair Option) or carry-in							
The Port Replicator and Charger provide cable management, a battery charger for an optional second battery, a palm rest when installed on the system, and has complete port Options for ThinkPad 365: - 4 MB SO DIMM 3.3v non-parity 72 pin 92G7297 - 16 MB SO DIMM 3.3v non-parity 72 pin 92G7293 - 720 MB EIDE HDD 13 ms PIO Mode 3 38H6306								

replication.

The Port Replicator can charge a battery whether or not a ThinkPad is connected to it. When the ThinkPad is attached to the Port Replicator, it will attempt to recharge the battery in ThinkPad first (if there is one) before charging the battery in the Port Replicator.

Port Replicator and Charger connectors:

- Serial (RS-232, 9 pin) Parallel (EPP, ECP, 25 pin) External display (15 pin)
- Keyboard
- Mouse
- Diskette drive (26 pin) Game with MIDI support (15 pin)
- Audio in (3.5 mm)
- Audio out (3.5 mm)
- DC input connector
- Spare battery connector (to charge 2nd battery)

- 720 MB EIDE HDD 13 ms PIO Mode 3 38H6306 810 MB EIDE HDD 13 ms PIO Mode 442H4012
- 1.08 GB EIDE HDD 13 ms Mode 4 69H7956
- Port Replicator and Charger 38H6303
- NiMH Battery Pack 38H6304

Setup is entered by Ctrl + Alt + F11 from any full-screen DOS prompt

Fn + F2 = Battery guage

Fn + F3 = Standby

Fn + F4 = Suspend

Fn + F7 = LCD/CRT/Simultaneous

Fn + F8 = Reverse video

Fn + F11 = Powermgmt

Fn + F12 = Hibernation

PgUp = Speaker enable PgDn = Speaker disable

System enters hibernation mode when keyboard is lifted up.

Disk is not removable (like 755/760 systems), but it can be upgraded via tools

FEATURES OF 365 MODELS

Product Map LED indicator panel Plug and Play 1.0a Non-disruptive battery exchange Doze, standby, suspend, safe suspend, and hibernation modes US EPA Energy Star compliant Personalized nameplate in indention Personalization screen at startup International Warranty Service 24 hour / 7 day telephone, bulletin board, fax, and electronic support IBM or dealer warranty/service Online Housecall (remote diagnostics) 30 day money back guarantee