

SERVICE MANUAL Schematic Diagrams





Block Diagram
Spare Part List
DM8
Master Board, VU-Meter PFL Module
Out-Balance Boards
Phono-Line Board, Mic-Line Board
Mic-Line DJ Board, VU-Meter Module

Mic-Line Boards
Phono-Line Boards
Out-Balance Boards



Notice

Service must be carried out by qualified personnel only.

period will forfeit the right to guarantee.


Schematic Notes

manufacturer's specified parts.

Ω

- ← Soldering point.
- Male connector.
- Female connector.
- M/F faston connector.
- W// lastoff confide
- Test point.

- Supply voltage.
- ▲ Logic supply ground.
- ▲ Analog supply ground.
- 🛨 Chassis ground.











 \bigcirc


 \bigcirc






















 \bigcirc

 \bigcirc





DM6

080710 *

080293 *

347355 * 347357 *

347354 *

347365 *

347363 *

	PHONO-LINE/A BOARD					
Code		Ref.	Description			
768150		CMO100	PHONO-LINE/A BOARD (CSP077)			
	*	POT010	100KBx2 Rotary Pot.	[GAIN]		
	*	POT011	100KBx2 Center Click Rotary Pot.			
100061	*	ICS011	TL072 DUAL OP. AMP.			
100084	*	ICS012	TL074 QUAD. OP. AMP.			
	*	DEV010	2V 2P Switch	[PHONO/LINE]		
	*	DEV011	4V 2P Switch	[PFL]		
140242	*	CON016	Vertical RCAx2 Socket			

20 Contacts Vertical Connector

Yellow LED

15V 1W ZENER

Gray/Blu Knob

Gray/Red Knob

Gray/Red Switch Cap

Gray/Yellow Switch Cap

Gray/Yellow Slider Knob

PHONO-LINE/B BOARD

CON076

LED015

DIO065

			-,	
Code		Ref.	Description	
768151		CMO101	PHONO-LINE/B BOARD (CSPCSP)	077)
	*	POT010	100KBx2 Rotary Pot.	[GAIN]
	*	POT011	100KBx2 Center Click Rotary Pot.	
100061	*	ICS011	TL072 DUAL OP. AMP.	
100084	*	ICS012	TL074 QUAD. OP. AMP.	
	*	DEV010	2V 2P Switch	[PHONO/LINE]
	*	DEV011	4V 2P Switch	[PFL]
	*	CON017	Vertical RCAx4 Socket	
	*	CON076	20 Contacts Vertical Connector	
080710	*	LED015	Yellow LED	
080293	*	DIO065	15V 1W ZENER	
347355	*		Gray/Red Switch Cap	
347357	*		Gray/Yellow Switch Cap	
347354	*		Gray/Yellow Slider Knob	
347365	*		Gray/Blu Knob	
347363	*		Gray/Red Knob	

MIC-LINE/B BOARD

Code		Ref.	Description	
768152		CMO102	MIC-LINE/B BOARD (CSP078)	
	*	POT010	100KBx2 Rotary Pot.	[GAIN]
	*	POT011	100KBx2 Center Click Rotary Pot.	
100061	*	ICS011	TL072 DUAL OP. AMP.	
100084	*	ICS012	TL074 QUAD. OP. AMP.	
100019	*		TL071 OP. AMP.	
	*	DEV010	2V 2P Switch	[MIC/LINE]
	*	DEV011	4V 2P Switch	[PFL]
080710	*	LED015	Yellow LED	
140242	*	CON016	Vertical RCAx2 Socket	
	*	CON140	20 Contacts Vertical Connector	
141184	*	CON141	MC3FPR-H Female XLR	
080293	*	DIO065	ZENER 15V 1W	
347355	*		Gray/Red Switch Cap	
347357	*		Gray/Yellow Switch Cap	
347343	*		Gray/White Slider Knob	
347365	*		Gray/Blu Knob	
347363	*		Gray/Red Knob	

MIC-LINE BOARD

Code		Ref.	Description	
768153		CMO103	MIC-LINE BOARD (CSP078)	
	*	POT010	100KBx2 Rotary Pot.	[GAIN]
	*	POT011	100KBx2 Center Click Rotary Pot.	
100061	*	ICS011	TL072 DUAL OP. AMP.	
100084	*	ICS012	TL074 QUAD. OP. AMP.	
100019	*		TL071 OP. AMP.	
	*	DEV010	2V 2P Switch	[MIC/LINE]
	*	DEV011	4V 2P Switch	[PFL]
080710	*	LED015	Yellow LED	
140242	*	CON016	Vertical RCAx2 Socket	
	*	CON140	20 Contacts Vertical Connector	
141184	*	CON141	MC3FPR-H Female XLR	
080293	*	DIO065	15V 1W Zener	
347355	*		Gray/Red Switch Cap	
347357	*		Gray/Yellow Switch Cap	
347343	*		Gray/White Slider Knob	

347365	*	Gray/Blu Knob
347363	*	Gray/Red Knob

MIC-LINE DJ BOARD

	IVII	C-LINE D	BOARD	
Code		Ref.	Description	
768154		CMO104	MIC-LINE BOARD (CSP078)	
	*	POT010	100KBx2 Rotary Pot.	[GAIN]
	*	POT011	100KBx2 Center Click Rotary Pot.	
100061	*	ICS011	TL072 DUAL OP. AMP.	
100084	*	ICS012	TL074 QUAD. OP. AMP.	
100019	*		TL071 OP. AMP.	
	*	DEV010	2V 2P Switch	[MIC/LINE] [TALK OVER
	*	DEV011	4V 2P Switch	[PFL] [X-FADER]
080710	*	LED015	Yellow LED	
140242	*	CON016	Vertical RCAx2 Socket	
	*	CON140	20 Contacts Vertical Connector	
141184	*	CON141	MC3FPR-H Female XLR	
080293	*	DIO065	ZENER 15V 1W	
	*	CON053	6 Contacts MICS6 LUMBERG	
347355	*		Gray/Red Switch Cap	
347357	*		Gray/Yellow Switch Cap	
347343	*		Gray/White Slider Knob	
347365	*		Gray/Blu Knob	
	*		Gray/Red Knob	

MASTER BOARD

Code		Ref.	Description		
768155		CMO105	MASTER BOARD (CSP079)		
	*	POT010	100KBx2 Rotary Pot.	[GAIN]	
100061	*	ICS011	TL072 DUAL OP. AMP.		
100084	*	ICS012	TL074 QUAD. OP. AMP.		
100910	*	ICS023	TDA2822M		
100060	*	ICS001	LM7815 1.5A Voltage Regulator	•	
100049	*	ICS002	LM7915 1.5A Voltage Regulator		
	*	DEV010	2V 2PSwitch		
080705	*	LED014	Red LED		
	*	TRN018	BF244 Transistor		
	*	TRN028	BF244 Transistor		
90194	*	TRN011	BC561 Transistor		
	*	CON135	MX254-3 Vertical Connetor		
	*	CON017	Vertical RCAx4 Socket		
	*	CON073	14 Contacts P.1.27 Vertical Con	inector	
	*	CON076	20 Contacts Vertical Connector		
140242	*	CON016	Vertical RCAx2 Socket		
	*	CON136	MX254-6 Vertical Connector		
	*	CON110	MX508-6 Vertical Connector		
110113	*	FUS001	5x20 Fuseclip		
080168	*	DIO010	W02 Rectifier Bridge		
347356	*		Gray/White Switch Cap		
347363	*		Gray/Red Knob		
347342	*		Gray/Red Slider Knob		

VU-METER BOARD

Code		Ref.	Description
768156		CMO106	VU-METER BOARD (CSP070)
	*		TRIMMER 22K OR P10
080706	*	LED016	Green LED
080710	*	LED015	Yellow LED
080705	*	LED014	Red LED
100927	*	ICS024	LB1412
	*	DEV007	2V 2P SMK Switch [1/2]
	*	CON135	MX254W03 Vertical Connector
	*	CON053	MICS6 Connector LUMBERG Connector

VU-METER PFL BOARD

Code		Ref.	Description
768157		CMO107	VU-METER PFL BOARD (CSP070)
	*		TRIMMER 22K OR P10
080706	*	LED016	Green LED
080710	*	LED015	Yellow LED
080705	*	LED014	Red LED
100927	*	ICS024	LB1412
	*	CON135	MX254W03 Vertical Connector

CROSSFADER BOARD

768158		
, 00.00	CMO108	CROSSFADER BOARD
*	CON053	6 Contacts MICS6 LUMBERG Connector
*	POT029	2x100kW Slider Pot. (60 mm)
347354 *		Gray/Yellow Slider Knob

OUT-BALANCE 3 BOARD

Code		Ref.	Description
768159		CMO109	OUT BALANCE 3 BOARD (CSP080C)
100923	*	ICS017	5532
100061	*	ICS011	TL072 DUAL OP. AMP.
140228	*	CON034	Stereo Jack
140242	*	CON016	Vertical RCAx2 Socket
	*	CON075	14 Contacts Vertical Connector

OUT-BALANCE 2 BOARD

Code		Ref.	Description
768160		CMO110	OUT BALANCE 2 BOARD (CSP080B)
100923	*	ICS017	5533
100061	*	ICS011	TL073
140228	*	CON034	Stereo Jack
140242	*	CON016	Vertical RCAx2 Socket
	*	CON053	6 Contacts MICS6 LUMBERG
	*	CON075	14 Contacts Vertical Connector

OUT-BALANCE 1 BOARD

	-		
Code		Ref.	Description
768161		CMO111	OUT BALANCE 1 BOARD (CSP080A)
100923	*	ICS017	5533
100061	*	ICS011	TL073 OP. AMP.
140242	*	CON016	Vertical RCAx2 Socket
	*	CON143	NC3MPR-H Male XLR
	*	CON053	6 Contacts MICS6 LUMBERG
	*	CON075	14 Contacts Vertical Connector

DM8

MASTER BOARD

Code		Ref.	Description
768162		CMO112	MASTER BOARD (CSP084)
100060	*	ICS001	LM7815 1.5A Voltage Regulator
	*		TDA2822M
100061	*	ICS011	TL072 DUAL OP. AMP.
100049	*	ICS002	LM7915 1.5A Voltage Regulator
100061	*	ICS011	TL072 DUAL OP. AMP.
	*	CON136	CONN M VERT MX254W-06
	*	CON140	20 Contacts Vertical Connector
	*	CON135	MX254-3 Vertical Connetor
	*	CON053	6 Contacts MICS6 LUMBERG Connector
	*	CON110	6 Contacts MX508 W-06 Male Connector
	*	CON053	6 Contacts MICS6 LUMBERG
	*	CON144	34 Contacts Vertical Connector
	*	CON017	Vertical RCAx4 Socket
140242	*	CON016	Vertical RCAx2 Socket
110113	*	FUS001	5x20 Fuseclip
080168	*	DIO010	W02 Rectifier Bridge
080705	*	LED014	Red LED
	*	DEV010	2V 2P Switch
	*	CON026	Stereo Jack
	*	POT010	100KBx2 Rotary Pot.
		IT DAL ANG	CE N 1 BOARD

OUT-BALANCE N.1 BOARD

Code		Ref.	Description	
768163		CMO113	OUT-BALANCE N.1 BOARD (CSP085)	
	*		TRIMMER 4K7 ORIZZ	
	*		5532	
100061	*	ICS011	TL072 DUAL OP. AMP.	
	*	CON143	NC3MPR-H Male XLR	
	*	CON026	Stereo Jack	
	*	CON145	Stereo Jack 6.3 A-PJ-678-0	
	*	CON053	6 Contacts MICS6 LUMBERG	
	*	CON076	20 Contacts Vertical Connector	
140242	*	CON016	Vertical RCAx2 Socket	

OUT-BALANCE N.2 BOARD

Code		Ref.	Description	
768164		CMO114	OUT-BALANCE N.1 BOARD (CSP086)	
	*		4K7 Horizontal Trimmer	
	*		5532	
100061	*	ICS011	TL072 DUAL OP. AMP.	
	*	CON143	NC3MPR-H Male XLR	
	*	CON026	Stereo Jack	
	*	CON145	Stereo Jack 6.3 A-PJ-678-0	
	*	CON053	6 Contacts MICS6 LUMBERG	
	*	CON076	20 Contacts Vertical Connector	
140242	*	CON016	Vertical RCAx2 Socket	

PHONO-LINE BOARD

Code	Ref.	Description
768165	CMO115	PHONO-LINE BOARD (CSP087)

100061	*	ICS011	TL072 DUAL OP. AMP.
100084	*	ICS012	TL074 QUAD. OP. AMP.
	*	POT010	100KBx2 Rotary Pot.
	*	POT011	2x100KB CLICK C.
	*		34 Contacts Vertical Connector
	*	CON017	Vertical RCAx4 Socket
	*	DEV011	4V 2P Switch
	*		6V 2P Switch
	*	TRN004	BC550C
080706	*	LED016	Green LED
080710	*	LED015	Yellow LED
080705	*	LED014	Red LED

VU-METER PFL MODULE

Code		Ref.	Description
768166		CMO116	VU-METER PFL MODULE (CSP070)
080706	*	LED016	Green LED
080710	*	LED015	Yellow LED
080705	*	LED014	Red LED
	*	ICS024	LB1412
	*	DEV010	2V 2P Switch
	*	CON135	MX254-3 Vertical Connetor
	*	CON153	LUMBERG MICS6 Connector

MIC-LINE BOARD

Code		Ref.	Description
768167		CMO117	MIC-LINE BOARD (CSP070)
	*	ICS010	TL071 OP. AMP.
100061	*	ICS011	TL072 DUAL OP. AMP.
100084	*	ICS012	TL074 QUAD. OP. AMP.
	*	POT010	100KBx2 Rotary Pot.
	*	POT011	2x100KB CLICK C.
	*	CON144	34Contacts Vertical Connector
140242	*	CON016	Vertical RCAx2 Socket
	*	DEV011	4V 2P Switch
	*	TRN004	BC550C Transistor
080705	*	LED014	Red LED
080710	*	LED015	Yellow LED
080706	*	LED016	Green LED
	*	CON026	Stereo Jack
	*	CON141	XLR FEMMINA MC3FPR-H
	*	DIO065	ZENER 15V 1W

MIC-LINE DJ BOARD

	MIC-LINE DJ BOARD					
Code		Ref.	Description			
768168		CMO118	MIC-LINE BOARD (CSP088)			
	*	ICS010	TL071			
100061	*	ICS011	TL072 DUAL OP. AMP.			
100084	*	ICS012	TL074 QUAD. OP. AMP.			
	*	POT010	100KBx2 Rotary Pot.			
	*	POT011	2x100KB CLICK C.			
	*	CON144	34Contacts Vertical Connector			
140242	*	CON016	Vertical RCAx2 Socket			
	*	CON035	CON VERT 3V MX254-W-03			
	*	DEV011	4V 2P Switch			
	*	TRN004	BC550C Transistor			
080705	*	LED014	Red LED			
080710	*	LED015	Yellow LED			
080706	*	LED016	Green LED			
	*	CON026	Stereo Jack			
	*	CON141	MC3FPR-H Female Connector			
	*	DIO065	15V 1W Zener			

VU-METER MODULE

Code		Ref.	Description
768169		CMO119	VU-METER MODULE (CSP070)
080706	*	LED016	Green LED
080710	*	LED015	Yellow LED
080705	*	LED014	Red LED
	*	ICS024	LB1412
	*	DEV010	2V 2P Switch
	*	CON135	MX254-3 Vertical Connetor
	*	CON153	6 Contacts MICS6 LUMBERG Connector
Note:			

Each spare part is single quantity unless otherwise specified.

= First level spare part.

One asterisk = Second level, part of previous listed first level part. Two asterisk = Third level, part of previous listed second level part

Three asterisk = .

Any request for not above mentioned part must encompass specific description including 1) Model name,

- 2) Section name.
- 3) Module code,
- 4) Reference name,
- 5) Quantity number.