
GENERALMUSIC

 \bigcirc

L2000SD SWITCHING DIVERSITY VHF WIRELESS SYSTEM L2000 TRUE DIVERSITY **VHF WIRELESS SYSTEM**





Index

L2000-BTX (Body Pack) Assembly, Block Diagram, Adjustments, Spare Part List. L2000-BTX (Body Pack) Schematic Diagram 1st Version L2000-BTX (Body Pack) Schematic Diagram 2nd Version L2000-HTX (Handheld) Schematic Diagram 1st Version L2000-SD (Switching Diversity Receiver) Assembly, Block Diagram, Adjustments, Spare Part List. L2000-SD (Switching Diversity Receiver) Schematic Diagram L2000-TD (True Diversity Receiver) Assembly, Block Diagram, Adjustments. L2000-TD (True Diversity Receiver) Schematic Diagram

Warnings



Notice

Service must be carried out by qualified personnel only. Any tampering carried out by unqualified personnel during the guarantee period

For a correct operation of the instrument, after having switched off, be careful to wait at least 3 seconds before switching on again

To improve the device's specifications, the schematic diagrams may be subject to change without prior notice

All components marked by this symbol have special safety characteristics, when replacing any of these components use only

The (µ) micro symbol of capacitance value is substituted by U

The (Ω) omega symbol of resistance value is substituted by E.

The electrolytic capacitors are 25Vdc rated voltage unless otherwise specified.

All switches shown in the "OFF" position. All DC voltages measured to ground with a voltmeter 20KOhm/V.

- Supply voltage.

⊥ Logic supply ground

- Test point.

_ Analog supply ground. Chassis ground.

- Female connector. M/F faston connector.
 - Flag joined with one or more flags
- with the same signal name inscribed
- ()Earth ground.




ATTENTION Observe precautions when handling electrostatic sensitive devices.


Address

- GENERALMUSIC S.p.A. Sales Division: 47842 S.Giovanni in Marignano (RN) ITALY Via delle Rose, 12
- Phone +39(0)541/959511 · Fax +39(0)541/957404 · GENERALMUSIC on the NET: http://www.generalmusic.com

(NOT AVAILABLE)





L2000-BTX Block Diagram




L2000-BTX Spare Part List


PARTS A	VAILABLE UP TO TODAY (DECEMBER 2001)
110289	9V Alkaline Battery Type 6LR61
SKK888002	L2000-BTX BODYPACK TRANSMITTER
SKK888003	LT-1 LAVALIER MICROPHONE
SKK888028	* LAVALIER PEG SUPPORT FOR LT-1
SKK888024	* FOAM WINDSCREEN FOR LT-1
SKK888004	ST-1 HEADSET MICROPHONE
SKK888026	* HEADSET SUPPORT FOR ST-1
SKK888025	* FOAM WINDSCREEN FOR ST-1
SKK888005	GT-1 INSTRUMENT CABLE
SKK888001	L2000-HTX HANDHELD MICROPHONE
SKK888027	* DYNAMIC CARDIOID MICROPHONE CAPSULE









L2000-SD Assembly







L2000-SD & TD Spare Part List


277353	L2000-SD OWNER'S MANUAL (I-UK)	
277354	L2000-TD OWNER'S MANUAL (I-UK)	
SKK347000	WIRELESS SYSTEM BAG	
SKK888000	L2000SD-RX RECEIVER	
SKK888006	L2000TD-RX RECEIVER	
SKK888010	MONO JACK-JACK CABLE L=1,5MT	
SKK888011	ANTENNA FOR VHF SYSTEM	
SKK888012	ADAPTER "D41WI120300-12/1" 230V VOUT=12VDC 300MA	
SKK888013	ADAPTER "D41WI120300-12/1" 115V VOUT=12VDC 300MA	









L2000-TD Assembly L2000-TD Adjustments



L2000-TD Block Diagram (General)


L2000-TD Block Diagram (Receiver Module)





 \bigcirc

 \bigcirc



POWER SW1

from SUPPLY BOARD CN4

from SUPPLY BOARD CN3

from SUPPLY BOARD CN1

+VCC IN (+10V) RF LEVEL DISP AF DISP GND CH-A LED CH-B LED

AF-LEVEL

LEDS LED7 LED6 LED5 LED4

BA6124

LEDI GREEN

R12 100R

LED2 RED

VR1 B100K

VOLUME