Installation Thermo-Calc on personal computer

Download the installation packages

For 64bit windows: http://www.met.kth.se/~lars/windows-installation-x64-6.1.23369.exe

For 32bit windows: http://www.met.kth.se/~lars/windows-installation-x86-6.1.23369.exe

For windows also download: http://www.met.kth.se/~lars/sfinit.zip

For MacOS: http://www.met.kth.se/~lars/mac-installation-6.1.23369.zip

For Linux: http://www.met.kth.se/~lars/linux-installation-x64-6.1.23369.run

Obtain a license file

In order to obtain a license file, retrieve the address of the "Ethernet adapter Local Area Connection", this may be obtained by starting a command window and typing:

ipconfig /all

The required number is 12 digit hexadecimal number (e.g. 00-01-A1-B1-88-5E) send this number to lars@mse.kth.se in order to receive a license file.

(for MacOS and linux open a terminal and type: ifconfig)

When you received the license file then rename the attached file to "Iservrc" (NOTE: without extension) and store it on your computer.

Installation

Run the installation package for Thermo-Calc by double-clicking on downloaded file. When prompted for the license file indicate the previously stored "Iservrc"

(for MacOS remember to install XQuartz)

Activate the license

For windows unzip the previously downloaded file "sfinit.zip" and run "sfinit.exe" as administrator