




| Dirección | Instrucción  | Tipo | Campos  |       |       |     |       | Lenguaje de máquina |          |
|-----------|--------------|------|---------|-------|-------|-----|-------|---------------------|----------|
|           |              |      | imm     | rs2   | rs1   | f3  | imm   | op                  |          |
| 0x1004    | sw x6, 8(x9) | S    | 0000000 | 00110 | 01001 | 010 | 01000 | 0100011             | 0064a423 |

| Banco de registros |        | Memoria de datos |    |
|--------------------|--------|------------------|----|
| x9                 | 0x2004 | 0x2000           | 10 |