
Operating Sundance's Spa and Pool Heater



When in "pool" mode, both spa and pool are heated to a max of approximately 90 degrees (depending upon the temperature that you set with the temperature buttons).

When in "spa" mode, spa will not "spillover" into pool. The result is that the spa will be heated to a max of approximately 100 degrees and the pool (because it is no longer receiving heated water) will gradually cool down.

Because of this, we recommend using "spa mode" only when actively using the spa. When not actively using the spa, we suggest using "pool mode" as this will keep the pool warm.