

Microprocessors Fall 2020

11. Analog Interfacing

https://micro.furkan.space

Tentative Weekly Schedule

- Week x1 Introduction to Course
- Week x2 Architecture
- Week x3 Assembly Language Introduction
- Week x4 Assembly Language Usage, Memory and Faults
- Week x5 Embedded C and Toolchain
- Week x6 Exceptions and Interrupts
- Week x7 GPIO, External Interrupts and Timers
- Week x8 Timers
- Week x9 Serial Communications I
- Week xA Serial Communications II
- Week xB Analog Interfacing
- Week xC DMA
- Week xD RTOS
- Week xE Wireless Communications



2

https://micro.furkan.space

Introduction

Why do we need analog interfacing?

- Embedded systems often need to measure values of physical parameters
- These parameters are usually continuous (analog) and not in a digital form which computers (which operate on discrete data values) can process


We live in an analog world!

- **Temperature** thermometer, thermostat, car engine, processor thermal management, reactors
- **Light intensity** digital camera, IR remote control, optical communication
- Pressure blood pressure monitor, altitude control, deep sea activity
- Acceleration air bag controller, vehicle stability, video game remote, pendulum
- Audio microphone, sonar, recording, noise cancelling
- Position Rotary position, wind gauge, volume control, knobs
- Monitoring battery level, motor control
- displacement, flow, radiation, ...





Example: Smart car sensors



Going from analog to digital

 We need to somehow convert these physical phenomena into engineering units for processing



 The first part of the puzzle is to use some sort of transducer that will translate one type of energy to another.


6

Usually to voltage or current.




https://micro.furkan.space

Example - Temperature Sensing



7

Example - Light Sensing






https://micro.furkan.space


Going from analog to digital

For the second part of the puzzle we can use two approaches:

- A comparator tells us if Vin > Vref
 - Compares an analog input voltage with an analog reference voltage and determines which is larger, returning a 1-bit number



• An Analog to Digital Converter (ADC, A/D) tells us how large Vin is as a fraction of Vref.





GEBZE

https://micro.furkan.space

Going from analog to digital

The last part is to use this **digital information** to produce the needed engineering unit.

```
#define ADCMASK (255)
        #define VREF
        adc val = read ADC();
        adc_voltage = VREF * adc_val / ADCMASK;
       temp = (adc_voltage - VTEMPOFFSET) / VTEMPGAIN;
Physical
                                                         Engineering
                   Voltage or
                                      ADC Counts
                                                         Units
Phenomena
                   Current
                               ADC
           Sensor
```



10

https://micro.furkan.space

Analog to Digital Converter


- An Analog to Digital Converter reads an analog input signal (usually a voltage) and produces a corresponding multi-bit number at the output.
- Requires two reference voltages for minimum and maximum values. (Usually denoted as AV_{RFF+} an AV_{REF})
 - Meaning, we can translate (or map) voltages in between these reference voltage values.
- Will round the voltage to the nearest possible digital value depending on the resolution.

(can round down if not adjusted)

Representing an analog signal digitally

How do we represent an analog signal?

- As a time series of discrete values (Sampling)
- Map voltages to digital values with a linear correlation (Quantization)
- The range of digital values is the resolution.



12




Choosing the horizontal range

We need to make sure we can represent the **whole**


voltage range effectively.


 What do the sample values represent?

What range to use?



Range Too Small








V.

https://micro.furkan.space

Example microphone signal

• It needs to be biased in the middle voltage level to get the full scale.



GEBZE

14


https://micro.furkan.space

How to represent analog value digitally

ADC Resolution is the **number of discrete** values that represent a range of analog values, denoted as **ADC bits** (8-bit, 12-bit, 16-bit, ...)

Example:

For a 3-bit ADC, voltage range are represented in $2^3 = 8$ different levels.




Step size is voltage range/ $2^3 = 1/8 = 0.125$ volts

Sampling

- In order to represent a continuous signal, we need to sample it periodically
- Each sample represents the **instantaneous** amplitude at the instant of sampling
- The interval between two samples is called the








Sampling Time (or rate)

- If the sampling time is too large, we cannot reconstruct the signal
- If the sampling time is too small, we waste computation, energy and resources.






17

https://micro.furkan.spa

Sampling Problems

- If the sampling time is too large (or sampling rate is too low), we cannot reconstruct the signal
- Will mix up frequencies





l8

https://micro.furkan.space

Shannon-Nyquist sampling theorem

 If a continuous-time signal f(x) contains no frequencies higher than f_{max}, it can be completely determined by discrete samples taken at double the desired max frequency.

$$f_{\text{samples}} > 2f_{\text{max}}$$

 Frequency components above 1/2 f_{samples} are aliased, distorting the measured signal.

Real world sampling

- Real world filters have more gentle roll-off
- Inexpensive filters are even worse.
- Thus, we usually need to go a little bit more higher

$$f_{\text{samples}} > 2f_{\text{max}}$$

Example:


- Humans can process audio signals between
 20 Hz 20 KHz
- Audio tracks sample at 44.1KHz






Aliasing

Aliasing causes a false lower frequency component to appear in the sampled data of a signal. The following figure shows an adequately sampled signal and an inadequately sampled signal.





Insert a Low-Pass Filter between the signal source and ADC (anti-aliasing filter)



Low-pass cutoff frequency is set to

$$f_{cutoff} = f_{Nyq} = \frac{1}{2 \times t_{samp}}$$

This ensures no high frequencies are sampled by the ADC




22


https://micro.furkan.space

Quantization

GEBZE


- Quantization is the digital representation of the analog signal
- For the same signal with same sampling time but different resolution will result in different waveforms. - Higher resolution is better.






Quantization Error

- Quantization Error describes how far off discrete value is from the actual voltage
- +- 1/2 LSB for a total of 1 LSB





Example: Quantization and Error



Forward Transfer Function Equations

What code n will the ADC use to represent voltage V_{in}?

$$n = \left| \frac{V_{in} - V_{-ref}}{V_{+ref} - V_{-ref}} 2^{N} + 1/2 \right|$$

General Equation

n = converted code

V_{in} = sampled input voltage

V_{+ref} = upper voltage reference

V_{-ref} = lower voltage reference

N = number of bits of resolution in ADC



26

https://micro.furkan.space

Forward Transfer Function Equations

We can simplify the equation if V-ref is 0 Volts.

$$n = \left| \frac{V_{in}}{V_{+ref}} 2^N + 1/2 \right|$$

Example:

$$n = \left| \frac{3.3V}{5V} 2^{10} + 1/2 \right| = 388$$

$$[X] = floor(X)$$

- floor(X) nearest integer I such that I <= X
- **floor(X + 0.5)** rounds x to the nearest integer

What if the Reference Voltage is not known?

- Example running off of an unregulated battery
 - Measure a known voltage and an unknown voltage.

$$V_{unknown} = V_{known} \frac{n_{unknown}}{n_{known}}$$


- Many MCUs include an internal fixed voltage source which ADC can measure for this purpose
 - Can also solve for Vref

$$V_{ref} = V_{known} \frac{2^N}{n}$$



Digital to Analog Conversion

- While we want to read and sample analog values using sensors, sometimes we want to also generate analog values to drive actuators.
- **Digital to Analog Converter (DAC)** generates the analog voltage which is the fraction of Vref
- General equation is $V_{ref} n/(2^N)$






29

https://micro.furkan.space

Example 3-bit DAC

- Simple **R-2R** configuration
- By turning on each switch, you change the resistor ratios that affects the output voltage







30


https://micro.furkan.space

Example 3-bit DAC



S2	Sl	so	٧o
OFF OFF OFF ON ON	OFF ON ON OFF OFF	OFF ON OFF ON OFF	$\begin{array}{c} 0 \\ 0.125 \times VR \; (1/8 \times VR) \\ 0.25 \times VR \; (2/8 \times VR) \\ 0.375 \times VR \; (3/8 \times VR) \\ 0.5 \times VR \; (4/8 \times VR) \\ 0.625 \times VR \; (5/8 \times VR) \end{array}$
ON	ON	OFF ON	$\begin{array}{l} 0.75 \times VR \; (6/8 \times VR) \\ 0.875 \times VR \; (7/8 \times VR) \end{array}$





ADC Types


- There are several different ADC types each with their strengths and weaknesses.
 - Tracking ADC
 - Flash ADC
 - Successive Approximation ADC
 - Single/Dual-slope ADC
 - Sigma-delta (ΣΔ) ADC






Tracking ADC

- The tracking ADC has a comparator, a counter and a digital-to-analog converter.
- The comparator compares the input voltage to the DAC output voltage.
 - o If the input is higher than the DAC voltage, the counter counts up.
 - If the input is lower than the DAC voltage, the counter counts down.



Tracking ADC

- Conversion of 0.37V input using 0-5V ADC
- Counter starts at 0, making DAC output 0V
- Counter counts up, stepping DAC voltage up, until comparator output changes
- Counter then oscillates around input voltage value




Flash ADC

- The flash ADC is the fastest type available.
- It has one comparator per voltage step.
 - o A 4-bit ADC will have 16 comparators, and an 8-bit ADC will have 256 comparators.
- One input of all the comparators is connected to the input to be measured.
- The other input of each comparator is connected to one point in a string of resistors.
- As you move up the resistor string, each comparator trips at a higher voltage thus all comparator outputs determines the output based on which is on and which is off.

Flash ADC

GEBZE

Flash ADCs are very fast (speed depends on the comparator and logic delays), but take large area and requires more power.








Successive Approximation Converter

- SAC is similar to the tracking ADC.
- The difference is that successive approximation register performs a binary search instead of just counting up or down by one.
- An 8-bit successive approximation ADC can do a conversion in 8 clocks regardless of the input voltage.



Successive Approximation Conversion


- To do a conversion first all the DAC bits are set to
- Start with DAC's MSB (half the voltage)
- Set next input bit for DAC to 1
- Wait for DAC and comparator to stabilize
- If the DAC output (test voltage) is smaller than the input then set the current bit to , else clear the current bit to 0



https://micro.furkan.space


Successive Approximation Converter

Conversion speed is consistent and usually faster.



Successive Approximation Converter

38




40



Sample and Hold

What happens if the signal is changing while we are sampling the ADC?

- Place a low-pass filter ahead of the ADC input to tolerate for conversion time
- Place a sample-and-hold (S/H) circuit



INPUT SIGNAL INPUT SIGNAL INPUT SIGNAL OUTPUT VOLTAGE SAMPLE/HOLD CONTROL (0 = SAMPLE, 1 = HOLD)

Sample and Hold Circuit

GEBZE TEKNÍK ÜNÍVERSÍTESÍ


42

https://micro.furkan.space

BUFFER

Analog Interfacing Peripherals

- GPIO pins may have different features which includes analog paths for ADCs and DACs.
- Not all the pins have analog functionality.
- Usually port based.



STM32G0 - ADC General Features

- STM32G0 has **12-bit successive approximation** ADC. Configurable to 12, 10, 8, 6-bits.
- ADC conversion time: 0.4 us for 12-bit resolution (2.5 Msps). Lower bits result higher conv. time.
- Up to 19 multiplexed channels allowing to measure signals from 16 external and 3 internal sources.
 - $\circ V_{sense}$ internal temperature sensor
 - V_{REFINT} internal reference voltage
 - \circ V_{BAT} monitoring external V_{BAT} power supply pin



STM32G0 - ADC General Features

- A/D conversion of the various channels can be performed in single, continuous, scan or discontinuous mode.
- Has an **analog watchdog** feature that allows the application to detect if the input voltage goes outside the user-defined higher or lower thresholds
- Start of conversion can be initiated using software, or **hardware triggers** (using GPIO inputs or **Timers**)
- ADC input range $V_{SSA} \le V_{IN} \le V_{REF+}$



https://micro.furkan.space

ADC pins in STM32G031K8

- Check the Pin assignment and description table from STM32G031 datasheet (Table 12)
- Pin number and ADC number can be different
- For example PB0 can be used as ADC IN8


-	D2	14	13	14	18	PA7	I/O	FT_a		SPI1_MOSI/I2S1_SD, TIM3_CH2, TIM1_CH1N, TIM14_CH1, TIM17_CH1	ADC_IN7
5	E1	15	14	15	19	PB0	1/0	FT_ea		SPI1_NSS/I2S1_WS, TIM3_CH3, TIM1_CH2N, LPTIM1_OUT	ADC_IN8
5	E1	15	15	16	20	PB1	I/O	FT_ea	T.	TIM14_CH1, TIM3_CH4, TIM1_CH3N, LPTIM2_IN1, LPUART1_RTS_DE, EVENTOUT	ADC_IN9



46

https://micro.furkan.space

STM32G0 - ADC Block Diagram



47

STM32G0 - ADC External Triggers

- ADC can be externally using different sources.
- Configure the EXTSEL bits in the relevant register to select the source.
- For example, we can use TIM3 to trigger ADC sampling.

Tak	ole	60.	Ex	terr	nal	tr	gg	ers
-----	-----	-----	----	------	-----	----	----	-----

Name	Source	EXTSEL[2:0]
TRG0	TIM1_TRGO2	000
TRG1	TIM1_CC4	001
TRG2	TIM2_TRGO	010
TRG3	TIM3_TRGO	011
TRG4	TIM15_TRGO	100
TRG5	TIM6_TRGO	101
TRG6	Reserved	110
TRG7	EXTI11	111



STM32G0 - ADC Voltage Regulator

- ADC has a specific internal voltage regulator which must be enabled and stable before using the ADC.
- Can be enabled by setting ADVREGEN bit to 1 in CR register.
- The software need to wait for the ADC voltage regulator startup time (20 us)



49

https://micro.furkan.space

STM32G0 - ADC Calibration

- ADC has a calibration feature that removes the offset error which may vary from chip to chip due to process variations.
- Calibration is initiated by software by setting bit ADCAL=1 in the relevant register.
- Can only be initiated when ADC voltage regulator is enabled and ADC is disabled.
- ADCAL stays 1 until calibration is complete, so wait for that amount. (or EOCAL=1 in status register)
- Calibration factor is written to the CALFACT reg.



50

https://micro.furkan.space

STM32G0 - ADC Channel selection

- It is possible to convert a single channel or a sequence of channels.
- The scan sequencer can be used in two different modes:
 - Not fully configurable The order in which the channels are scanned can be defined by the channel number (forward or backward)
 - **Fully configurable** The order in which the channels are scanned can be programmed using SQx bits up to 8 channels.

STM32G0 - ADC Timings

• The elapsed time between the start of a conversion and the end of conversion is the sum of the configured sampling time plus the successive approximation time depending on the data resolution

$$t_{CONV} = t_{SMPL} + t_{SAR} = [1.5 \mid_{min} + 12.5 \mid_{12bit}] \times t_{ADC_CLK}$$

$$t_{CONV} = t_{SMPL} + t_{SAR} = 42.9 \text{ ns} \mid_{min} + 357.1 \text{ ns} \mid_{12bit} = 0.400 \text{ }\mu\text{s} \mid_{min} \text{ (for } f_{ADC_CLK} = 35 \text{ MHz)}$$

$$ADC \text{ state} = RDY \times SAMPLING CH(N) \times CONVERTING CH(N) \times SAMPLING CH(N+1) \times CH(N+1)$$

DATA N-1

52

cleared by SW



GEBZE

EOSMP

EOC

(1) t_{SMPL} depends on SMP[2:0] (2) tSAR depends on RES[2:0]




cleared

DATA N


STM32G0 - ADC EOC EOS

- It is possible to generate interrupt for both end of conversion (single channel) and end of sequence (multi-channel selection) events
- Single conversions of a sequence, software trigger:




STM32G0 - ADC Hardware Trigger

- To set a sampling time, we can setup a timer and generate trigger events to start conversions
- In single conversions, each trigger start next **conversion**
- Single conversions of a sequence, hardware trigger:



STM32G0 - ADC Hardware Trigger

- In continuous conversions, each trigger start next sequence
- Continuous conversions of a sequence, hardware trigger:



STM32G0 - ADC Setup Continuous mode

- Choose the relevant GPIO pin as Analog Input (Table 12 from stm32g031k8 datasheet)
- 2. Enable ADC Clock
- 3. Enable ADC Voltage Regulator, wait for at least 20us
- 4. Enable Calibration, wait until completion
- 5. Enable end of calibration or sequence interrupts
- 6. Configure number of bits to sample (6, 8, 10, 12)
- 7. Configure single/continuous mode
- 8. Select sampling time from SMPR register
- 9. Enable channels (for the ANx pins)
- 10. Enable ADC and wait until it is ready
- 11. Start conversion



STM32G0 - ADC Setup Trigger mode

- 1. Additionally, in ADC setup choose TRGO from EXTSEL and choose trigger edge from EXTEN.
 - a. Note that ADC should be in single mode (not continuous)
- 2. Setup relevant Timer module normally. No need for interrupts.
- 3. Choose Update mode in the MMS register for the Timer
- 4. Don't forget the NVIC stuff for ADC interrupts
- 5. Each time timer overflows, it will generate a trigger out that will trigger the ADC which in turn will interrupt when the conversion ends. (EOC)



https://micro.furkan.space