

Microprocessors

Fall 2020

2. Architecture

2. TH CHITCCTUTE

https://micro.furkan.space

Tentative Weekly Schedule

- Week x1 Introduction to Course
- Week x2 Architecture
- Week x3 Assembly Language Introduction
- Week x4 Assembly Language Memory and Control
- Week x5 Embedded C, Toolchain and Debugging
- Week x6 Interrupts
- Week x7 Timers
- Week x8 Modulation
- Week x9 Serial Communications I
- Week xA Serial Communications II
- Week xB Analog Interfacing
- Week xC Memory and DMA
- Week xD RTOS
- Week xE Wireless Communications

GEBZE TEKNIK ÜNİVERSİTESİ


2

https://micro.furkan.space

Review: Transition from Logic Design to Microprocessors

For Combinational Logic:

- **Propagation delay:** t_{pd} = max delay from $\frac{1}{A}$ input to output
- Contamination delay: t_{cd} = min delay from input to output



- In Logic Design course, we cared about timing within a clock cycle and tried to optimize what we can achieve within that clock cycle.
- In Microprocessors course, we don't care about single clock cycle, but we care about how fast we can compute and try to optimize number of clock cycles.

Review: Classes of Computers

Desktop computers

- General purpose, variety of software
- Subject to cost, performance tradeoff

Server computers

- Network based
- High capacity, performance, reliability
- Range from small servers to building sized


• Embedded computers

- Hidden as components of systems
- Strict power, performance, cost constraints







Review: General Purpose Computer



Review: Embedded System



Review: What is inside a Microcontroller?



Review: Characteristics of microprocessors

- Low power
- Fast interrupt response
- High code density
- Debug
- OS support
- Ease of use
- High software portability and reusability
- Upgrade and downgrade path
- Tool chain support
- Low cost





Let's talk about ARM...


ARM: Recently...



Apple Bet The Farm On Arm. Now NVIDIA's In Charge, Does It Stick Or Twist?

ARM: Brief history

- Acorn Computers, Ltd is founded in Cambridge, UK in 1978
- Worked on projects using 6502 processor
- Created Acorn RISC Machine (ARM1) to meet the fast growing demand in industry
- Later founded ARM Company





10

https://micro.furkan.space

ARM: Overview of Processor Families

There are three branches in ARM Cortex family cores:

- Cortex-A Application processors. Designed as fully functional computers capable of running complex operating systems.
 Commonly used in mobile phones, tablets, and laptops such as Raspberry PI, Android phones, iPhones, iPads, ...
- Cortex-R Real-time processors. Designed to be fast reacting to events. Have low interrupt latency and more deterministic in tight situations. Often used in critical systems where data interpretation is essential such as medical devices, car systems, basebands and low-level device controllers, such as hard drive controllers.
- Cortex-M Microcontroller series. Designed to be ultra-low-power and small form-factor. Runs at a way slower clock speed then A and R series. They are used in robotic systems and small consumer electronics.





ARM: Cortex-M applications


Processor	Applications
Cortex-M0, Cortex-M0+ processors	General data processing and I/O control tasks. Ultra low power applications. Upgrade/replacement for 8-bit/16-bit microcontrollers. Low-cost ASICs, ASSPs
Cortex-M1	Field Programmable Gate Array(FPGA) applications with small to medium data processing complexity. (For high-complexity data processing there are FPGAs with built-in Cortex-A processors such as Xilinx Zynq-7000 and some of the Altera Arria V SoCs and Cyclone V SoCs).
Cortex-M3	Feature-rich/high-performance/low-power microcontrollers. Light-weight DSP applications.
Cortex-M4	Feature-rich/high-performance/low-power microcontrollers. DSP applications. Applications with frequent single precision floating point operations.
Cortex-M7	Feature-rich/very high performance power microcontrollers. DSP applications. Applications with frequent single or double precision floating point operations.


GEBZE KERNIK ÜNİVERSİTESİ

13 https://micro.furkan.space

Let's talk about computer architecture...

ARM: Cortex-M Processor Family





GEBZE TEKNIK ÜNİVERSİTESİ

14

https://micro.furkan.space

Architecture vs. Microarchitecture

• Instruction Set Architecture (Architecture)

- programmer's view of a computer (memory & register)
- operations (instructions and how they work)
- execution semantics (interrupts)
- o input/output
- data types/sizes
- o ARM, x86, MIPS, SPARC, PowerPC
- o ARMv6-M Architecture Reference Manual

Microarchitecture (Organization)


- tradeoffs on how to implement ISA for some metric (speed, energy, cost)
- pipeline depth, number of pipelines, cache size, silicon area, peak power, execution ordering, bus widths, ALU widths..
- o different implementations of Intel i3, i5, i7 cores of 2010-2020

16

Same Arch & Different Microarch


AMD Phenom x4

- x86 ISA
- Quad core
- 125W
- Decode 3 Instructions/Cycle/Core
- 64 KB L1 I/D Cache
- 512 KB L2 Cache
- Out-of-order
- 2.6Ghz



Intel Atom


- x86 ISA
- Single Core
- 2W
- Decode 2 Instructions/Cycle/Core
- 32 KB L1 I, 24 KB D Cache
- 512 KB L2 Cache
- In-order
- 1.6Ghz



Different Arch & Different Microarch


AMD Phenom x4

- x86 ISA
- Quad core
- 125W
- Decode 3 Instructions/Cycle/Core
- 64 KB L1 I/D Cache
- 512 KB L2 Cache
- Out-of-order
- 2.6Ghz



IBM POWER7

- Power ISA
- Eight Core
- 200W
- Decode 6 Instructions/Cycle/Core
- 32 KB L1 I/D Cache
- 256 KB L2 Cache
- Out-of-order
- 4.25Ghz



https://micro.furkan.space



17 https://micro.furkan.space




Complexity based ISA Classification

Complex instruction set computers (CISC)

- Uses single complex instruction that can perform many operations usually requiring multiple cycles
- Usually supports varying instruction length
- $\circ \quad \text{More complex hardware, simplified compiler} \\$

Reduced instruction set computers (RISC)

- Uses simplified instructions that can use many instructions to perform an operation usually completing one instruction per cycle
- More simplified hardware, complex compiler to transform code




19

Memory Interface-Based Architecture Classification

18

There are two widely used memory interface architectures


- von Neumann uses a common bus for both data and code
- **Harvard** uses separate buses for data and code









Where do operands come and results go?




Register-Register Architecture

- Also called load-store architecture
- Register-Register architecture operands need to be in registers (or immediates)
- Special instructions are used to get and send data from / to memory. (LDR, STR)
- Common in RISC architectures.
- 2 or 3 explicitly named operands








https://micro.furkan.space

ARM Cortex MO+ Two stage pipeline




ARM Cortex MO+ Processors


- Cortex-M0+ instruction set is based on **Thumb ISA** which is built for more compact support and implements a **subset** of them.
- **Most instructions are 16 bit** (some are 32)
- 32-bit addressing support supporting **up to 4GB** of memory space
- System bus is based on AHB-Lite supporting 8-bit, 16-bit, and 32-bit data transfers.
- Peripherals can be connected to a simpler bus based on the APB protocol



ARM Cortex M0+ Simplified block diagram



ARM Cortex M0+ Typical System




ARM Cortex M0+ based microcontrollers

- ABOV Semiconductor A31G11x, A31G12x, A31G314
- Cypress PSoC 4000S, 4100S, 4100S+, 4100PS, 4700S, FM0+
- Epson S1C31W74, S1C31D01, S1C31D50
- Holtek HT32F52000
- Microchip (Atmel) SAM C2, D0, D1, D2, DA, L2, R2, R3
- NXP LPC800, LPC11E60, LPC11U60
- NXP (Freescale) Kinetis E, EA, L, M, V1, W0
- Renesas Synergy S124, Synergy S128
- Renesas RE, RE01
- Silicon Labs (Energy Micro) EFM32 Zero, Happy
- ST STM32 L0, G0

The following chips have a Cortex-M0+ as a secondary core:

- Cypress PSoC 6200 (one Cortex-M4F + one Cortex-M0+)
- ST WB (one Cortex-M4F + one Cortex-M0+)

ST Microelectronics Cortex-M portfilo



Microcontroller choice decisions

- Low Power / Energy Efficiency
 - low-power features (sleep modes)
 - small gate count (dynamic / static power)
 - technology size (leakage, voltage)
- **High Code Density**
 - smaller binary size (memory)
- Low (Interrupt) Latency
 - determinism (exact response time)
- Fase of Use
 - Development environment, debugger, software, middleware support
 - Software portability, scalability, reusability, flexibility
- Debugging support




29

https://micro.furkan.space

Operation Modes and States

ARMv6-M architecture has two operation modes and two stages with privileged and unprivileged access levels.

- Thumb state is when the processor is running a program
 - Thread mode
 - Handler mode
- **Debug state** is when the processor is halted




Regular and Special Registers

• In Cortex-M0+, there are 16 32-bit registers (13 general purpose and 3 specific use)

31

- o R0 R15 with R0-R12 being general purpose registers.
- due to size, mostly only low registers can be used with 16-bit Thumb code.
- data needs to be loaded from memory to registers to be processed (load/store)



Special use registers

- R13 Stack Pointer (SP) points to the top of the stack
 - o **POP** and **PUSH** instructions are used to access memory.
 - Banked Main (MSP) and Process Stack Pointer (PSP). Can be changed, but only one of them is visible
 - Special register access instructions MRS and MSR is used to change between them.
 - Access is 32-bits so **lowest 2 bits are always 0**.
- R14 Link Register (LR) keeps the return address of a subroutine or function call
 - Lowest bit is usually set to 1 to indicate Thumb state. Otherwise it can imply an attempt to switch the processor to ARM state which is not supported - tuhs can cause a fault.
- R15 Program Counter (PC) points to the next instruction in line
- **Lowest bit** is usually set to 1 to indicate **Thumb** state. Otherwise it can imply an attempt to switch the processor to ARM state which is not supported - thus can cause a fault. **GEBZE**



Special Registers

 xPSR - Program Status Register - holds information about program execution, exception number and the ALU flags.




PRIMASK - Interrupt Mask special Register is used to block all interrupts
 except Non-Maskable Interrupt (NMI) and the HardFault exception



 CONTROL - special register that is used to change processor mode and stack pointer



Controlling processor state with CONTROL




ALU Flags and examples

Flag	Descriptions
N (bit 31)	Set to bit[31] of the result of the executed instruction. When it is "1," the result has a negative value (when interpreted as a signed integer). When it is "0," the result has a positive value or equal zero.
Z (bit 30)	Set to "1" if the result of the executed instruction is zero. It can also be set to "1" after a compare instruction is executed if the two values are the same.
C (bit 29)	Carry flag of the result. For unsigned addition, this bit is set to "1" if an unsigned overflow occurred. For unsigned subtract operations, this bit is the inverse of the borrow output status.
V (bit 28)	Overflow of the result. For signed addition or subtraction, this bit is set to "1" if a signed overflow occurred.

Operation	Results, flags
0x70000000 + 0x70000000	Result = $0xE00000000$, N = 1, Z = 0, C = 0, V = 1
0x90000000 + 0x90000000	Result = $0x20000000$, N = 0 , Z = 0 , C = 1 , V = 1
0x80000000 + 0x80000000	Result = $0x000000000$, N = 0 , Z = 1 , C = 1 , V = 1
$0 \times 00001234 - 0 \times 00001000$	Result = $0x00000234$, N = 0, Z = 0, C = 1, V = 0
$0 \times 000000004 - 0 \times 000000005$	Result = $0xFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF$
0xFFFFFFFF - 0xFFFFFFC	Result = $0x00000003$, N = 0, Z = 0, C = 1, V = 0
0x80000005 - 0x80000004	Result = $0x00000001$, N = 0, Z = 0, C = 1, V = 0
0x70000000 - 0xF0000000	Result = $0x80000000$, N = 1, Z = 0, C = 0, V = 1
0xA0000000 - 0xA0000000	Result = $0x000000000$, N = 0 , Z = 1 , C = 1 , V = 0

Memory System

- Cortex-M processors have 4 GB of memory address space.
- Memory space is architecturally defined into a number of regions
- As a result all the Cortex-M devices have the same programming model for interrupt control and debug.






GEBZE

Stack Memory Operation

- Stack memory is a memory usage mechanism that allows the system memory to be used as temporary data storage that behaves as a first-in-last-out (FILO) buffer.
- Content can be added with PUSH instruction and can be acquired using POP instruction
- Usually located at the top of SRAM, and **grows downwards** meaning if data is added it gets **filled toward lower addresses** (**full-descending**)
- Stack Pointer shows the top of the stack






37 https://micro.furkan.space

Stack Memory Operation - PUSH

- In case of a PUSH operation: (PUSH {R1})
 - First Stack Pointer is decremented by 4
 - Then, the register data is written to the address that the Stack Pointer points to.






38 https://micro.furkan.space

Stack Memory Operation - POP

- In case of a POP operation: (POP {R2})
 - First, the memory content that the Stack Pointer points to is written to the Register in the instruction
 - Then, Stack pointer is incremented by 4.



Exceptions and Interrupts

- Exceptions are events that cause changes to program control
- the processor suspends the current executing task and executes a part of the program code called the **exception** handler
- after the handler is completed, the processor resumes the normal program execution
- **Interrupts** are a **subset** of exceptions commonly referred as **IRO**.
 - Cortex-M0+ processors support up to 32 external interrupts
- The exception handlers for interrupt events are commonly called **Interrupt Service Routines (ISRs)**.





Exception numbers and priority

- Each exception has an exception number. This number is reflected in registers including xPSR and used to define the exception vector address.
- Exception numbers **1-16** are common in all M series, IRQ number varies based on manufacturer.
- Except Reset, NMI and HardFault all other exceptions have a programmable priority level.

Exception type	Exception number	Description
Reset	1	Power on reset or system reset.
NMI	2	Non-Maskable interrupt—highest priority exception that cannot be disabled. For safety critical events.
HardFault	3	For fault handling-activated when a system error is detected.
SVCall	11	Supervisor call—activated when SVC instruction is executed. Primarily for OS applications.
PendSV	14	Pendable service (system) call—activate by writing to an interrupt control and status register. Primarily for OS applications.
SysTick	15	System Tick timer exception — typically used by an OS for a regular system tick exception. The system tick timer (SysTick) is an optional timer unit inside the Cortex®-M processor.
IRQ0 to IRQ31 ^b	16-47	Interrupts—can be from external sources or from on-chip peripherals.



41 https://micro.furkan.space

Nested Vectored Interrupt Controller


- Used for **prioritizing** the interrupt requests and handling other exceptions
- The interrupt management function is controlled by registers in the NVIC located within the System Control Space (SCS)
- NVIC supports:
 - Flexible interrupt management
 - Nested interrupt support
 - Vectored exception entry
 - Interrupt masking



42 https://micro.furkan.space

Vector Table


- The beginning of the program image has the **vector table** which contains the starting address of exceptions.
- The size of the vector table depends on the number of interrupts implemented.
- First two addresses are important for reset operation. The next two are important for faulty recovery.



43

Reset Sequence

- We have already seen what happens after reset in terms of software routines.
- First address in the vector table indicates the stack pointer value. (SP is set)
- Second address in the vector table is the Reset Handler. (PC is set)
- Then PC makes the jump to the pointing address.




44



_{pace} G

Example Stack Pointer and PC init



Let's talk about software design...




45

https://micro.furkan.space

Software Program Flows - Polling

Polling (also called **super-loop**)


- uses one big loop, and completes tasks in order
- As tasks get bulkier or tasks increase in number, the execution frequency of tasks decreases



Interrupt Driven


Interrupt driven approach uses interrupts that will handle predefined requests, or incoming events

- Otherwise can sleep to reduce power consumption
- Different priorities can be set to interrupts ensuring higher priority routine gets executed no matter what.



GEBZE

Hybrid with Polling and Interrupt Driven



Handling Concurrent Processes

In some cases an application process could take a significant amount of time to complete

• e.g if A takes a long time, B and C will not be able to respond to requests fast enough, and even might not be able to run at all (**starve**).

Two solutions:


- Break down a long processing task to a sequence of states managing with an FSM. Each time the process is processed, only one state is executed
- Use a Real-Time Operating System (**RTOS**) to manage multiple tasks.




50

https://micro.furkan.space

Handling Concurrent Processes - Solutions





RTOS

Programming Language Decisions

Language	Pros and cons
C/C++	Pros:
95	• easy to learn
	• portable
	easy handling of complex data structures
	Cons:
	 limited/no direct access to core register and stack
	 no direct control over instruction sequence generate
	no direct control over stack usage
Assembly	Pros:
	· allows direct control to each instruction step and all memory operations
	 allows direct access to instructions that cannot be generated with C
	Cons:
	takes longer time to learn
	difficult to manage data structure
	• less portable (syntax of assembly language in different tool chains can be different)

We will get ourselves familiarized with Assembly for the first couple weeks, then transition into C.





Inside a program image

When we compile code for the target platform, there are different components:

- vector table contains the starting address of each exception and interrupt
- reset handler some software and hardware initialization routines, clock initialization
- startup code initialization of data and calling of main() function.
- application code your code
- runtime library functions any functions that you didn't implement
- other data other global and static variables




53

https://micro.furkan.space

Programming Microcontrollers

A simple reset circuitry looks like this.




54



<u>htt</u>

https://micro.furkan.space


Role of decoupling capacitors



55

Microcontroller Startup Sequence

- Most modern microcontrollers hold compiled program in on-chip flash memory.
- After the processor is reset, it obtains the initial stack pointer value and reset address from vector table.
- Executes the reset handler in startup code.








Bootloader

- A piece of software burned at the beginning of memory that initializes any selected peripherals and boots up the actual code.
- Before booting up the actual code, it offers a way to re-flash the code with a new one without the need for a debugger.
- It can be through **serial port**, **usb** or any other communication method using wired or wireless channels.

Typical program generation flow





57

https://micro.furkan.space

https://micro.furkan.space



58


https://micro.furkan.space

Programming / Debugging

- After generating the binary (elf / bin) we can program the board using a **debugger** (or bootloader if present)
 - Usually are more expensive and has debugging capabilities.
- Program can be debugged using an in-circuit

debugger.

Nucleo G031K8 board has built-in debugger on the back. No additional hardware required



This week

- Find / order hardware components
- Install VisUAL / CubeIDE + G0
 - import a project and compile the program. Will send out info later this week.
- Read Chapter 2, 3 and 4 from Yiu
- Assignment 2





Links

- https://en.wikipedia.org/wiki/ARM_Cortex-M
- https://www.st.com/en/microcontrollers-microprocessors/stm32-32-bit-arm-cortex-mcus.html

61

- https://www.arm.com/products/silicon-ip-cpu
- https://developer.arm.com/ip-products/processors/cortex-m
- https://developer.arm.com/documentation/ddi0419/c
- https://www.simetrix.co.uk/



https://micro.furkan.space