
# 外觀與接線:

如下圖




- 1.左上方是電源(右正左負), 請維持 3.6V 供電。
- 2.右上接腳為 UART 與 STLINK




左到右依序是 GND,TX,RX, SWDIO,SWCLK 3.下方是測試接腳 左到右依序是 GND,Port1,Port2,Port3

# STR 程式執行

- 1. 正常運作
  - I. 啟動後,藍色 LED 會閃爍,表示正在傳輸,
  - II. 當 LED 熄滅,表示進入睡眠
  - III. 將 Port 接地,LED 會閃爍,表示正在執行,執行完畢後,LED 將會熄滅並且 進入睡眠等待
- 2. 測試流程



II. 打開 Macro



載入 CheckConsoleLog\_STR\_V51\_test.TTL



會出現一個對話框



#### Ⅲ. 上電

```
COM5 - TeraTerm VT

File Edit Setup Control Window Help

SmartTxr_IOT1_20220705A
System power on
Init RTC base
Init RTC date/time/alarm
>>> Current ppio state = 00000111
>>> Current ppio state = 0 00000111
>>> Current PVD state = 0
MNB303R Power on
*MATREADY: 1
+CFUN: 1
+CPIN: READY
```

## IV. 等待睡眠



#### V. 測試 Port1



## i. 當測試完成後會進入睡眠 並且顯示如下



#### VI. 測試 Port2 到進入睡眠

```
File Edit Setup Control Window Help

+EMQCERT: to be continued
OK

AT-EMQCERT: 0, 3358, 158, 65644843717178567a735a794872395453446a2b4357694b517966536e5a335334434d47764347464e2b35657077
3d3d3da2d2d2d2d2d2d454e44205253412050524956415445204b45592d2d2d2d2d2d0a

OK

AT-EMQNEW-"iot1.wavein.com.tw","18883",60000,1536

+EMQNEW: 0

OK

AT-EMQCON=0,3,"358826100845573",60,1,0

OK

C<= MQTT publish Event (172,200) {Event/358826100845573 00,07,05,00,358826100845573,466978000484087,18E2667,-70,02,0
0,2022/08/10_10:48:330MT+03
0303034388349038372c314245923636372c2d37302c30372c30352c30302c3335383332363130303834353537332c3436363937383
030303438383938372c314245923636372c2d37302c30322c30302c3233538332363130303834353537332c3436363937383
030303438383938372c314245923636372c2d37302c30322c30302c323353833333474d542b38"

OK

AT-EMQUBBe, "Request/358826100845573", 1

OK

AT-EMQSUB-0, "Request/358826100845573", 1

OK

AT-EMQSUB-0, "Request/358826100845573,", 1

OK

AT-EMQSUB-0, "Request/358826100845573,", 1

OK


AT-EMQSUB-0, "Request/358826100845573,", 1

OK

AT-EMDOISCON=0

O
```

#### VII. 測試 Port3



```
COM5 - Tera Term VT
                                                                                                             SMART Transmit Reporter
   Edit Setup Control Window Help
                                                          Checking was completed.
+EMQCERT: to be continued
AT+EMQNEW="iot1.wavein.com.tw","18883",60000,1536
+EMQNEW: 0
AT+EMQCON=0,3,"358826100845573",60,1,0
on
>>> state.rst=0, flag.latest=1
<== MQTT publish Event (172,200) {Event/358826100845573 00,07,03,00,358826100845573,466978000484087,1BE2667,-70,01,0
0,2022/08/10_10:54:08GMT+8}
AT+EMQPUB=0,"Event/358826100845573",2,0,0,172,"30302c30372c30332c30302c3335383832363130303834353537332c3436363937383
AT+EMQSUB=0,"Request/358826100845573/#",1
on
>>> Request: config=0, events=0, recheck=1
AT+EMQUNSUB=0,"Request/358826100845573/#",1
AT+EMQDISCON=0
AT+CFUN=0
AT+CFUN=1
NNB303R Power off
>>> Will reboot and enter stop mode!!
SmartTxr_IOT1_20220705A
System software reset
Init RTC base
>>> Entering stop mode...zzzZZ
```

VIII. 當 Port3 測試到睡著後會出現顯示"All strings were found!! [PASS]"的對話框

這就代表順利結束

否則會一直停在有問題的那個區塊

