wire connect table

Arduino UNO	v5.0	Module		
	G	G		
	V	V+	Line tracking module #1	
D11	S11	S		
	G	G		
	V	V+	Line tracking module #2	
D4	S4	S		
	G	G		
	V	V+	Line tracking module #3	
D2	S2	S		
	G			
	V		SG90	
D3	S3			
D10	S10	ENA		
D9	S9	N1	L298N(Motor driver board)	
D8	S8	N2		
D 7	S7	N3		
D6	S6	N4		
D5	S5	ENB		
	G	G		
	V	R	Infrared receicer module	
D12	S12	Y		
	V	Vcc		
A5	A5	Trlg	Ultrasonic Sensor module	
A4	A4	Echo		
	G	Gnd		
	+	VCC		
	_	GND	D1. () 1 1 1	
DO (RX)	RX	TXD	Bluetooth module	
D1 (TX)	TX	RXD		

L298N board	Motor		Control Pin
OUT1	Brack wire	Right back motor	N1, N2
OUT2	Red wire	Might back motor	
OUT1	Brack wire	Dight front motor	
OUT2	Red wire	Right front motor	
OUT3	Brack wire	Left front motor	N3, N4
OUT4	Red wire	Lert Hollt motor	
OUT3	Brack wire	Left back motor	
OUT4	Red wire	Left back motor	

PS:1.V, +, Vcc, VCC, V+ connect to UNO board +5v 2.GND,G, connect to UNO board GND 3.the fill color is the wire color

4.the uno pin A0~A3 have never use in the car