IN CASE OF EMERGENCY.

If there is a power failure, check and reset the R.C.D's [Box on wall].

If this does not restore power, you will have to enter the Club, enter the Ladies Toilets and open the Cleaner's Cupboard[door straight in front of you, key on hook, right hand top of door]. Reset any tripped R.C.D's.

Computer will need restarting, button on top of hard drive. After home page comes up, click on bottom left hand corner and then click on Race Station. When a password is requested, enter racestation, all one word, lower case.

If this fails, there is an Atomic Clock on the wall to enable the race to continue[lap times etc.] and a air horn on the flag shelves.

The two V.H.F. radio's are battery powered and should operate as normal.