Installing the Cantaloupe G9



ePort Serial number and Customer Service phone number are on every box



What's in the kit



What's in the kit



G9 Controller and cable connectors



Aux, Antenna and DEX receptacles



Standard antenna and connector




Card Reader mounting screw holes, cable and connector




Choose a suitable location to mount the G9 Controller

- Carefully choose a location inside the vendor door or cabinet to mount the G9
 Controller. Make sure the G9 MDB, DEX and Serial cables will be able to reach their
 connection points to the vendor MDB cables, DEX port and the Card Reader cable.
 Make sure the cabling is not going to get pinched by or interfere with moving parts
 in the vendor.
- Also make sure you will be able to see the service buttons and LEDs on the G9
 Controller and manipulate the "Service" "Fill/DEX" "END" and signal test
 buttons when needed. You will also need to access the "Hand Held DEX"
 receptacle if you use hand held DEX devices on your equipment.
- When locating the antenna, avoid positioning it near the vendor control board.
- Locate the antenna on top of the vendor door or cabinet if possible. If you need to locate the antenna inside the vendor, try to position it directly behind the Lexxan or glass front. Do not locate the antenna where it will be surrounded on all sides by metal as this will greatly reduce signal quality.
- DO NOT coil the antenna wire. This will also reduce signal quality. This wire should be stretched out as best possible and secured so it will not be pinched or cut.

Power down the machine and Locate the MDB Bus connectors between the machine controller and bill acceptor. Then separate the connectors.




Connect to the MDB bus with the two 6 position connectors of the G9 MDB cable




Antenna connection to G9 Controller



Card Reader cable connection to G9 Controller



DEX Connection to VMC





NOTE: The vendor DEX port will be found in different locations according to vendor make/model. Look for the standard female phono type receptacle.

The card reader can be installed with a spacer or without depending on the vendor. Be sure to use the short screws for mounting without the spacer. The long screws are for use <u>only</u> with a spacer.






Card reader mounted in second cutout



Inside view of Card Reader with flange plate



Surface mounted Card Reader using drilling template.





Temporarily remove bill acceptor before drilling holes. Reinstall after mounting Card Reader

Start up / LED activity and reader displays



Green LED will light and then flash



First card reader display

Start up / LED activity and reader displays continued





Blue and Green LEDs will blink

Device serial number and firmware rev displayed on reader.

Start up / LED activity and reader displays continued



COMPLETE

Blue and Green LEDs will blink

MEID and IP Address displayed

Swipe A Card. Unit is ready for business





G9 - Green LED Blinking

Card Reader Welcome Message

Authorizing a card



Authorizing



Card is approved - ready to vend

User is prompted through the vend process





In multi-vend mode the customer is asked to make another selection or press "END"





Once the END (Complete) button is pressed, the purchased items are totaled

Thank You Message is displayed



Push this button to perform Signal Test



LEDs will light according to signal strength. See next slide for LED Chart.



Numeric signal strength reading will display on card reader


RSSI (CSQ) LED Chart


RSSI	BER	Signal Evaluation	LEDs	Comment:
0 to 7	0 or x	Very Poor	NO LED	
8 to 9	1 to 19	Poor	0	Short messages (auth, scheduled call-ins) may work but OTA would fail.
	0	1 001	•	
10 to 14	1 to 19	Good	•	ePort has worked well in the past.
	0	Good	•	
15 to 19	1 to 19	Excellent	•	
	0	Excellent	• • •	
20 to 48	1 to 19	BEST	• • •	
	0		•••	
>48	>20		0	It almost never happens.

AMS Vendors



National Merchant





Card reader is inserted in POS window. Card reader kit # 1815084 is available from Crane to mount the reader

HVV Vendor & DN5800 with optional install kits





Pepsi HVV HVV card reader kit Dixie 5800 DN5800 Card Reader kit

High gain antenna mounting on DN5800





You will need to trim the metal lip above the door to provide clearance for the antenna

Royal 500 with Card Reader Kit & High Gain Antenna



G9 LED MATRIX for basic troubleshooting

Red LED	Yellow LED	Green LED	Blue LED	
		0		In service – one second pulses. (Heartbeat)
0				Momentary Device File System transfers. (quick blink when saving)
		•	•	Establishing a Cell Connection. (ACTIVATED)
	•			Pending transaction or Settlement file.
		•		Initializing.
			•	Communications for Port 1 only. (not shown when an ERROR)
•	0			Disabled by VMC or no communications to VMC.
•	O _x 2			MDB busy or ReSetting

O = Blinking

x2 = number of blinks

= On solid