CFD on HPC – OpenFOAM

02 – Basics and Meshing



Aleksander GRM – December, 2024

Cases review

OpenFOAM mesh

Mesh elements

BlockMesh

Introduction

BlockMesh - Examples

GMSH introduction

Introduction

GMSH – Examples

Turbulent Flow Modelling

Why do we need turbulent models?

Turbulence modelling

Turbulence models in OpenFOAM

Show case in OpenFOAM

Cases review

- ► BlockMesh introduction
- ► GMSH introduction
- ► Advanced cavity_with_hole show case study
 - **BlockMesh** mesh: steady and transient case (turbulent $k \omega$ SST models)
 - ▶ GMSH mesh: steady and transient case (turbulent $k \omega$ SST models)

OpenFOAM mesh



By default OpenFOAM defines a mesh of **arbitrary polyhedral cells** in *3D*, bounded by **arbitrary polygonal faces**, i.e. the cells can have an unlimited number of faces where, for each face, there is no limit on the number of edges nor any restriction on its alignment. A mesh with this general structure is known in OpenFOAM as a **polyMesh**. This type of mesh offers great freedom in mesh generation and manipulation in particular when the geometry of the domain is complex or changes over time.

Basic mesh elements

- ► Point
- ► Face
- ► Cell
- ► Boundary

(Detailed mesh description @ cfd.direkt)



A point is a location in 3-D space, defined by a vector in units of metres (m). The points are compiled into a list and each point is referred to by a label, which represents its position in the list, starting from zero.


The point list cannot contain two different points at an exactly identical position nor any point that is not part at least one face.

```
FoamFile
 2
     format
                   ascii;
 3
     class
                   vectorField;
     object
                   points;
 6
 8
 9
   21812
   (-17.5492 \ 0.306481 \ 0)
   (-17.5472 \ 0.397851 \ 0)
   (-17.5391 \ 0.49775 \ 0)
   (-17.5189 \ 0.60624 \ 0)
   (-17.4861 \ 0.723342 \ 0)
17 . . .
18
```





- ▶ face is an ordered list of points
- each two neighbouring points are connected by an edge
- ► direction of the face normal vector is defined by the right-hand rule
- ▶ there are two types of face
 - ► Internal faces
 - ► Boundary faces



```
FoamFile
    format
             ascii;
   class
            faceList;
    object
           faces;
9 43066
  4(156 0 78 235)
12 4(157 236 79 1)
13 4(156 235 236 157)
14 4(158 237 80 2)
15 . . .
16
```



A cell is a list of faces in arbitrary order. Cells must have the properties listed below.

- ► The cells must be **contiguous**, i.e. completely cover the computational domain and must not overlap one another.
- ► Every cell must be **closed geometrically**, such that when all face area vectors are oriented to point outwards of the cell, their sum should equal the zero vector to machine accuracy;
- ► Every cell must be **closed topologically** such that all the edges in a cell are used by exactly two faces of the cell in question.

```
FoamFile
2
      format
                   ascii;
3
      class
                   cellList;
      object
                   cells:
5
8
 10720
 6(0 1 21626 21627 2 21548)
```

```
12 6(1 3 21628 21629 4 21549)
  6(3 5 21630 21631 6 21550)
14 ...
15
```



- ▶ **points**: a list of vectors describing the cell vertices, where the first vector in the list represents vertex 0, the second vector represents vertex 1, etc. ;
- ▶ faces: a list of faces, each face being a list of indices to vertices in the points list, where again, the first entry in the list represents face 0, etc.;
- ▶ owner: a list of owner cell labels, the index of entry relating directly to the index of the face, so that the first entry in the list is the owner label for face 0, the second entry is the owner label for face 1, etc;
- ▶ neighbour: a list of neighbour cell labels;
- **boundary**: a list of patches, containing a dictionary entry for each patch, declared using the patch name

We will follow the text in cfd.direkt web page, explaining:

- ► geometry boundaries
- ▶ different types of standard boundary conditions

OpenFOAM v10 User Guide: 5.2 Boundaries

$\operatorname{BlockMesh}$



The **blockMesh** mesh generator is generator of **structured mesh**. In most of the cases this is most desiderated type of mesh.

- ► The blockMesh utility creates parametric meshes with grading and curved edges.
- ▶ The mesh is generated from a dictionary file named blockMeshDict located in the system (or constant/polyMesh) directory of a case. blockMesh reads this dictionary, generates the mesh and writes out the mesh data to points and faces, cells and boundary files in the same directory.
- ▶ The principle behind blockMesh is to decompose the domain geometry into a set of 1 or more three dimensional, hexahedral blocks. Edges of the blocks can be straight lines, arcs or splines. The mesh is ostensibly specified as a number of cells in each direction of the block, sufficient information for blockMesh to generate the mesh data.

We shall continue **BlockMesh** learning over the web UserGuide @ OpenFoam.org

5.4 BlockMesh @ cfd.direct

Folder: day-02/01_blockMesh

- ► show the **cavity** example.
- ► show the **cavity_with_hole** example.





To be able to run advanced GMSH examples we need to set up Python environment

```
1. load module python:
   $> ml av python (check target version)
   $> ml python-version
4
 2. Create new env:
   $> pvthon3 -m venv local
 3. Activate new env:
   $> source local/bin/activate
 4. Install new packages (active env local):
   $(local)> pip install numpy scipy sympy matplotlib gmsh
```

To use Python environment we need only to load it

We shall continue \mathbf{GMSH} description/learning over the web UserGuide @ gmsh.info

 $User\ Guide-vLatest@\ gmsh.info$

Folder: day-02/02_GMSH

- ► show the **cavity** example.
- ► show the **cavity_with_hole** example.

Emphasise how GMSH mesh is converted to OpenFOAM mesh!

Turbulent Flow Modelling

Most of engineering CFD problems are in turbulent regime!


ightharpoonup external flow: Re > 500,000 (slender bodies), Re > 20,000 (obstacles)

▶ internal flow: Re > 2,300

Reynolds number Re

$$Re = \frac{UL}{\nu}, \quad \nu = \frac{R}{\mu}$$

- ightharpoonup U: problem undisturbed flow velocity magnitude,
- ightharpoonup L: problem length scale,
- $\blacktriangleright \mu$: dynamic viscosity,
- $\triangleright \rho$: density
- $\triangleright \nu$: kinematic viscosity.





Wind tunnel test of new tennis ball.

(This we will try to solve in 2D!)

Wake turbulence behind individual wind turbines

"Turbulence is the most important unresolved problem of classical physics"

Richard Feynman

"Turbulence was probably invented by the devil on the seventh day of creation when the good lord was not looking"

Peter Bradshaw

"Turbulence is the graveyard of theories"

Hans W. Liepmann




- Most natural and engineering flows are turbulent, hence the necessity of modelling turbulence.
- ▶ The goal of turbulence modelling is to develop equations that predict the **time averaged** velocity, pressure, temperature fields without calculating the complete turbulent flow pattern as a function of time.
- ► Turbulence can be wall bounded or free shear. Depending on what you want to simulate, you will need to choose an appropriate turbulence model.
- ▶ There is no universal turbulence model, hence you need to know the capabilities and limitations of the turbulence models.
- Due to the multi-scale and unsteady nature of turbulence, modelling it is not an easy task.
- ► Simulating turbulent flows in any general CFD solver (e.g., OpenFOAM, SU2, Fluent, CFX, Star-CCM+) requires selecting a turbulence model, providing initial conditions and boundary conditions for the closure equations of the turbulent model, selecting a near-wall modelling treatment, and choosing runtime parameters and numerics.

What happens when we increase the Reynolds number? 23/42


Creeping flow (no separation) Steady flow	Re < 5
A pair of stable vortices in the wake Steady flow	5 < Re < 40 - 46
Laminar vortex street (Von Karman street) Unsteady flow	40 - 46 < Re < 150
Laminar boundary layer up to the separation point, turbulent wake Unsteady flow	150 < Re < 300 Transition to turbulence 300 < Re < 3 x 10 ⁵
Boundary layer transition to turbulent Unsteady flow	$3 \times 10^5 < \text{Re} < 3 \times 10^6$
Turbulent vortex street, but the wake is narrower than in the laminar case Unsteady flow	3 x 10 ⁶ > Re

- Easy to simulate
- Steady
- Relatively easy to simulate.
- It becomes more challenging when the boundary layer transition to turbulent
- Unsteady
- Challenging to simulate
- Unsteady






- a laminar boundary layer starts to form at the leading edge.
- ▶ as the flow proceeds further downstream, large shear stresses and velocity gradient develop within the boundary layer. At one point the flow becomes turbulent.
- ▶ the turbulent motion increases the mixing and the boundary layer mixing.
- ▶ what is happening in the transition region is not well understood. The flow can become laminar again or can become turbulent.
- ▶ as for the pipe flow, the velocity profiles in the laminar and turbulent regions are different.



The boundary layer explanation!





LoW is the cornerstone law for the boundary layer mesh design!

 $\begin{array}{c} Law \ of \ the \ wall \\ (\textbf{LoW}) \end{array}$

$$u^+ = f(y^+)$$

Non-dimensional velocity

$$u^+ = \frac{u}{u_\tau}$$

Non-dimensional y scale

$$y^+ = \frac{y \, u_\tau}{\nu}$$



► Viscous sublayer

- ► The viscous sublayer, refers to the region of the inner-region of the boundary layer, very close to the wall and where the flow is *laminar*.
- ▶ In this region the flow mean velocity can be described using a simple analytic function.
- ► The viscous sublayer law, is stated as follows

$$u^+ = y^+$$

► Remember, this equation is only valid in the viscous sublayer, where the flow is laminar and viscous effect are very strong, therefore,

$$\tau_{\text{wall}} = \mu \frac{\partial u}{\partial y}$$

► According to this law, the behaviour of the mean velocity is linear in this region.



► Logarithmic law or log-law

- ▶ The logarithmic law, refers to the region of the inner-region of the boundary layer that can be described using a simple analytic function in the form of a logarithmic equation.
- ► This is one of the most famous empirically determined relationships in turbulent flows *near solid boundaries*.
- ▶ Measurements show that, for both **internal** and **external** flows, the stream-wise velocity in the flow near the wall varies logarithmically with distance from the surface.
- ► The log-law, is stated as follows,

$$u^+ = \frac{1}{\kappa} \log y^+ + C^+$$
, the most common values $\kappa = 0.41$, $C^+ = 5.0$

- \blacktriangleright Reported values for the constant C^+ can go anywhere from 4.5 to 5.5.
- \blacktriangleright Reported values of the Karman constant κ can go anywhere from 0.36 to 0.42.



▶ Viscous sublayer – The viscous sublayer law is valid for values of y^+ ranging from,

$$y^{+} < 5$$

▶ Buffer layer – The buffer layer is enclosed in the following range of y^+ values,

$$5 < y^+ < 30$$

- ► Logarithmic law layer
 - \blacktriangleright The logarithmic law or log-law is valid for values of y^+ ranging from,

$$30 < y^+ < 300$$

► For practical purposes in CFD $30 < y^+ < 600$



► Needed parameters

to find first near wall cell height

- ▶ U_{∞} : free stream velocity in [m/s]
- L: problem length scale in [m]
 ρ: fluid density [kg/m³]
- μ: fluid density [kg/m]
 μ: fluid dynamic viscosity [Pas]
- \triangleright y^+ : layer resolution parameter

► Calculation steps

► Kinematic viscosity [m²/s]

$$\nu = \frac{\mu}{\rho}$$

► Reynolds number

$$Re = \frac{U_{\infty} \; L}{\nu}$$

Friction coefficient

$$C_f = \left(2 \log_{10}(Re) - 0.65\right)^{-2.3}$$

► Wall shear stress

$$au_w = \mathit{C}_f \, rac{1}{2} \,
ho \, \mathit{U}_{\infty}^2$$

► Friction velocity

$$U_{\tau} = \sqrt{\frac{\tau_w}{\rho}}$$

► Near wall layer thickness

$$y = h_1 = \frac{y^+ \, \mu}{\rho \, U_\tau}$$



► Viscous sublayer

- ▶ if there is flow separation
- ▶ if using laminar flow model (need to resolve viscous sublayer)
- first near wall cell height h_1 is based on $y^+ = 1$
- ▶ needed 5-10 layers with inflation scaling factor $\alpha = 1.2$


► Logarithmic law layer


- ▶ not needed to resolve viscous sublayer
- use of wall function in turbulent model $(k \omega SST)$
- first near wall cell height h_1 is based on $y^+ \approx 30$
- ightharpoonup needed N layers with scaling factor $\alpha = 1.2$
- \triangleright N can be computed using boundary layer thickness information δ

$$\delta = H = 0.37 L Re^{-1/5}, \quad N = 1 + \frac{\log\left(1 - \frac{H}{h_1}(1 - \alpha)\right)}{\log \alpha}$$

where $\alpha = 1.2$ is inflation factor, h_1 thickness of the first near wall layer, found on the previous slide.











Wall modeling mesh Average y+ approximately 60


Wall resolving mesh Average y+ approximately 1


	Wall modeling mesh	Wall resolving mesh
Number of cells	57 853 037	111 137 673











Wall resolving mesh Average y⁺ approximately 1


	Wall modeling mesh	Wall resolving mesh
Number of cells	6 613 049	11 149 266



Folder: tools and literature/mesh calculator

- ► mesh_size_calculator.ipynb
 - \rightarrow calculates the boundary layer mesh parameters.
- ► k_omega_initial_conditions.ipynb
 - \rightarrow calculates the initial values for k and ω OpenFOAM fields.


Files *.ipynb are interactive python notebooks, used in Jupyter (jupyter.org)




Increasing computational cost

Increasing modelling and complexity mathematical







RANS

LES - Instantaneous field

RANS/URANS	DES/LES	DNS
Solve the time-average NSE. All turbulent spatial scales are modeled. Many models are available. One equation models, two equation models, Reynolds stress models, transition models, and so on. This is the most widely approach for industrial flows. Unsteady RANS (URANS), use the same equations as the RANS but with the transient term retained. It can be used in 2D and 3D cases.	Solve the filtered unsteady NSE. Sub-grid scales (SGS) are filtered, grid scales (GS) are resolved. Aim at resolving the temporal scales, hence requires small time-steps. For most industrial applications, it is computational expensive. However, thanks to the current advances in parallel and scientific computing it is becoming affordable. Many models are available. It is intrinsically 3D and asymmetric.	Solves the unsteady NSE with no models involved (laminar NSE). Solves all spatial and temporal scales; hence, requires extremely fine meshes and small time-steps. No modeling is required. It is extremely computational expensive. Not practical for industrial flows. It is intrinsically 3D and asymmetric.

- ► RANS: used to mode *steady* turbulent flow
 - $\rightarrow k \omega$ SST model (in **OF** under RAS kOmegaSST)
- ▶ URANS: used to model *transient* turbulent flow
 - $ightarrow k \omega$ SST-SAS model (in **OF** under RAS kOmegaSSTSAS)

 $k - \omega$ SST model is considered to be the most **reliable** turbulent model in RANS family!

RANS and URANS family of turbulent models do time window solution averaging! The job is to smear out vortices and hide the vortex energy in turbulent viscosity ν_T .

File: constant/transportProperties



File: constant/turbulenceProperties

```
// *** laminar model ***
  //simulationType laminar;
3
  // ** RAS turbulent model ***
  simulationType RAS;
6
7 RAS
8
      RASModel
                        kOmegaSST;
9
      turbulence
                        on;
      printCoeffs
                        on;
11
12 }
```



File: constant/turbulenceProperties

```
// *** laminar model ***
   //simulationType laminar:
   // ** RAS turbulent model ***
   simulationType RAS:
   RAS
 8
                        kOmegaSSTSAS;
9
       RASModel.
       turbulence
                        on:
       printCoeffs
                        on:
12
13
       delta
                        vanDriest:
```

```
vanDriestCoeffs
16
17
                             cubeRootVol:
            delta
18
            cubeRootVolCoeffs
19
20
                deltaCoeff
                                  1:
21
23
            smoothCoeffs
24
25
                delta
                                  cubeRootVol:
26
                cubeRootVolCoeffs
27
                     deltaCoeff
                                      1:
30
31
                maxDeltaRatio
                                  1.1:
32
33
34
            Aplus
                             26:
35
            Cdelta
                             0.158:
36
37
38
```



To realistically model a given problem, it is important to define the turbulence intensity at the inlets. Here are a few examples of common estimations of the incoming turbulence intensity:

- ▶ **High-turbulence**: (between 5% and 20%): Cases with high velocity flow inside complex geometries. Examples: heat exchangers, flow in rotating machinery like fans, engines, etc.
- ▶ Medium-turbulence (between 1% and 5%): Flow in not-so-complex geometries or low speed flows. Examples: flow in large pipes, ventilation flows, etc.
- ▶ Low-turbulence (well below 1%): Cases with fluids that stand still or highly viscous fluids, very high-quality wind tunnels. Examples: external flow across cars, submarines, aircraft, etc.

Folder: day-02/03_cavity_with_hole

- ▶ Block Mesh mesh model case:
 - ▶ steady case: use of $k \omega$ SST turbulent model
 - \blacktriangleright transient case: use of $k-\omega$ SST-SAS turbulent model
- ► **GMSH** mesh model case:
 - **b** steady case: use of $k-\omega$ SST turbulent model
 - \blacktriangleright transient case: use of $k-\omega$ SST-SAS turbulent model





Thank you for attention!

