SERVO MOTORS - NORMAL: Has Range 180° * They are Low powered po motors. * Can be abjectly connected to andumo for Supply (Not recommended if multiple motors are * USECASES: - Twining & positioning applicating · Ey: Torin Your CCTV Comera. x Maximum of 8 servomotors can be connected CONNECTION (a) BLACK = GND RED - SV WHITE = PWM o "Servo.h" library is used to override Servo myservo) my Servo. attach (PINL PWM); my sono. write (value); Value = absolute positioning

Continous Servo motors

* Can complete fell

* used as wheel where movement have to be precise.

· Servo. write (value)

Value is speed of rotation (0-130)

Value = 90 (REST)
Value = 91-180 (Robote Clockwise Speed


Value : 0 - 90 (Rotate anticlokuise

* The Resting Value (90) have to be Calibrated by adjusting the potentiometer in the Servo motor.

Address changeled

**Can Connect 16- Servo motors

or any device required pury



* PWM Resolute 15 12-bit
$$2^{n} = 40\%$$

[as opposed to $10-bit$)

 $2^{n} = 1024$

* Each Serve motor pin is attached to 220 Se Coverent Cimiting session.

Driver! Adafrat_PWMSenvoDriven.h