

L=FL J2=FR J3=BR J4=BL corner sensors.
pairing: J1+J3 -> SIG_POS, J2+J4 -> SIG_NEG.
kit's wiring diagram - swap if reading is inverted/flat.

J6 pin order (GND,DT,SCK,VCC) is a common HX711 module layout -
CONFIRM against your specific module's silkscreen before wiring/routing.

J7 = RJ11 jack to in-keezer hub.
Pin1=GND(Black) Pin2=VCC(Red) Pin3=SCK(Green) Pin4=DT(Yellow).
Must match hub-side RJ11 pin convention (wiring.md) for a straight-through cable.
Footprint intentionally left blank - assign to match your exact RJ11 jack part.

Part of the Sallaup KegSense keg-monitoring system
HX711 carrier + 4x half-bridge sensor terminals + RJ11 to hub

Sallaup Electronics

Sheet: /
File: keg_sensor_module.kicad_sch

Title: KegSensor

Size: A3	Date:	Rev:
KiCad E.D.A. 9.0.1		Id: 1/1