## **Options**

**Title:** Not titled yet Output Language: Python

**Generate Options: QT GUI** 

## Variable

**ID:** samp rate Value: 20M


## **QT GUI Range**

**ID:** my range

**Default Value: 88M** 

Start: 88M **Stop:** 108M

Step: 1M



## Center Frequency (Hz): 88M Bandwidth (Hz): 20M

QT GUI Waterfall Sink

**FFT Size: 1024**