




# Daisy Seed




## Other stuff



## **USB**




# **OLED**




# Flags




# 9V DC




# Power Mux




# USB/SWD/JTAG



## MIDI




#### SD




## Audio Left In

# C14 1uF R12 2M WCP6004T-I/SL 100k MCP6004T-I/SL AUDIO\_LIN GND GND GND


#### Audio Left Out




# Audio Right In




# Audio Right Out




# OpAmp Power




# **HP Out**




## Pots




## Encoder




## **Push buttons**




## **Footswitch**




## **Switches**



# **Button Caps**



## **LEDs**



#### **Knobs**

