

ESPception - Flash Firmware

Upload Firmware to ESPception SD storage

ESPception

Flash Firmware

TCP Serial Bridge

System

1) Upload Firmware To SD

Browse...

firmware-station-g2-2.7.22.96dd647.bin

Upload

Uploading 16%

SD space: 3.61 GB free of 3.63 GB (used 20.2 MB)

2) Select Firmware

-- Select firmware --

Delete Selected

No firmware selected

3) Flash Target

Interface: Espressif Systems BQ Station G2 VID:PID=303A:1001

Start Flash

Enter DFU Mode

Soft Reset

Power Reset

Power interrupt pulse started.

When successful the MD5 hash is calculated so you can verify the image was transferred correctly

1) Upload Firmware To SD

Browse...

No file selected.

Upload

Upload Complete: MD5 45b38c864d9b2742f249e1004fae1741

SD space: 3.61 GB free of 3.63 GB (used 20.2 MB)

Select the firmware file to flash

2) Select Firmware

firmware-station-g2-2_7_22_96dd647.bin

Delete Selected

✓ firmware-station-g2-2_7_22_96dd647.bin selected

Note: You also have the option to delete firmware from SD storage.

Enter DFU Mode, the interface should change to say JTAG / DEBUG or similar.

Interface: Espressif USB JTAG/serial debug unit VID:PID=303A:1001

Enter DFU Mode

Soft Reset

Power Reset

Issue a Soft Reset.

Soft Reset

Click Start Flash

3) Flash Target

Start Flash

Soft reset sent.

Monitor the logs for progress

```
Selected Firmware: firmware-station-g2-2_7_22_96dd647.bin
USB host flashing starting with: firmware-station-g2-2_7_22_96dd647.bin
Flash pipeline: assuming target already in DFU/ROM mode (manual entry)
Flash pipeline: preparing ROM transport from current USB interface
ROM endpoints: OUT=0x03 IN=0x84
CDC host driver uninstalled; switching to raw USB transfers
SYNC: waiting for ROM response...
SYNC ACK confirmed
Chip ID register 0x40001000 = 0x00000009
Flash precheck: detected flash size = 0x01000000 (16777216 bytes)
Flash precheck: image size=2092672 bytes, range=0x00010000..0x0020EE80
Flashing /sdcard/firmware-station-g2-2_7_22_96dd647.bin (2092672 bytes) at 0x00010000
Flashing: 2%
Flashing: 4%
Flashing: 6%
```

When the flash is complete, the status will appear under the Flash button. The logs will also indicate completion.

3) Flash Target

Interface: Espressif USB JTAG/serial debug unit VID:PID=303A:1001

Start Flash

Enter DFU Mode

Soft Reset

Power Reset

✓ Flash successful

Logs

Clear Logs

Flashing: 62%

Flashing: 64%

Flashing: 66%

Flashing: 68%

Flashing: 70%

Flashing: 72%

Flashing: 74%

Flashing: 76%

Flashing: 78%

Flashing: 80%

Flashing: 82%

Flashing: 84%

Flashing: 86%

Flashing: 88%

Flashing: 90%

Flashing: 92%

Flashing: 94%

Flashing: 96%

Flashing: 98%

Flashing: 100%

Flash + verify complete

Flash pipeline: sending FLASH_END (exit ROM)

USB host flashing complete

Issue a Power Reset to boot into the new Firmware.

Power Reset