Setup MDK-ARM V5.28a X

## 

Setup MDK-ARM V5.28a

## License Agreement


Please read the following license agreement carefully.



To continue with SETUP, you must accept the terms of the License Agreement. To accept the agreement, click the check box below.

## END USER LICENSE AGREEMENT FOR ARM SOFTWARE DEVELOPMENT TOOLS


This end user license agreement ("License") is a legal agreement between you (a single individual), or the company or organisation (a single legal entity) that you represent and have the legal authority to bind, and Arm relating to use of the Arm Tools. Arm is only willing to license the Arm Tools on condition that you accept all of the terms of this License. By clicking "I Agree" or by installing or >




Setup MDK-ARM V5.28a X



Setup MDK-ARM V5.28a



Setup MDK-ARM V5.28a X




Setup MDK-ARM V5.28a



## Açılan Pack Installer sayfasında Board sekmesini seçtikten sonra

Arama kutusuna stm32f407 yazarak ilgili kartlar getirilir ve ilgili Discovery kart seçilir.



Aynı pencerenin sağ kısmında eğer kurulu veya güncel değilse

Keil::STM32F4xx DFP

ARM::CMSIS

ARM::CMSIS-Driver kurulmalıdır. Kurulu olmayan paketler internetten indirecektir ve kurulması biraz zaman alabilir.

