

# TravAID — Jump-Start a Dead Battery

Duration: 10–15 min • Difficulty: Medium

**Safety:** Never connect the negative cable directly to the dead battery's negative terminal — sparks near hydrogen gas can cause an explosion.

## ***Step 1. Park donor car nose-to-nose***

Both cars off, parking brakes on. Keys removed.

## ***Step 2. Red to dead positive***

Connect one red (positive) clamp to the dead battery's + terminal.

## ***Step 3. Red to good positive***

Connect the other red clamp to the good battery's + terminal.

## ***Step 4. Black to good negative***

Connect one black (negative) clamp to the good battery's - terminal.

## ***Step 5. Black to bare metal***

Clip the final black clamp to an unpainted metal bolt on the dead car's engine block — NOT the battery.

## ***Step 6. Start the donor, then the dead car***

Run donor for 2 minutes. Try starting the dead car. If it doesn't start in 3 tries, the battery is likely dead — call for help.

## ***Step 7. Disconnect in reverse order***

Black off engine, black off good battery, red off good, red off dead. Drive the rescued car for at least 30 minutes to recharge.