Appendix A. Mnemonic Series Names (MSN)

This appendix contains alphabetical listings of the variables used in the price and expenditure module of the State Energy Data System (SEDS). The first list presents the price and expenditure variables, and the second presents the consumption adjustment variables as described in Section 7, "Consumption Adjustments for Calculating Expenditures."

Provided for each variable are: a brief description; unit of measure; and the formulas used to create the variable. If a variable is not one calculated in SEDS but is entered into the system, it is described as an independent variable. Formulas for the state calculations have "ZZ" following the variable name, where "ZZ" represents the two-letter postal code of a state, and formulas for the United States have "US" following the variable name. If the formula for the states and the United States are the same, only one formula is shown.

Variables in SEDS have five-letter names that generally consist of the following components:

Energy activity or energy-consuming sector

MGACV

Type of energy Type of data

For a detailed explanation of the naming convention, see Section 1, "Documentation Guide."

In general, state-level price estimates are independent variables and are expressed in dollars per million Btu. Estimates of state-level expenditures are calculated by multiplying the appropriate consumption estimates by the corresponding prices and converting to million dollars. The consumption variables are taken from the SEDS consumption module and some are adjusted for process fuel, intermediate products, and fuels with no direct cost (see discussion in Section 7). Expenditures for the United States are the sum of the 50 states and the District of Columbia. Prices for the United States are the sum of the states' expenditures divided by the sum of the states'

consumption or adjusted consumption, converted to dollars per million Btu.

If the consumption variables in a formula are taken directly from the SEDS consumption module (i.e., not adjusted), they are listed in Appendix A of the Consumption Technical Notes (http://www.eia.gov/state/seds/sep_prices/notes/pr_a.pdf) and are not reproduced in this appendix. Generally, if the third and fourth letters of the consumption variables are the same as the corresponding price and expenditure variables, they are from the consumption module. Examples are: TC (total consumption), TX (total end-use consumption), RC (residential consumption), CC (commercial consumption), IC (industrial consumption), AC (transportation consumption), and EI (electric power sector consumption). Variables related to consumption adjustments are listed from page 140 onwards.

Table A1. Price and Expenditure Variables

MSN	Description	Unit	Formula
ARICD	Asphalt and road oil price in the industrial sector.	Dollars per million Btu	ARICDZZ is independent. ARICDUS = ARICVUS / ARICBUS * 1000
ARICV	Asphalt and road oil expenditures in the industrial sector.	Million dollars	ARICVZZ = ARICBZZ * ARICDZZ / 1000 ARICVUS = ΣARICVZZ
ARTCD	Asphalt and road oil average price, all sectors.	Dollars per million Btu	ARTCD = ARICD
ARTCV	Asphalt and road oil total expenditures.	Million dollars	ARTCV = ARICV
ARTXD	Asphalt and road oil average price, all end-use sectors.	Dollars per million Btu	ARTXD = ARTXV / ARTXB * 1000
ARTXV	Asphalt and road oil total end-use expenditures.	Million dollars	ARTXV = ARICV
AVACD	Aviation gasoline price in the transportation sector.	Dollars per million Btu	AVACDZZ is independent. AVACDUS = AVACVUS / AVACBUS * 1000
AVACV	Aviation gasoline expenditures in the transportation sector.	Million dollars	AVACVZZ = AVACBZZ * AVACDZZ / 1000 AVACVUS = Σ AVACVZZ
AVTCD	Aviation gasoline average price, all sectors.	Dollars per million Btu	AVTCD = AVACD
AVTCV	Aviation gasoline total expenditures.	Million dollars	AVTCV = AVACV
AVTXD	Aviation gasoline average price, all end-use sectors.	Dollars per million Btu	AVTXD = AVTXV / AVTXB * 1000
AVTXV	Aviation gasoline total end-use expenditures.	Million dollars	AVTXV = AVACV
CCEXD	Coal coke exports average price, United States.	Dollars per million Btu	CCEXDUS is independent.
CCEXV	Coal coke exports expenditures, United States.	Million dollars	CCEXVUS = CCEXBUS * CCEXDUS / 1000
CCIMD	Coal coke imports average price, United States.	Dollars per million Btu	CCIMDUS is independent.
CCIMV	Coal coke imports expenditures, United States.	Million dollars	CCIMVUS = CCIMBUS * CCIMDUS / 1000
CCNIV	Coal coke net imports expenditures, United States.	Million dollars	CCNIVUS = CCIMVUS - CCEXVUS
CLACD	Coal price in the transportation sector.	Dollars per million Btu	CLACDZZ is independent. CLACDUS = CLACVUS / CLACBUS * 1000
CLACV	Coal expenditures in the transportation sector.	Million dollars	CLACVZZ = CLACBZZ * CLACDZZ / 1000 CLACVUS = ΣCLACVZZ
CLCCD	Coal price in the commercial sector.	Dollars per million Btu	CLCCDZZ is independent. CLCCDUS = CLCCVUS / CLCCBUS * 1000
CLCCV	Coal expenditures in the commercial sector.	Million dollars	CLCCVZZ = CLCCBZZ * CLCCDZZ / 1000 CLCCVUS = ΣCLCCVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
CLEID	Coal price in the electric power sector.	Dollars per million Btu	CLEIDZZ is independent. CLEIDUS = CLEIVUS / CLEIBUS * 1000
CLEIV	Coal expenditures in the electric power sector.	Million dollars	CLEIVZZ = CLEIBZZ * CLEIDZZ / 1000 CLEIVUS = ΣCLEIVZZ
CLICD	Coal price in the industrial sector.	Dollars per million Btu	CLICD = CLICV / CLISB * 1000
CLICV	Coal expenditures in the industrial sector.	Million dollars	CLICVZZ = CLKCVZZ + CLOCVZZ CLICVUS = Σ CLICVZZ
CLKCD	Coal price at coke plants.	Dollars per million Btu	CLKCDZZ is independent. CLKCDUS = CLKCVUS / CLKCBUS * 1000
CLKCV	Coal expenditures at coke plants.	Million dollars	CLKCVZZ = CLKCBZZ * CLKCDZZ / 1000 CLKCVUS = Σ CLKCVZZ
CLOCD	Coal price in the industrial sector other than coke plants.	Dollars per million Btu	CLOCDZZ is independent. CLOCDUS = CLOCVUS / CLOSBUS * 1000
CLOCV	Coal expenditures in the industrial sector other than coke plants.	Million dollars	CLOCVZZ = CLOSBZZ * CLOCDZZ / 1000 CLOCVUS = Σ CLOCVZZ
CLRCD	Coal price in the residential sector.	Dollars per million Btu	CLRCDZZ is independent. CLRCDUS = CLRCVUS / CLRCBUS * 1000
CLRCV	Coal expenditures in the residential sector.	Million dollars	CLRCVZZ = CLRCBZZ * CLRCDZZ / 1000 CLRCVUS = Σ CLRCVZZ
CLTCD	Coal average price, all sectors.	Dollars per million Btu	CLTCD = CLTCV / CLSCB * 1000
CLTCV	Coal total expenditures.	Million dollars	CLTCV = CLKCV + CLXCV
CLTXD	Coal average price, all end-use sectors.	Dollars per million Btu	CLTXD = (CLTXV / (CLSCB - CLEIB)) * 1000
CLTXV	Coal total end-use expenditures.	Million dollars	CLTXVZZ = CLACVZZ + CLCCVZZ + CLICVZZ + CLRCVZZ CLTXVUS = Σ CLTXVZZ
CLXCD	Coal average price for all sectors excluding coke plants and refineries.	Dollars per million Btu	CLXCD = CLXCV / CLXCB * 1000
CLXCV	Coal expenditures for all sectors excluding coke plants and refineries.	Million dollars	CLXCVZZ = CLRCVZZ + CLCCVZZ + CLOCVZZ + CLACVZZ + CLEIVZZ CLXCVUS = ΣCLXCVZZ
DFACD	Distillate fuel oil price in the transportation sector.	Dollars per million Btu	DFACDZZ is independent. DFACDUS = DFACVUS / DFACBUS * 1000

MSN	Description	Unit	Formula
DFACV	Distillate fuel oil expenditures in the transportation sector.	Million dollars	DFACVZZ = DFACBZZ * DFACDZZ / 1000 DFACVUS = ΣDFACVZZ
DFCCD	Distillate fuel oil price in the commercial sector.	Dollars per million Btu	DFCCDZZ is independent. DFCCDUS = DFCCVUS / DFCCBUS * 1000
DFCCV	Distillate fuel oil expenditures in the commercial sector.	Million dollars	DFCCVZZ = DFCCBZZ * DFCCDZZ / 1000 DFCCVUS = ΣDFCCVZZ
DFEID	Distillate fuel oil price in the electric power sector.	Dollars per million Btu	DFEIDZZ is independent. DFEIDUS = DFEIVUS / DFEIBUS * 1000
DFEIV	Distillate fuel oil expenditures in the electric power sector.	Million dollars	DFEIVZZ = DFEIBZZ * DFEIDZZ / 1000 DFEIVUS = ΣDFEIVZZ
DFICD	Distillate fuel oil price in the industrial sector.	Dollars per million Btu	DFICDZZ is independent. DFICDUS = DFICVUS / DFISBUS * 1000
DFICV	Distillate fuel oil expenditures in the industrial sector.	Million dollars	DFICVZZ = DFISBZZ * DFICDZZ / 1000 DFICVUS = ΣDFICVZZ
DFRCD	Distillate fuel oil price in the residential sector.	Dollars per million Btu	DFRCDZZ is independent. DFRCDUS = DFRCVZZ / DFRCBZZ * 1000
DFRCV	Distillate fuel oil expenditures in the residential sector.	Million dollars	DFRCVZZ = DFRCBZZ * DFRCDZZ / 1000 DFRCVUS = ΣDFRCVZZ
DFTCD	Distillate fuel oil average price, all sectors.	Dollars per million Btu	DFTCD = DFTCV / DFSCB * 1000
DFTCV	Distillate fuel oil total expenditures.	Million dollars	DFTCVZZ = DFRCVZZ + DFCCVZZ + DFICVZZ + DFACVZZ + DFEIVZZ DFTCVUS = Σ DFTCVZZ
DFTXD	Distillate fuel oil average price, all end-use sectors.	Dollars per million Btu	DFTXD = (DFTXV / (DFSCB - DFEIB)) * 1000
DFTXV	Distillate fuel oil total end-use expenditures.	Million dollars	$\begin{aligned} DFTXVZZ &= DFACVZZ + DFCCVZZ + DFICVZZ + DFRCVZZ \\ DFTXVUS &= \Sigma DFTXVZZ \end{aligned}$
DKEID	Distillate fuel oil and kerosene-type jet fuel average price in the electric power sector.	Dollars per million Btu	DKEID = DKEIV / DKEIB * 1000
DKEIV	Distillate fuel oil and kerosene-type jet fuel expenditures in the electric power sector.	Million dollars	DKEIVZZ = DFEIVZZ + JFEUVZZ DKEIVUS = Σ DKEIVZZ
ELEXD	Electricity exports average price.	Dollars per million Btu	ELEXD is independent.
ELEXV	Electricity exports expenditures.	Million dollars	ELEXVZZ = ELEXBZZ * ELEXDZZ / 1000 ELEXVUS = ΣELEXVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
ELIMD	Electricity imports average price.	Dollars per million Btu	ELIMD is independent.
ELIMV	Electricity imports expenditures.	Million dollars	ELIMVZZ = ELIMBZZ * ELIMDZZ / 1000 ELIMVUS = ΣELIMVZZ
EMACV	Fuel ethanol, excluding denaturant, expenditures in the transportation sector (compiled for inclusion in total expenditures by end-use sector before 1993).	Million dollars	EMACVZZ = EMACBZZ * MGACDZZ / 1000 EMACVUS = ΣEMACVZZ
EMCCV	Fuel ethanol, excluding denaturant, expenditures in the commercial sector (compiled for inclusion in total expenditires by end use sector before 1993).	Million dollars	EMCCVZZ = EMCCBZZ * MGCCDZZ / 1000 EMCCVUS = ΣEMCCVZZ
EMICV	Fuel ethanol, excluding denaturant, expenditures in the industrial sector (compiled for inclusion in total expenditures by end-use sector before 1993).	Million dollars	EMICVZZ = EMICBZZ * MGACDZZ / 1000 EMICVUS = ΣEMICVZZ
EMTCV	Fuel ethanol, excluding denaturant, total expenditures (compiled for inclusion in total expenditures before 1993).	Million dollars	EMTCVZZ = EMACVZZ + EMCCVZZ + EMICVZZ EMTCVUS = ΣEMTCVZZ
ESACD	Electricity price in the transportation sector.	Dollars per million Btu	ESACDZZ is independent. ESACDUS = ESACVUS / ESACBUS * 1000
ESACV	Electricity expenditures in the transportation sector.	Million dollars	ESACVZZ = ESACBZZ * ESACDZZ / 1000 ESACVUS = ΣESACVZZ
ESCCD	Electricity price in the commercial sector.	Dollars per million Btu	ESCCDZZ is independent. ESCCDUS = ESCCVUS / ESCCBUS * 1000
ESCCV	Electricity expenditures in the commercial sector.	Million dollars	ESCCVZZ = ESCCBZZ * ESCCDZZ / 1000 ESCCVUS = ΣESCCVZZ
ESICD	Electricity price in the industrial sector.	Dollars per million Btu	ESICDZZ is independent. ESICDUS = ESICVUS / ESISBUS * 1000
ESICV	Electricity expenditures in the industrial sector.	Million dollars	ESICVZZ = ESESBZZ * ESICDZZ / 1000 ESICVUS = ΣESICVZZ
ESRCD	Electricity price in the residential sector.	Dollars per million Btu	ESRCDZZ is independent. ESRCDUS = ESRCVUS / ESRCBUS * 1000
ESRCV	Electricity expenditures in the residential sector.	Million dollars	ESRCVZZ = ESRCBZZ * ESRCDZZ / 1000 ESRCVUS = ΣESRCVZZ
ESTCD	Electricity average price, all sectors.	Dollars per million Btu	ESTCD = ESTCV / ESSCB * 1000

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
ESTCV	Electricity total expenditures.	Million dollars	ESTCVZZ = ESRCVZZ + ESCCVZZ + ESICVZZ + ESACVZZ ESTCVUS = Σ ESTCVZZ
ESTXD	Electricity average price, all end-use sectors.	Dollars per million Btu	ESTXD = ESTXV / ESSCB * 1000
ESTXV	Electricity total end-use expenditures.	Million dollars	ESTXVZZ = ESACVZZ + ESCCVZZ + ESICVZZ + ESRCVZZ ESTXVUS = Σ ESTXVZZ
FNICD	Petrochemical feedstocks, naphtha less than 401° F, price in the industrial sector.	Dollars per million Btu	FNICDZZ is independent. FNICDUS = FNICVUS / FNICBUS * 1000
FNICV	Petrochemical feedstocks, naphtha less than 401° F, expenditures in the industrial sector.	Million dollars	FNICVZZ = FNICBZZ * FNICDZZ / 1000 FNICVUS = ΣFNICVZZ
FOICD	Petrochemical feedstocks, other oils equal to or greater than 401° F, price in the industrial sector.	Dollars per million Btu	FOICDZZ is independent. FOICDUS = FOICVUS / FOICBUS * 1000
FOICV	Petrochemical feedstocks, other oils equal to or greater than 401° F, expenditures in industrial sector.	Million dollars	FOICVZZ = FOICBZZ * FOICDZZ / 1000 FOICVUS = ΣFOICVZZ
FSICD	Petrochemical feedstocks, still gas, price in the industrial sector.	Dollars per million Btu	FSICDZZ is independent. FSICDUS = FSICVUS / FSICBUS * 1000
FSICV	Petrochemical feedstocks, still gas, expenditures in the industrial sector.	Million dollars	FSICVZZ = FSICBZZ * FSICDZZ / 1000 FSICVUS = ΣFSICVZZ
GDPRV	Current-dollar gross domestic product.	Million dollars	GDPRV is independent.
JFACD	Jet fuel price in the transportation sector.	Dollars per million Btu	JFACDZZ is independent. JFACDUS = JFACVUS / JFACBUS * 1000
JFACV	Jet fuel expenditures in the transportation sector.	Million dollars	JFACVZZ = JFACBZZ * JFACDZZ / 1000 JFACVUS = ΣJFACVZZ
JFEUD	Jet fuel price in the electric power sector (1972–1982 only).	Dollars per million Btu	JFEUDZZ is independent.
JFEUV	Jet fuel expenditures in the electric power sector (1972–1982 only).	Million dollars	JFEUVZZ = JFEUBZZ * JFEUDZZ / 1000
JFTCD	Jet fuel average price, all sectors.	Dollars per million Btu	JFTCD = JFTCV / JFTCB * 1000
JFTCV	Jet fuel total expenditures.	Million dollars	JFTCVZZ = JFACVZZ + JFEUVZZ JFTCVUS = ΣJFTCVZZ
JFTXD	Jet fuel average price, all end-use sectors.	Dollars per million Btu	JFTXD = JFTXV / JFTXB * 1000

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
JFTXV	Jet fuel total end-use expenditures.	Million dollars	JFTXVZZ = JFACVZZ JFTXVUS = \$\textit{Z}\text{JFTXVZZ}
KSCCD	Kerosene price in the commercial sector.	Dollars per million Btu	KSCCDZZ is independent. KSCCDUS = KSCCVUS / KSCCBUS * 1000
KSCCV	Kerosene expenditures in the commercial sector.	Million dollars	KSCCVZZ = KSCCBZZ * KSCCDZZ / 1000 KSCCVUS = Σ KSCCVZZ
KSICD	Kerosene price in the industrial sector.	Dollars per million Btu	KSICDZZ = is independent. KSICDUS = KSICVUS / KSICBUS * 1000
KSICV	Kerosene expenditures in the industrial sector.	Million dollars	KSICVZZ = KSICBZZ * KSICDZZ / 1000 KSICVUS = ΣKSICVZZ
KSRCD	Kerosene price in the residential sector.	Dollars per million Btu	KSRCDZZ = is independent. KSRCDUS = KSRCVUS / KSRCBUS * 1000
KSRCV	Kerosene expenditures in the residential sector.	Million dollars	KSRCVZZ = KSRCBZZ * KSRCDZZ / 1000 KSRCVUS = ΣKSRCVZZ
KSTCD	Kerosene average price, all sectors.	Dollars per million Btu	KSTCD = KSTCV / KSTCB * 1000
KSTCV	Kerosene total expenditures.	Million dollars	KSTCVZZ = KSRCVZZ + KSCCVZZ + KSICVZZ KSTCVUS = Σ KSTCVZZ
KSTXD	Kerosene average price, all end-use sectors.	Dollars per million Btu	KSTXD = KSTXV / KSTXB * 1000
KSTXV	Kerosene total end-use expenditures.	Million dollars	KSTXVZZ = KSCCVZZ + KSICVZZ + KSRCVZZ KSTXVUS = Σ KSTXVZZ
LGACD	LPG price in the transportation sector.	Dollars per million Btu	LGACDZZ is independent. LGACDUS = LGACVUS / LGACBUS * 1000
LGACV	LPG expenditures in the transportation sector.	Million dollars	LGACVZZ = LGACBZZ * LGACDZZ / 1000 LGACVUS = ΣLGACVZZ
LGCCD	LPG price in the commercial sector.	Dollars per million Btu	LGCCDZZ is independent. LGCCDUS = LGCCVUS / LGCCBUS * 1000
LGCCV	LPG expenditures in the commercial sector.	Million dollars	LGCCVZZ = LGCCBZZ * LGCCDZZ / 1000 LGCCVUS = ΣLGCCVZZ
LGICD	LPG price in the industrial sector.	Dollars per million Btu	LGICDZZ is independent. LGICDUS = LGICVUS / LGISBUS * 1000
LGICV	LPG expenditures in the industrial sector.	Million dollars	LGICVZZ = LGISBZZ * LGICDZZ / 1000 LGICVUS = ΣLGICVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
LGRCD	LPG price in the residential sector.	Dollars per million Btu	LGRCDZZ is independent. LGRCDUS = LGRCVUS / LGRCBUS * 1000
LGRCV	LPG expenditures in the residential sector.	Million dollars	LGRCVZZ = LGRCBZZ * LGRCDZZ / 1000 LGRCVUS = ΣLGRCVZZ
LGTCD	LPG average price, all sectors.	Dollars per million Btu	LGTCD = LGTCV / LGSCB * 1000
LGTCV	LPG total expenditures.	Million dollars	LGTCVZZ = LGACVZZ + LGCCVZZ + LGICVZZ + LGRCVZZ LGTCVUS = Σ LGTCVZZ
LGTXD	LPG average price, all end-use sectors.	Dollars per million Btu	LGTXD = LGTXV / LGSCB * 1000
LGTXV	LPG total end-use expenditures.	Million dollars	LGTXVZZ = LGACVZZ + LGCCVZZ + LGICVZZ + LGRCVZZ LGTXVUS = Σ LGTXVZZ
LUACD	Lubricants price in the transportation sector.	Dollars per million Btu	LUACDZZ is independent. LUACDUS = LUACVUS / LUACBUS * 1000
LUACV	Lubricants expenditures in the transportation sector.	Million dollars	LUACVZZ = LUACBZZ * LUACDZZ / 1000 LUACVUS = ΣLUACVZZ
LUICD	Lubricants price in the industrial sector.	Dollars per million Btu	LUICDZZ is independent. LUICDUS = LUICVUS / LUICBUS * 1000
LUICV	Lubricants expenditures in the industrial sector.	Million dollars	LUICVZZ = LUICBZZ * LUICDZZ / 1000 LUICVUS = ΣLUICVZZ
LUTCD	Lubricants average price, all sectors.	Dollars per million Btu	LUTCD = LUTCV / LUTCB * 1000
LUTCV	Lubricants average price, all sectors.	Million dollars	LUTCVZZ = LUACVZZ + LUICVZZ LUTCVUS = ΣLUTCVZZ
LUTXD	Lubricants average price, all end-use sectors.	Dollars per million Btu	LUTXD = LUTXV / LUTXB * 1000
LUTXV	Lubricants total end-use expenditures.	Million dollars	LUTXVZZ = LUACVZZ + LUICVZZ LUTXVUS = Σ LUTXVZZ
MGACD	Motor gasoline price in the transportation sector.	Dollars per million Btu	MGACDZZ is independent. MGACDUS = MGACVUS / MGACBUS * 1000
MGACV	Motor gasoline expenditures in the transportation sector.	Million dollars	MGACVZZ = MGACBZZ * MGACDZZ / 1000 MGACVUS = Σ MGACVZZ
MGCCD	Motor gasoline price in the commercial sector.	Dollars per million Btu	MGCCDZZ is independent. MGCCDUS = MGCCVUS / MGCCBUS * 1000
MGCCV	Motor gasoline expenditures in the commercial sector.	Million dollars	MGCCVZZ = MGCCBZZ * MGCCDZZ / 1000 MGCCVUS = Σ MGCCVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
MGICD	Motor gasoline price in the industrial sector.	Dollars per million Btu	MGICDZZ is independent. MGICDUS = MGICVUS / MGICBUS * 1000
MGICV	Motor gasoline expenditures in the industrial sector.	Million dollars	MGICVZZ = MGICBZZ * MGICDZZ / 1000 MGICVUS = Σ MGICVZZ
MGTCD	Motor gasoline average price, all sectors.	Dollars per million Btu	MGTCD = MGTCV / MGTCB * 1000
MGTCV	Motor gasoline total expenditures.	Million dollars	MGTCVZZ = MGACVZZ + MGCCVZZ + MGICVZZ MGTCVUS = Σ MGTCVZZ
MGTPV	Motor gasoline expenditures per capita.	Million dollars	MGTPV = MGTCV / TPOPP * 1000
MGTXD	Motor gasoline average price, all end-use sectors.	Dollars per million Btu	MGTXD = MGTXV / MGTXB * 1000
MGTXV	Motor gasoline total end-use expenditures.	Million dollars	MGTXVZZ = MGACVZZ + MGCCVZZ + MGICVZZ MGTXVUS = Σ MGTXVZZ
MSICD	Miscellaneous petroleum products price in the industrial sector.	Dollars per million Btu	MSICDZZ is independent. MSICDUS = MSICVUS / MSICBUS * 1000
MSICV	Miscellaneous petroleum products expenditures in the industrial sector.	Million dollars	MSICVZZ = MSICBZZ * MSICDZZ / 1000 MSICVUS = ΣMSICVZZ
NGACD	Natural gas price in the transportation sector.	Dollars per million Btu	NGACDZZ is independent. NGACDUS = NGACVUS / NGASBUS * 1000
NGACV	Natural gas expenditures in the transportation sector.	Million dollars	NGACVZZ = NGASBZZ * NGACDZZ / 1000 NGACVUS = Σ NGACVZZ
NGCCD	Natural gas price in the commercial sector (including supplemental gaseous fuels).	Dollars per million Btu	NGCCDZZ is independent. NGCCDUS = NGCCVUS / NGCCBUS * 1000
NGCCV	Natural gas expenditures in the commercial sector (including supplemental gaseous fuels).	Million dollars	NGCCVZZ = NGCCBZZ * NGCCDZZ / 1000 NGCCVUS = Σ NGCCVZZ
NGEID	Natural gas price in the electric power sector (including supplemental gaseous fuels).	Dollars per million Btu	NGEIDZZ is independent. NGEIDUS = NGEIVUS / NGEIBUS * 1000
NGEIV	Natural gas expenditures in the electric power sector (including supplemental gaseous fuels).	Million dollars	NGEIVZZ = NGEIBZZ * NGEIDZZ / 1000 NGEIVUS = ΣNGEIVZZ
NGICD	Natural gas price in the industrial sector (including supplemental gaseous fuels).	Dollars per million Btu	NGICDZZ is independent. NGICDUS = NGICVZZ / NGISBZZ * 1000
NGICV	Natural gas expenditures in the industrial sector (including supplemental gaseous fuels).	Million dollars	NGICVZZ = NGISBZZ * NGICDZZ / 1000 NGICVUS = ΣNGICVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
NGRCD	Natural gas price in the residential sector (including supplemental gaseous fuels).	Dollars per million Btu	NGRCDZZ is independent. NGRCDUS = NGRCVZZ / NGRCBZZ * 1000
NGRCV	Natural gas expenditures in the residential sector (including supplemental gaseous fuels).	Million dollars	NGRCVZZ = NGRCBZZ * NGRCDZZ / 1000 NGRCVUS = Σ NGRCVZZ
NGTCD	Natural gas average price, all sectors (including supplemental gaseous fuels).	Dollars per million Btu	NGTCD = NGTCV / NGSCB * 1000
NGTCV	Natural gas total expenditures (including supplemental gaseous fuels).	Million dollars	$\begin{aligned} & \text{NGTCVZZ} = \text{NGRCVZZ} + \text{NGCCVZZ} + \text{NGICVZZ} + \text{NGACVZZ} + \\ & \text{NGEIVZZ} \\ & \text{NGTCVUS} = \Sigma \text{NGTCVZZ} \end{aligned}$
NGTXD	Natural gas average price, all end-use sectors (including supplemental gaseous fuels).	Dollars per million Btu	NGTXD = (NGTXV / (NGSCB - NGEIB)) * 1000
NGTXV	Natural gas total end-use expenditures (including supplemental gaseous fuels).	Million dollars	NGTXVZZ = NGACVZZ + NGCCVZZ + NGICVZZ + NGRCVZZ NGTXVUS = Σ NGTXVZZ
NUEGD	Nuclear fuel price in the electric power sector.	Dollars per million Btu	NUEGDZZ is independent. NUEGDUS = NUEGVUS / NUEGBUS * 1000
NUEGV	Nuclear fuel expenditures in the electric power sector.	Million dollars	NUEGVZZ = NUEGBZZ * NUEGDZZ / 1000 NUEGVUS = ΣNUEGVZZ
NUETD	Nuclear fuel average price, all sectors.	Dollars per million Btu	NUETD = NUETV / NUETB * 1000
NUETV	Nuclear fuel total expenditures.	Million dollars	NUETVZZ = NUEGVZZ NUETVUS = Σ NUETVZZ
P1ICD	Asphalt and road oil, kerosene, lubricants, and "other petroleum products" average price in the industrial sector.	Dollars per million Btu	P1ICD = P1ICV / P1ISB * 1000
P1ICV	Asphalt and road oil, kerosene, lubricants, and "other petroleum products" expenditures in the industrial sector.	Million dollars	P1ICVZZ = ARICVZZ + KSICVZZ + LUICVZZ + POICVZZ P1ICVUS = ΣP1ICVZZ
P1TCD	Asphalt and road oil, aviation gasoline, kerosene, lubricants, and "other petroleum products" average price, all sectors.	Dollars per million Btu	P1TCD = P1TCV / P1SCB * 1000
P1TCV	Asphalt and road oil, aviation gasoline, kerosene, lubricants, and "other petroleum products" total expenditures.	Million dollars	P1TCVZZ = ARTCVZZ + AVTCVZZ + KSTCVZZ + LUTCVZZ + POTCVZZ P1TCVUS = Σ P1TCVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
P1TXD	Asphalt and road oil, aviation gasoline, kerosene, lubricants, and "other petroleum products" average price, all end-use sectors.	Dollars per million Btu	P1TXD = (P1TXV / (P1SCB - PCEIB)) * 1000
P1TXV	Asphalt and road oil, aviation gasoline, kerosene, lubricants, and "other petroleum products" total end-use expenditures.	Million dollars	P1TXVZZ = P1TCVZZ - PCEIVZZ P1TXVUS = ΣP1TXVZZ
PAACD	All petroleum products average price in the transportation sector.	Dollars per million Btu	PAACD = PAACV / PAACB * 1000
PAACV	All petroleum products total expenditures in the transportation sector.	Million dollars	PAACVZZ = AVACVZZ + DFACVZZ + JFACVZZ + LGACVZZ + LUACVZZ + MGACVZZ + RFACVZZ PAACVUS = Σ PAACVZZ
PACCD	All petroleum products average price in the commercial sector.	Dollars per million Btu	PACCD = PACCV / PACCB * 1000
PACCV	All petroleum products total expenditures in the commercial sector.	Million dollars	PACCVZZ = DFCCVZZ + KSCCVZZ + LGCCVZZ + MGCCVZZ + PCCCVZZ + RFCCVZZ PACCVUS = ΣPACCVZZ
PAEID	All petroleum products average price in the electric power sector.	Dollars per million Btu	PAEID = PAEIV / PAEIB * 1000
PAEIV	All petroleum products total expenditures in the electric power sector.	Million dollars	PAEIVZZ = DKEIVZZ + PCEIVZZ + RFEIVZZ PAEIVUS = Σ PAEIVZZ
PAICD	All petroleum products average price in the industrial sector.	Dollars per million Btu	PAICD = PAICV / PAISB * 1000
PAICV	All petroleum products total expenditures in the industrial sector.	Million dollars	PAICVZZ = ARICVZZ + DFICVZZ + KSICVZZ + LGICVZZ + LUICVZZ + MGICVZZ + RFICVZZ + POICVZZ PAICVUS = Σ PAICVZZ
PARCD	All petroleum products average price in the residential sector.	Dollars per million Btu	PARCD = PARCV / PARCB * 1000
PARCV	All petroleum products total expenditures in the residential sector.	Million dollars	PARCVZZ = DFRCVZZ + KSRCVZZ + LGRCVZZ PARCVUS = ΣPARCVZZ
PATCD	All petroleum products average price, all sectors.	Dollars per million Btu	PATCD = PATCV / PASCB * 1000
PATCV	All petroleum products total expenditures.	Million dollars	PATCVZZ = ARTCVZZ + AVTCVZZ + DFTCVZZ + JFTCVZZ + KSTCVZZ + LGTCVZZ + LUTCVZZ + MGTCVZZ + RFTCVZZ + POTCVZZ PATCVUS = ΣPATCVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
PATXD	All petroleum products average price, all end-use sectors.	Dollars per million Btu	PATXD = (PATXV / (PASCB - PAEIB)) * 1000
PATXV	All petroleum products total end-use expenditures.	Million dollars	PATXVZZ = ARTXVZZ + AVTXVZZ + DFTXVZZ + JFTXVZZ + KSTXVZZ + LGTXVZZ + LUTXVZZ + MGTXVZZ + POTXVZZ + RFTXVZZ PATXVUS = ΣPATXVZZ
PCCCD	Petroleum coke price in the commercial sector.	Dollars per million Btu	PCCCDZZ is independent. PCCCDUS = PCCCVUS / PCCCBUS * 1000
PCCCV	Petroleum coke expenditures in the commercial sector.	Million dollars	PCCCVZZ = PCCCBZZ * PCCCDZZ / 1000 PCCCVUS = ΣPCCCVZZ
PCEID	Petroleum coke price in the electric power sector.	Dollars per million Btu	PCEIDZZ is independent. PCEIDUS = PCEIVUS / PCEIBUS * 1000
PCEIV	Petroleum coke expenditures in the electric power sector.	Million dollars	PCEIVZZ = PCEIBZZ * PCEIDZZ / 1000 PCEIVUS = ΣPCEIVZZ
PCI3D	Price of petroleum coke consumed by the industrial CHP and electricity-only plants.	Dollars per million Btu	PCI3DZZ is independent. PCI3DUS = PCI3VUS / PCI3BUS * 1000
PCI3V	Expenditures of petroleum coke consumed by the industrial CHP and electricity-only plants.	Million dollars	PCI3VZZ = PCI3BZZ * PCI3DZZ / 1000 PCI3VUS = ΣPCI3VZZ
PCICD	Petroleum coke price in the industrial sector.	Dollars per million Btu	PCICD = PCICV / PCISB * 1000
PCICV	Petroleum coke expenditures in the industrial sector.	Million dollars	PCICVZZ = PCI3VZZ + PCOCVZZ PCICVUS = ΣPCICVZZ
PCOCD	Petroleum coke price in the industrial sector other than for refinery use and CHP.	Dollars per million Btu	PCOCDZZ is independent. PCOCDUS = PCOCVUS / PCOCBUS * 1000
PCOCV	Petroleum coke expenditures in the industrial sector other than for refinery use and CHP.	Million dollars	PCOCVZZ = PCOCBZZ * PCOCDZZ / 1000 PCOCVUS = Σ PCOCVZZ
PCTCD	Petroleum coke average price, all sectors.	Dollars per million Btu	PCTCD = PCTCV / PCSCB * 1000
PCTCV	Petroleum coke total expenditures.	Million dollars	PCTCVZZ = PCCCVZZ + PCICVZZ + PCEIVZZ PCTCVUS = ΣPCTCVZZ
PEACD	Primary energy average price in the transportation sector.	Dollars per million Btu	PEACD = PEACV / PEASB * 1000
PEACV	Primary energy total expenditures in the transportation sector.	Million dollars	PEACVZZ = CLACVZZ + NGACVZZ + PAACVZZ PEACVUS = Σ PEACVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
PECCD	Primary energy average price in the commercial sector.	Dollars per million Btu	PECCD = PECCV / PECSB * 1000
PECCV	Primary energy total expenditures in the commercial sector.	Million dollars	PECCVZZ = CLCCVZZ + NGCCVZZ + PACCVZZ + WWCCVZZ PECCVUS = ΣPECCVZZ
PEEID	Primary energy average price in the electric power sector.	Dollars per million Btu	PEEID = PEEIV / PEEIB * 1000
PEEIV	Primary energy total expenditures in the electric power sector.	Million dollars	PEEIVZZ = CLEIVZZ + NGEIVZZ + PAEIVZZ + NUEGVZZ + WWEIVZZ + ELIMVZZ PEEIVUS = ΣPEEIVZZ
PEICD	Primary energy average price in the industrial sector.	Dollars per million Btu	PEICD = PEICV / PEISB * 1000
PEICV	Primary energy total expenditures in the industrial sector.	Million dollars	PEICVZZ = CLICVZZ + NGICVZZ + PAICVZZ + WWICVZZ PEICVUS = Σ PEICVZZ + CCNIVUS
PERCV	Primary energy total expenditures in the residential sector.	Million dollars	PERCVZZ = CLRCVZZ + NGRCVZZ + PARCVZZ + WDRCVZZ PERCVUS = ΣPERCVZZ
PESSD	Primary energy average price, all end-use sectors.	Dollars per million Btu	PESSD = PESSV / PESSB * 1000
PESSV	Primary energy total end-use expenditures.	Million dollars	PESSVZZ = PERCVZZ + PECCVZZ + PEICVZZ + PEACVZZ PESSVUS = ΣPESSVZZ + CCNIVUS
PETCD	Primary energy average price, all sectors.	Dollars per million Btu	PETCD = PETCV / PESCB * 1000
PETCV	Primary energy total expenditures.	Million dollars	PETCVZZ = PESSVZZ + PEEIVZZ PETCVUS = ΣPETCVZZ + CCNIVUS
PETXD	Primary energy average price, all end-use sectors.	Dollars per million Btu	PETXD = (PETXV / (PESCB - PEEIB)) * 1000
PETXV	Primary energy total end-use expenditures.	Million dollars	PETXVZZ = PEACVZZ + PECCVZZ + PEICVZZ + PERCVZZ PETXVUS = ΣPETXVZZ + CCIMVUS - CCEXVUS
POICD	Other petroleum products average price in the industrial sector.	Dollars per million Btu	POICD = POICV / POISB * 1000
POICV	Other petroleum products total expenditures in the industrial sector.	Million dollars	POICVZZ = FNICVZZ + FOICVZZ + FSICVZZ + MSICVZZ + PCICVZZ + SNICVZZ + WXICVZZ POICVUS = ΣΡΟΙCVZZ
POTCD	Other petroleum products average price, all enduse sectors.	Dollars per million Btu	POTCD = POTCV / POSCB * 1000

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
POTCV	Other petroleum products total expenditures.	Million dollars	POTCVZZ = PCCCVZZ + PCEIVZZ + POICVZZ POTCVUS = Σ POTCVZZ
POTXD	Other petroleum products average price, all enduse sectors.	Dollars per million Btu	POTXD = (POTXV / (POSCB - PCEIB)) * 1000
POTXV	Other petroleum products total end-use expenditures.	Million dollars	POTXVZZ = PCCCVZZ + POICVZZ POTXVUS = Σ POTXVZZ
RFACD	Residual fuel oil price in the transportation sector.	Dollars per million Btu	RFACDZZ is independent. RFACDUS = RFACVUS / RFACBUS * 1000
RFACV	Residual fuel oil expenditures in the transportation sector.	Million dollars	RFACVZZ = RFACBZZ * RFACDZZ / 1000 RFACVUS = ΣRFACVZZ
RFCCD	Residual fuel oil price in the commercial sector.	Dollars per million Btu	RFCCDZZ is independent. RFCCDUS = RFCCVUS / RFCCBUS * 1000
RFCCV	Residual fuel oil expenditures in the commercial sector.	Million dollars	RFCCVZZ = RFCCBZZ * RFCCDZZ / 1000 RFCCVUS = ΣRFCCVZZ
RFEID	Residual fuel oil price in the electric power sector.	Dollars per million Btu	RFEIDZZ is independent. RFEIDUS = RFEIVUS / RFEIBUS * 1000
RFEIV	Residual fuel oil expenditures in the electric power sector.	Million dollars	RFEIVZZ = RFEIBZZ * RFEIDZZ / 1000 RFEIVUS = ΣRFEIVZZ
RFICD	Residual fuel oil price in the industrial sector.	Dollars per million Btu	RFICDZZ is independent. RFICDUS = RFICVUS / RFISBUS * 1000
RFICV	Residual fuel oil expenditures in the industrial sector.	Million dollars	RFICVZZ = RFISBZZ * RFICDZZ / 1000 RFICVUS = ΣRFICVZZ
RFTCD	Residual fuel oil average price, all sectors.	Dollars per million Btu	RFTCD = RFTCV / RFSCB * 1000
RFTCV	Residual fuel oil total expenditures.	Million dollars	RFTCVZZ = RFCCVZZ + RFICVZZ + RFACVZZ + RFEIVZZ RFTCVUS = Σ RFTCVZZ
RFTXD	Residual fuel oil average price, all end-use sectors.	Dollars per million Btu	RFTXD = (RFTXV / (RFSCB - RFEIB)) * 1000
RFTXV	Residual fuel oil total end-use consumption.	Million dollars	RFTXVZZ = RFACVZZ + RFCCVZZ + RFICVZZ RFTXVUS = Σ RFTXVZZ
SNICD	Special naphthas price in the industrial sector.	Dollars per million Btu	SNICDZZ is independent. SNICDUS = SNICVUS / SNICBUS * 1000
SNICV	Special naphthas expenditures in the industrial sector.	Million dollars	SNICVZZ = SNICBZZ * SNICDZZ / 1000 SNICVUS = ΣSNICVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
TEACD	Total energy average price in the transportation.	Dollars per million Btu	TEACD = TEACV / TNASB * 1000
TEACV	Total energy expenditures in the transportation sector.	Million dollars	TEACVZZ = PEACVZZ + ESACVZZ TEACVUS = Σ TEACVZZ
TECCD	Total energy average price in the commercial sector.	Dollars per million Btu	TECCD = TECCV / TNCSB * 1000
TECCV	Total energy expenditures in the commercial sector.	Million dollars	TECCVZZ = PECCVZZ + ESCCVZZ TECCVUS = Σ TECCVZZ
TEGDS	Energy expenditures as percent of current-dollar GDP.	Percent	TEGDS = TETCV / GDPRV * 100
TEICD	Total energy average price in the industrial sector.	Dollars per million Btu	TEICD = TEICV / TNISB * 1000
TEICV	Total energy expenditures in the industrial sector.	Million dollars	TEICVZZ = PEICVZZ + ESICVZZ TEICVUS = ΣΤΕΙCVZZ + CCNIVUS
TERCD	Total energy average price in the residential sector.	Dollars per million Btu	TERCD = TERCV / TNRSB * 1000
TERCV	Total energy total expenditures in the residential sector.	Million dollars	TERCVZZ = PERCVZZ + ESRCVZZ TERCVUS = Σ TERCVZZ
TETCD	Total energy average price.	Dollars per million Btu	TETCD = TETCV / TNSCB * 1000
TETCV	Total energy total expenditures.	Million dollars	TETCV = PESSV + ESTCV
TETPV	Total energy expenditures per capita.	Dollars	TETPV = TETCV / TPOPP * 1000
TETXD	Total end-use energy average price.	Dollars per million Btu	TETXD = TETXV / TNSCB * 1000
TETXV	Total end-use energy expenditures.	Million dollars	TETXVZZ = TEACVZZ + TECCVZZ + TEICVZZ + TERCVZZ TETXVUS = ΣTETXVZZ
WDC3D	Wood price, commercial CHP and electricity-only plants, U.S. only.	Dollars per million Btu	WDC3DUS = WDC3VUS / WDCYBUS * 1000
WDC3V	Wood expenditures, commercial CHP and electricity-only plants.	Million dollars	WDC3VZZ = WDCYBZZ * WDEIDUS / 1000 WDC3VUS = ΣWDC3VZZ
WDC4D	Wood price, commercial sector other than CHP and electricity-only plants.	Dollars per million Btu	WDC4D is independent.
WDC4V	Wood expenditures, commercial sector other than CHP and electricity-only plants.	Million dollars	WDC4VZZ = WDCVBZZ * WDC4DZZ / 1000 WDC4VUS = ΣWDC4VZZ
WDEID	Wood price in the electric power sector, U.S. only.	Dollars per million Btu	WDEIDUS is independent.

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
WDI3D	Wood price, industrial CHP and electricity-only plants, U.S. only.	Dollars per million Btu	WDI3DUS = WDI3VUS / WDIYBUS * 1000
WDI3V	Wood expenditures, industrial CHP and electricity-only plants.	Million dollars	WDI3VZZ = WDIYBZZ * WDEIDUS / 1000 WDI3VUS = ΣWDI3VZZ
WDRCD	Wood price in the residential sector.	Dollars per million Btu	WDRCDZZ is independent. WDRCDUS = WDRCVUS / WDRSBUS * 1000
WDRCV	Wood expenditures in the residential sector.	Million dollars	WDRCVZZ = WDRSBZZ * WDRCDZZ / 1000 WDRCVUS = ΣWDRCVZZ
WSC3D	Waste price, commercial CHP and electricity-only plants, U.S. only.	Dollars per million Btu	WSC3DUS = WSC3VUS / WSCYBUS * 1000
WSC3V	Waste expenditures, commercial CHP and electricity-only plants.	Million dollars	WSC3VZZ = WSCYBZZ * WSEIDUS /1000 WSC3VUS = ΣWSC3VZZ
WSEID	Waste price in the electric power sector, U.S. only.	Dollars per million Btu	WSEIDUS is independent.
WSI3D	Waste price, industrial CHP and electricity-only plants, U.S. only.	Dollars per million Btu	WSI3DUS = WSI3VUS / WSIYBUS * 1000
WSI3V	Waste expenditures, industrial CHP and electricity-only plants.	Million dollars	WSI3VZZ = WSIYBZZ * WSEIDUS /1000 WSI3VUS = ΣWSI3VZZ
WWCCD	Wood and waste price in the commercial sector.	Dollars per million Btu	WWCCD = WWCCV / WWCSB * 1000
WWCCV	Wood and waste expenditures in the commercial sector.	Million dollars	WWCCVZZ = WDC3VZZ + WDC4VZZ + WSC3VZZ WWCCVUS = Σ WWCCVZZ
WWEID	Wood and waste price in the electric power sector.	Dollars per million Btu	WWEIDZZ is independent. WWEIDUS = WWEIVUS / WWEIBUS * 1000
WWEIV	Wood and waste expenditures in the electric power sector.	Million dollars	WWEIVZZ = WWEIBZZ * WWEIDZZ / 1000 WWEIVUS = ΣWWEIVZZ
WWI4D	Wood and waste prices in the industrial sector other than CHP and electricity-only plants.	Dollars per million Btu	WWI4DZZ is independent. WWI4DUS = WWI4VUS / WWIVBUS
WWI4V	Wood and waste expenditures in the industrial sector other than CHP and electricity-only plants.	Million dollars	WWI4VZZ = WWIVBZZ * WWI4DZZ / 1000 WWI4VUS = ΣWWI4VZZ
WWICD	Wood and waste price in the industrial sector.	Dollars per million Btu	WWICD = WWICV / WWISB * 1000
WWICV	Wood and waste expenditures in the industrial sector.	Million dollars	WWICVZZ = WWI4VZZ + WDI3VZZ + WSI3VZZ WWICVUS = Σ WWICVZZ

Table A1. Price and Expenditure Variables (cont.)

MSN	Description	Unit	Formula
WWSSV	Wood and waste total end-use expenditures.	Million dollars	WWSSVZZ = WDRCVZZ + WWCCVZZ + WWICVZZ WWSSVUS = Σ WWSSVZZ
WWTCD	Wood and waste average price, all sectors.	Dollars per million Btu	WWTCD = WWTCV / WWSCB * 1000
WWTCV	Wood and waste total expenditures.	Million dollars	WWTCVZZ = WWSSVZZ + WWEIVZZ WWTCVUS = Σ WWTCVZZ
WWTXD	Wood and waste average price, all end-use sectors.	Dollars per million Btu	WWTXD = WWTXV / WWSSB * 1000
WWTXV	Wood and waste total end-use expenditures.	Million dollars	WWTXVZZ = WDRCVZZ + WWCCVZZ + WWICVZZ WWTXVUS = Σ WWTXVZZ
WXICD	Waxes price in the industrial sector.	Dollars per million Btu	WXICDZZ is independent. WXICDUS = WXICVUS / WXICBUS * 1000
WXICV	Waxes expenditures in the industrial sector.	Million dollars	WXICVZZ = WXICBZZ * WXICDZZ / 1000 WXICVUS = ΣWXICVZZ

Table A2. Consumption Adjustment Variables

MSN	Description	Unit	Formula
CLISB	Coal consumed by the industrial sector excluding refinery fuel.	Billion Btu	CLISB = CLOSB + CLKCB
CLOCB	Coal consumed by industrial users other than coke plants.	Billion Btu	SEDS consumption variable
CLOCK	Factor for converting coal consumed by industrial users other than coke plants from physical units to Btu.	Million Btu per short ton	SEDS consumption variable
CLOSB	Coal consumed by the industrial sector other than coke plants excluding refinery fuel.	Billion Btu	CLOSB = CLOCB - CLRFB
CLRFB	Coal consumed as refinery fuel.	Billion Btu	CLRFBZZ = CLRFPZZ * CLOCKZZ
CLRFP	Coal consumed as refinery fuel.	Thousand short tons	CLRFPZZ is independent.
CLSCB	Coal total consumption adjusted for process fuel.	Billion Btu	CLSCB = CLRCB + CLCCB + CLISB + CLACB + CLEIB
CLXCB	Coal consumed by all sectors excluding coke plants and refineries.	Billion Btu	CLXCB = CLRCB + CLCCB + CLOSB + CLACB + CLEIB
DFISB	Distillate fuel oil consumed by the industrial sector excluding refinery fuel.	Billion Btu	DFISB = DFICB - DFRFB
DFRFB	Distillate fuel oil consumed as refinery fuel.	Billion Btu	DFRFBZZ = DFRFPZZ * DFTCKUS
DFRFP	Distillate fuel oil consumed as refinery fuel.	Thousand barrels	DFRFPZZ is independent.
DFSCB	Distillate fuel oil total consumption adjusted for process fuel.	Billion Btu	DFSCB = DFRCB + DFCCB + DFISB + DFACB + DFEIB
EMLCB	Energy losses and co-products from the production of fuel ethanol.	Billion Btu	SEDS consumption variable
ESISB	Electricity sales to the industrial sector excluding refinery use.	Billion Btu	ESISB = ESICB - ESRFB
ESRFB	Electricity consumed by refineries.	Billion Btu	ESRFBZZ = ESRFPZZ * 3.412
ESRFP	Electricity consumed by refineries.	Million kilowatthours	ESRFPZZ is independent.
ESSCB	Electricity total consumption adjusted for process fuel.	Billion Btu	ESSCB = ESRCB + ESCCB + ESISB + ESACB
LGISB	LPG consumed by the industrial sector excluding refinery fuel.	Billion Btu	LGISB = LGICB - LGRFB
LGRFB	LPG consumed as refinery fuel.	Billion Btu	LGRFBZZ = LGRFPZZ * LGICKUS

Table A2. Consumption Adjustment Variables (cont.)

MSN	Description	Unit	Formula
LGRFP	LPG consumed as refinery fuel.	Thousand barrels	LGRFPZZ is independent.
LGSCB	LPG total consumption adjusted for process fuel.	Billion Btu	LGSCB = LGRCB + LGCCB + LGISB + LGACB
NGASB	Natural gas consumed by the transportation sector adjusted for process fuel.	Billion Btu	NGASB = NGACB - NGPZB
NGISB	Natural gas consumed by the industrial sector excluding refinery fuel and lease and plant fuels (including supplemental gaseous fuels).	Billion Btu	NGISB = NGICB - NGRFB - NGLPB
NGLPB	Natural gas consumed as lease and plant fuel.	Billion Btu	SEDS consumption variable
NGPZB	Natural gas consumed as pipeline fuel.	Billion Btu	SEDS consumption variable
NGRFB	Natural gas consumed as refinery fuel (including supplemental gaseous fuels).	Billion Btu	NGRFBZZ = NGRFPZZ * NGTXKZZ
NGRFP	Natural gas consumed as refinery fuel (including supplemental gaseous fuels).	Million cubic feet	NGRFPZZ is independent.
NGSCB	Natural gas total consumption adjusted for process fuel.	Billion Btu	NGSCB = NGRCB + NGCCB + NGISB + NGASB + NGEIB
NGTXK	Factor for converting natural gas consumed by all sectors other than electric power from physical units to Btu.	Thousand Btu per cubic foot	SEDS consumption variable
P1ISB	Asphalt and roal oil, kerosene, lubricants, and other petroleum products consumed by the industrial sector excluding refinery fuel and intermediate products.	Billion Btu	P1ISB = ARICB + KSICB + LUICB + POISB
P1SCB	Asphalt and roal oil, kerosene, lubricants, and other petroleum products total consumption adjusted for process fuel and intermediate products.	Billion Btu	P1SCB = ARTCB + AVTCB + KSTCB + LUTCB + POSCB
P5RFB	Other petroleum products consumed as refinery fuel and intermediate products.	Billion Btu	P5RFB = ABICB + MBICB + NAICB + PCRFB + PLICB + PPICB + SGICB + UOICB + USICB
PAISB	All petroleum products consumed by the industrial sector excluding process fuel and intermediate products.	Billion Btu	PAISB = ARICB + DFISB + KSICB + LGISB + LUICB + MGICB + RFISB + POISB
PASCB	All petroleum products total consumption adjusted for process fuel and intermediate products.	Billion Btu	PASCB = ARTCB + AVTCB + DFSCB + JFTCB + KSTCB + LGSCB + LUTCB + MGTCB + RFSCB + POSCB

MSN	Description	Unit	Formula
PCISB	Petroleum coke consumed by the industrial sector excluding refinery fuel.	Billion Btu	PCISB = PCICB - PCRFB
PCRFB	Petroleum coke consumed as refinery fuel.	Billion Btu	SEDS consumption variable
PCSCB	Petroleum coke total consumption adjusted for process fuel.	Billion Btu	PCSCB = PCCCB + PCISB + PCEIB
PEASB	Primary energy consumed by the transportation sector, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	PEASB = CLACB + NGASB + PAACB
PECSB	Primary energy consumed by the commercial sector, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	PECSB = CLCCB + NGCCB + PACCB + WWCSB
PEISB	Primary energy consumed by the industrial sector, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	PEISB = CLISB + NGISB + PAISB + WWISB
PERSB	Primary energy consumed by the residential sector, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	PERSB = CLRCB + NGRCB + PARCB + WDRSB
PESCB	Primary energy total consumption, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	PESCB = PESSB + PEEIB
PESSB	Primary energy total end-use consumption, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	PESSB = PERSB + PECSB + PEISB + PEASB
POISB	Other petroleum products consumed by the industrial sector excluding refinery fuel and intermediate products.	Billion Btu	POISB = FNICB + FOICB + FSICB + MSICB + PCISB + SNICB + WXICB
POSCB	Other petroleum products total consumption adjusted for refinery fuel and intermediate products.	Billion Btu	POSCB = PCCCB + PCEIB + POISB
RFISB	Residual fuel oil consumed by the industrial sector excluding refinery fuel.	Billion Btu	RFISB = RFICB - RFRFB
RFRFB	Residual fuel oil consumed as refinery fuel.	Billion Btu	RFRFBZZ = RFRFPZZ * 6.287
RFRFP	Residuial fuel oil consumed as refinery fuel.	Thousand barrels	RFRFPZZ is independent.

Table A2. Consumption Adjustment Variables (cont.)

MSN	Description	Unit	Formula
RFSCB	Residential fuel oil total consumption excluding process fuel.	Billion Btu	RFSCB = RFCCB + RFISB + RFACB + RFEIB
SFINB	Supplemental gaseous fuels consumed by the industrial sector.	Billion Btu	SEDS consumption variable
SOHCB	Photovoltaic and solar thermal energy consumed in the residential, commercial, and industrial sectors (excluding power generated at commercial and industrial facilities with capacity of 1 megawatt or greater).	Billion Btu	SEDS consumption variable
TEPFB	Total energy used as process fuel and other consumption that has no direct fuel costs.	Billion Btu	TEPFB = COICB + EMLCB + GECCB + GEICB + GERCB + HYCCB + HYICB + LOTCB + NGLPB + NGPZB + SOCCB + SOHCB + SOICB + TERFB + WDRXB + WWCXB + WWIXB + WYCCB + WYICB
TERFB	Total energy used as refinery fuel and intermediate products.	Billion Btu	TERFB = CLRFB + DFRFB + ESRFB + LGRFB + NGRFB + P5RFB + RFRFB
TNASB	Total net energy consumed by the transportation sector, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	TNASB = PEASB + ESACB
TNCSB	Total net energy consumed by the commercial sector, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	TNCSB = PECSB + ESCCB
TNISB	Total net energy consumed by the industrial sector, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	TNISB = PEISB + ESISB
TNRSB	Total net energy consumed by the residential sector, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	TNRSB = PERSB + ESRCB
TNSCB	Total net energy consumption, adjusted for process fuel, intermediate products, and fuels with no direct cost.	Billion Btu	TNSCB = PESSB + ESSCB
WDCUB	Wood consumed by the commercial sector other than CHP and electricity-only plants, at no cost.	Billion Btu	WDCUB = WDC4B - WDCVB
WDCVB	Wood consumed by the commercial sector other than CHP and electricity-only plants, costed.	Billion Btu	WDCVBZZ = WDC4BZZ * WDPHSZZ WDCVBUS = ΣWDCVBZZ

Table A2. Consumption Adjustment Variables (cont.)

MSN	Description	Unit	Formula
WDCYB	Wood consumed by commercial CHP and electricity-only plants, costed.	Billion Btu	WDCYBZZ = WDC3BZZ * WDEISUS WDCYBUS = ΣWDCYBZZ
WDCZB	Wood consumed by commercial CHP and electricity-only plants, at no cost.	Billion Btu	WDCZB = WDC3B - WDCYB
WDEIS	Purchased wood as a percentage of all wood consumed by the electric power sector, U.S. only.	Percent	WDEISUS is independent.
WDIYB	Wood consumed by industrial CHP and electricity-only plants, costed.	Billion Btu	WDIYBZZ = WDI3BZZ * WDEISUS WDIYBUS = Σ WDIYBZZ
WDIZB	Wood consumed by industrial CHP and electricity-only plants, at no cost.	Billion Btu	WDIZB = WDI3B - WDIYB
WDPHS	Purchased wood as a percentage of all wood consumed by the residential sector.	Percent	WDPHS is independent.
WDRSB	Wood consumed by the residential sector, costed.	Billion Btu	WDRSBZZ = WDRCBZZ * WDPHSZZ WDRSBUS = Σ WDRSBZZ
WDRXB	Wood consumed by the residential sector, at no cost.	Billion Btu	WDRXB = WDRCB - WDRSB
WSCYB	Waste consumed by commercial CHP and electricity-only plants, costed.	Billion Btu	WSCYBZZ = WSC3BZZ * WSEISUS WSCYBUS = ΣWSCYBZZ
WSCZB	Waste consumed by commercial CHP and electricity-only plants, at no cost.	Billion Btu	WSCZB = WSC3B - WSCYB
WSEIS	Purchased waste as a percentage of all waste consumed by the electric power sector, U.S. only.	Percent	WSEISUS is independent.
WSIYB	Waste consumed by industrial CHP and electricity-only plants, costed.	Billion Btu	WSIYBZZ = WSI3BZZ * WSEISUS WSIYBUS = ΣWSIYBZZ
WSIZB	Waste consumed by industrial CHP and electricity-only plants, at no cost.	Billion Btu	WSIZB = WSI3B - WSIYB
WWCSB	Wood and waste consumed by the commercial sector, costed.	Billion Btu	WWCSB = WDCVB + WDCYB + WSCYB
WWCXB	Wood and waste consumed by the commercial sector, at no cost.	Billion Btu	WWCXB = WDCUB + WDCZB + WSCZB
WWISB	Wood and waste consumed by the industrial sector, costed.	Billion Btu	WWISB = WWIVB + WDIYB + WSIYB

Table A2. Consumption Adjustment Variables (cont.)

MSN	Description	Unit	Formula
WWIXB	Wood and waste consumed by the industrial sector, at no cost.	Billion Btu	WWIXB = WWIUB + WDIZB + WSIZB
WWIUB	Wood and waste consumed by the industrial sector other than CHP and electricity-only plants, at no cost.	Billion Btu	WWIUB = WWI4B - WWIVB
WWIVB	Wood and waste consumed by the industrial sector other than CHP and electricity-only plants, costed.	Billion Btu	WWIVB is independent.
WWSCB	Wood and waste total consumption, adjusted for fuels with no direct cost.	Billion Btu	WWSCB = WWSSB + WWEIB
WWSSB	Wood and waste consumed by the end-use sectors, costed.	Billion Btu	WWSSB = WDRSB + WWCSB + WWISB