

Laptop Issue Guide

1. Common Fault Codes & Troubleshooting

If your laptop displays a Blue Screen of Death (BSoD) or a numeric error code on boot, document the code immediately. For temporary lockups, perform a hard reset by holding the power button for 30 seconds.

2. Power Issues

Ensure the power adapter is securely connected to both the wall outlet and the laptop. Verify the charging LED indicator is active. If the battery fails to hold a charge, contact IT for a replacement.

3. Screen Problems

For flickering or blank screens, try connecting an external monitor via HDMI or USB-C. If the external monitor displays correctly, the internal laptop screen may require hardware repair.

4. Keyboard/Mouse Faults

Clean the keyboard with compressed air. For trackpad issues, verify that it has not been disabled via function keys (Fn + F7). Try a USB peripheral to isolate the issue.

5. Escalation Procedure & Loaner Device Request

If self-troubleshooting fails, log a critical ticket on the IT Helpdesk. For repairs exceeding 24 hours, you may request a loaner laptop via the portal, subject to inventory availability.