# PROCECURES

## **OUTLINES**

Stack Operations

Defining and Using Procedures

#### Imagine a stack of plates . . .

- plates are only added to the top
- plates are only removed from the top
- LIFO structure

	√— top
10	√ top
9	)
8	)
7	)
6	)
5	)
4	
3	
2	)
1	→ bottom

## **5.1 STACK OPERATIONS**

- •A stack data structure follows the same principle as a stack of plates:
  - New values are added to the top of the stack, and existing values are removed from the top.
- •A stack is also called a LIFO structure (Last-In, First-Out) because the last value put into the stack is always the first value taken out.

#### Runtime Stack

- •The runtime stack is a memory array managed directly by the CPU, using the ESP (extended stack pointer) register, known as the stack pointer register.
- •ESP always points to the last value to be added to, or *pushed* on, the top of stack.
  - We rarely manipulate ESP directly; instead, it is indirectly modified by instructions such as CALL, RET, PUSH, and POP

Offset

00001000

00000006

 $\leftarrow$  ESP = 00001000h

00000FFC


00000FF8

00000FF4


00000FF0

#### **PUSH Operation**

•A 32-bit *push* operation decrements the stack pointer by 4 and copies a value into the location in the stack pointed to by the stack pointer.




•Same stack after pushing two more integers:



•runtime stack grows downward in memory, from higher addresses to lower addresses.

#### **POP Operation**

•A pop operation removes a value from the stack. After the value is popped from the stack, the stack pointer is incremented (by the stack element size) to point to the next-highest location in the stack.



#### STACK APPLICATIONS

- •A stack makes a convenient temporary save area for registers when they are used for more than one purpose.
- •When the CALL instruction executes, the CPU saves the current subroutine's return address on the stack.
- •When calling a subroutine, you pass input values called *arguments* by pushing them on the stack.
- •The stack provides temporary storage for local variables inside subroutines.

## PUSH AND POP INSTRUCTIONS

- •The **PUSH** instruction first decrements ESP and then copies a source operand into the stack.
  - A 16-bit operand causes ESP to be decremented by 2.
  - A 32-bit operand causes ESP to be decremented by 4.

```
PUSH reg/mem16
PUSH reg/mem32
PUSH imm32
```

- •The **POP** instruction first copies the contents of the stack element pointed to by ESP into a 16- or 32-bit destination operand and then increments ESP.
  - If the operand is 16 bits, ESP is incremented by 2; if the operand is 32 bits, ESP is incremented by 4:

POP reg/mem16
POP reg/mem32

#### PUSHAD, PUSHA, POPAD, POPA

- •The **PUSHAD** instruction pushes all of the 32-bit general-purpose registers on the stack in the following order: EAX, ECX, EDX, EBX, ESP (value before executing **PUSHAD**), EBP, ESI, and EDI.
- •The **POPAD** instruction pops the same registers off the stack in reverse order.
- •Similarly, the **PUSHA** instruction, pushes the 16-bit general-purpose registers (AX, CX, DX, BX, SP, BP, SI, DI) on the stack in the order listed. The POPA instruction pops the same registers in reverse.

```
data
aName BYTE "Abraham Lincoln",0
nameSize = (\$ - aName) - 1
.code
main PROC
; Push the name on the stack.
         ecx,nameSize
    mov
         esi,0
    mov
L1: movzx eax,aName[esi]
                                      ; get character
                                      ; push on stack
    push eax
    inc
         esi
    loop L1
; Pop the name from the stack, in reverse,
; and store in the aName array.
         ecx,nameSize
    mov
         esi,0
    mov
L2: pop
                                      ; get character
         eax
    mov aName[esi],al
                                      ; store in string
          esi
    inc
     loop L2
     INVOKE ExitProcess, 0
main ENDP
                                                 EXAMPLE: REVERSING A
END main
                                                       STRING
```

# 5.2 DEFINING AND USING PROCEDURES

- A complicated problem is usually divided into separate tasks (subroutines).
  - We typically use the term procedure to mean a subroutine.
- •A procedure is named block of statements that ends in a return statement
  - Declared using PROC and ENDP directives
- Must be assigned a name (valid identifier).

main PROC

.

main ENDP

- •When you create a procedure other than your program's startup procedure, end it with a RET instruction.
  - RET forces the CPU to return to the location from where the procedure was called:

```
sample PROC

add eax,ebx

add eax,ecx

ret
```

sample ENDP

- •Labels in Procedures are visible only within the procedure in which they are declared.
  - In the following example, the label named Destination must be located in the same procedure as the JMP instruction:

jmp Destination

•It is possible to work around this limitation by declaring a global label, identified by a double colon (::) after its name:

Destination::

#### CALL AND RET INSTRUCTIONS

- •The **CALL** instruction calls a procedure by directing the processor to begin execution at a new memory location
  - Pushes offset of next (instruction after call) on the stack
  - Copies the address of the called procedure into EIP
- •The **RET** instruction returns from a procedure
  - Pops top of stack into EIP

## CALL-RET EXAMPLE (1 OF 2)

0000025 is the offset of the instruction immediately following the CALL instruction

0000040 is the offset of the first instruction inside MySub


```
main PROC
00000020 call MySub
00000025 mov eax,ebx
.
.
main ENDP

MySub PROC
00000040 mov eax,edx
.
.
ret
MySub ENDP
```

## CALL-RET EXAMPLE (2 OF 2)

The CALL instruction pushes 00000025 onto the stack, and loads 00000040 into EIP


The RET instruction pops 00000025 from the stack into EIP




(stack shown before RET executes)

•A *nested procedure call* occurs when a called procedure calls another procedure before the first procedure returns.

By the time Sub3 is called, the stack contains all three return addresses:





In assembly language, it is common to **pass arguments inside general-purpose** registers.

```
.data
theSum DWORD ?
.code
main PROC
          eax,10000h
                                     ; argument
    mov
          ebx,20000h
                                     ; argument
    mov
    mov ecx,30000h
                                     ; argument
    call Sumof
                                     ; EAX = (EAX + EBX + ECX)
                                     ; save the sum
          theSum, eax
    mov
SumOf PROC
     add
            eax,ebx
     add
            eax,ecx
     ret
SumOf ENDP
```

#### **SUMMARY**

Stack

- Stack Operations
  - PUSH
  - POP

- Defining and using Procedures
- Call and Ret instructions