



Setup Steps

- 1 Prepare the Chassis by following the "Steps to Assemble Chassis" on Page 3
- 2 Mount the battery holder on chassis at Position 1 using Velcro
- 3 Mount the PCB Board on the Chassis at Position 2 using Velcro
- 4 Mount the IR Sensor on the Chassis at Position 3 using Velcro
- 5 Connect the IR Sensor to the Sensor JST connector on the PCB board using the 3-pin to 3-pin JST cable
- 6 Mount the Buzzer on the chassis at Position 6 and connect JST connector in the CON1 JST connector on the PCB board
- 7 Connect the Reverse JST cable to REV JST connector on the PCB board
- 8 Connect the Battery Holder to the Power JST connector on the PCB board
- 9 Check that all connections are secure before switching on the power



How It Works



When your hand comes near the IR sensor, it detects the motion and the buzzer rings.

It works without touching – keeping it clean, safe and hygienic!



How to Try It

- 1 Switch ON the circuit.
- 2 Move your hand in front of the IR sensor (without touching it).
- 3 You should hear the buzzer ring.
- 4 Try adjusting the distance and angle to see how it responds best.

CONTACTLESS DOOR BELL

Plug each module into the correct JST port

