



Setup Steps

- 1 Prepare the Chassis by following the "Steps to Assemble Chassis" on Page 3
- 2 Mount the battery holder on chassis at Position 1 using Velcro
- 3 Mount the PCB Board on the Chassis at Position 2 using Velcro
- 4 Mount the LDR Sensor on the Chassis at Position 3 using Velcro.
- 5 Connect the LDR Sensor to the Sensor JST connector on the PCB board using the 3-pin to 3-pin JST cable
- 6 Mount the LED on the chassis at Position 5 and connect JST connector in the CON2 JST connector on the PCB board
- 7 Connect the Battery Holder to the Power JST connector on the PCB board.
- 8 Check that all connections are secure before switching on the power.



How It Works



When the LDR sensor detects low light or darkness, the LED turns ON.

When the sensor detects bright light, the LED turns OFF.

This works like an automatic street light that switches on when it gets dark and switches off when there is enough light.



How to Try It

- 1 Cover the LDR sensor or place it in a darker area – the LED should turn ON.
- 2 Shine a torch on the LDR sensor – the LED should turn OFF.
- 3 Avoid very bright surrounding light while testing, as it may affect the sensor and produce unexpected results.





Small Projects. Big Possibilities!


EXPLORE • LEARN • INNOVATE

SMART Street Light

Plug each module into the correct JST port



How to connect the LDR Sensor



LDR Sensor: plug the 3-pin JST onto VCC, GND and DO. Leave AO unused.