




Plug each module into the correct JST port



## Setup Steps

- 1 Prepare the Chassis by following the "Steps to Assemble Chassis" on Page 3
- 2 Mount the battery holder on chassis at Position 1 using Velcro
- 3 Mount the PCB Board on the Chassis at Position 2 using Velcro
- 4 Mount the IR Sensor on the Chassis at Position 3 using Velcro
- 5 Connect the IR Sensor to the Sensor JST connector on the PCB board using the 3-pin to 3-pin JST cable.
- 6 Connect the Motor JST to CON2 JST connector on the PCB board
- 7 Connect the Reverse JST cable to REV JST connector on the PCB board
- 8 Connect the Battery Holder to the Power JST connector on the PCB board
- 9 Check that all connections are secure before switching on the power

## How It Works



When your hand comes near the IR sensor, the robot detects the motion and moves backward.

This works like a "don't pet me" robot that keeps its distance!

## How to Try It

- 1 Switch ON the circuit.
- 2 Place your hand in front of the IR sensor (without touching it).
- 3 The robot should move backward.
- 4 Try adjusting the distance and angle to see how it responds best.



Small Projects. Big Possibilities!

EXPLORE • LEARN • INNOVATE