


PLA Single Recall Application Overview

- Introduction
- System walkthrough

Introduction




• The single recall is used for the selective change of a parts recall status without the need to use the standard recall application



Initiation

Navigate to http://produktionssysteme-prodweb.app.corpintra.net/.




Click on Dev1 SM and Enter your credentials

Initiation


Daimler AG - Microsoft Edge

A https://login-int.daimler.com/test?brand=default&TYPE=33554432&REALMOID=06-26f532a8-8554-1014-86



Enter valid user name and password and Click on Log on button

Home Page-Prod web tree




On Click of login button Prodweb page is displayed.


PLA user can select respective Plants and Cost center and access the PLA application

To select particular node navigate from Machines>Plant 10 → Production Engines[PT/M] → PT/MVM

Content




System Tutorial Navigation




PLA-User can access any module based on the rights assigned to each user. On Click of Single Recall module Single Recall Search page will be displayed

MBRDI is only responsible for Search, Recall, Single recall and Injector Data check. Archive is not in the scope of MBRDI.


Single Recall Screen




Single recall on Click of Search




Single recall on Click of Search




Single recall on Click of Search button




Single recall on Click of Search button




On Click of Part ID hyperlink




Click of Print preview button




Click of Print preview button




On Click of Column toggle




On Click of Print button inside print preview window




Change status and system for recall number B18722




On Click of Confirm button



Click on Reset button



On Click of Reset button



On Click of Reset button ,Results are cleared.

Single Recall Confirmation

- When Status and System is changed and clicked on confirm button, Status and System should be updated for that recall number and stored in DB. Recall Statistics should be displayed with count value.
- When Life cycle window is opened after Status and System change, Information should get updated in respective recall number. Expand accordian to view the state, modified date and user. Entry should get created in chronology arranged based on date (Ascending order)".
- Print preview must reflect the updated data of recall number. Part Overview and "Recall Information" to be displayed with same data. Data should match.