

Legend:



F= Ceiling Fan



S= 5A-2 pin Switched Socket



TV= TV outlet with 3-4" PVC pipe



TL= Telephone outlet with 3 4" PVC pipe



L=Incandescent Wall Mounted Bracket Light Fitting



R= 20A-3pin Switched Socket at 36" Level



LCE=Energy Saving Light Fitting (Ceiling Mounted)



Ex= Exhaust Fan



SB= Switch Board



SDB= Sub Distribution Board