


Pause keeps the mission available to resume



Manual or Hold is different: either one stops and cancels autonomous navigation.