


Dual Joystick Remote Controller — numbered operator guide

1 Prepare controls




Left RTK · Middle GPS · Right RC
J1/J2 centered

2 Read Home screen

ONLINE RSSI -62
MODE HOLD
CMD 0.0 / 0.0
UVC DISARMED

3 Drive with J2



SW5

Manual / Hold

4 Navigate pages



Previous / Next
SW3 Select · SW4 Back

5 Confirm UVC warning

UV-C WARNING
SW3 = TURN ON
SW4 = CANCEL

10-second timeout

6 Use Wi-Fi setup



RC-Controller
rccontroller
192.168.4.1

Keep RC and RTK radio settings separate