

Camera Panel

Recording Mode

Images (12 MP) ▼

Exposure



Frame Rate / Min. Movement

Numeric inputs and sliders

Start / Stop Recording

Download Data

Delete Images



Tap-to-focus/expose:

tap the camera view to focus and adjust exposure there (requires control)