


## Navigation controller — numbered automatic-mission guide

### 1 Inspect controller




PoE · cooling · CSI · lens

### 2 Start services

```
camera.service  
ACTIVE  
CAN ONLINE  
VIDEO READY
```


Keep robot in Hold

### 3 Open web console




Map + GPS + video + status

### 4 Draw safe boundary



At least 3 boundary points

### 5 Add and review route



Check rows · turns · speed

### 6 Upload and verify

UPLOAD



Robot must be inside geofence

### 7 Start and supervise

AUTO

START

Watch robot + map + RTK  
Operator remains at E-stop

### 8 Pause or finish

PAUSE

HOLD

Correct fault before Resume  
Save logs · clean shutdown