

PATENTED · MADE IN USA

Roll Puller™ RP3XL & RP4XL

One-operator unloading for geosynthetic rolls in vans, containers, and flatbeds.



Multiple pullers unload a full container in minutes — safely, without a crew of four.

Why Roll Pullers

Manual unloading of geosynthetic rolls from vans and containers is where crews get hurt and rolls get damaged. The Roll Puller™ eliminates the pry-bar-and-shoulder routine.

- **One operator** pulls the roll — no team lift.
- **Up to 10x faster** with multiple pullers.
- **Protects cardboard cores** so rolls stay usable.
- **Pays for itself in a few shipments.**

Model Specifications

MODEL	CORE ID RANGE	MIN. CORE THICKNESS	BEST FIT
RP3XL	2.75" – 3.25"	0.5"	Standard paving-fabric and geotextile rolls, singly or banded in pairs and trios.
RP4XL	3.75" – 4.50"	0.5"	Oversized geosynthetic rolls, hybrid mats, and larger cardboard cores.

Engineering (2016 Redesign)

- **Grabs 4" deeper** into the cardboard core, multiplying its effective capacity.
- **Patent-pending laser-cut armor plate teeth** maintain grip and reduce core tearing.
- **Forged ring, double-welded** onto machined shaft steel.
- **Handles multi-roll banded groups** in one pull.

Field Performance

"3 RP4XL Roll Pullers pulling a 75-roll tier of paving fabric in 25 banded groups of 3 rolls in one pull. I was amazed."

— Contractor, name withheld

Watch a 3-Roll Puller set pull 6 banded groups of 18 rolls:

[youtube.com/shorts/7I6ESZXjh4Y](https://www.youtube.com/shorts/7I6ESZXjh4Y)

Courtesy of US Silt & Site Supply · Bow, NH 03304

Pricing & ordering: Pricing and shipping quoted on request — include quantity, model, and shipping ZIP code. Full accessory chain, hook, and O-ring systems available for complete kits.

SAFETY FIRST

Roll Pullers do not break with proper use. Chains, cables, ropes, and slings do break.

1 Never exceed the Working Load Limit

The WLL is less than breaking strength — that's the point. OSHA requires you stay below it, every pull.

2 Stand to the side of the truck

Never stand behind the ropes, chains, or in line with the pull. A snapped rigging line kills.

3 Pull horizontally, not down

Insert the puller horizontally, then lift slightly or pull level. Downward pulls tear the core wall.

4 Train every operator

Speed and safety come from operators who understand the rig. Walk every new operator through the drill.

Recommended Technique

- Insert horizontally until the teeth seat, then lift slightly or pull level.
- Guide rolls along rails, a dolly, or a waiting forklift to prevent core drag.
- For loosely wrapped rolls where cores start to pull out, use multiple Roll Pullers — one in each core — to distribute load.
- Pyramided rolls can be pulled until roll weight exceeds the puller's tested capacity.

Rigging Configurations

Puller Set	Chain Configuration
2 Puller Set	Two 6-foot chains
3 Puller Set	One 4-foot center chain + two 6-foot outer chains
4 Puller Set	Two 4-foot chains + two 6-foot chains

Chain, hooks, and O-rings sized for complete Roll Puller systems are available on request.

Warranty

90-day warranty against defects from date of purchase with proper use. Full operating instructions are included with every order. Contact GAC for warranty claims, replacement parts, or additional operator training.